



OPERATING INSTRUCTIONS

Leeb 5.300 / 6.300 VL

OPERATING INSTRUCTIONS FOR MACHINE WITH
SERIAL NUMBER 25181251
READ THOROUGHLY BEFORE COMMISSIONING!
KEEP THE OPERATING INSTRUCTIONS IN A SAFE PLACE!

EDITION: 12/2020

HORSCH

Farming with passion

- Translation of the original Operating Instructions -

Identification of machine

Please enter the corresponding data into the following list upon reception of the machine:

Serial number:
Machine type:
Year of
construction:
Initial use:
Accessories:
.....
.....
.....

Issuing date of operating instructions: 12/2020
Last change:

Leeb 5.300 / 6.300 VL

Dealer address: Name:
 Road:
 Place:
 Phone:

.....

Cust. No. Dealer:

Address of HORSCH: HORSCH Maschinen GmbH
 92421 Schwandorf, Sitzenhof 1
 92401 Schwandorf, P.O.Box 1038

Phone: +49 9431 / 7143-0
Fax: +49 9431 / 7143-9200
E-mail: info@horsch.com

Cust. No.: HORSCH:

Confirmation of receipt of machinery

Warranty claims become only effective when the first use of the machine is reported to HORSCH Maschinen GmbH within a week.

At www.horsch.com under *SERVICE PARTNERBEREICH* an interactive PDF form is available for download for this purpose (not available in all languages).

By clicking on *Send* – depending on the e-mail program installed – an e-mail draft with the completed form is generated automatically. Alternatively, the form can be sent as e-mail attachment to *machine.registration@horsch.com*.

A different form of registration (postal mail, by fax, etc.) is not allowed for.



EG-Konformitätserklärung

Die

HORSCH LEEB Application Systems GmbH

Kleegartenstraße 54, D-94405 Landau a. d. Isar

erklärt hiermit in alleiniger Verantwortung als Hersteller, dass das nachfolgend genannte Produkt:

Selbstfahrende Pflanzenschutzspritze
Typ: **Leeb 5.300 VL**
Leeb 6.300 VL
Leeb 8.300 VL

den einschlägigen grundlegenden Sicherheits- und Gesundheitsanforderungen der Richtlinien 2006/42/EG und 2009/127/EG entspricht.

Landau, 29.05.2020

Theodor Leeb
Geschäftsführer

Klaus Winkler

Dokumentationsbevollmächtigter
HORSCH Maschinen GmbH
Sitzenhof 1
D-92421 Schwandorf

Translation of EC Declaration of Conformity

(Directive 2006/42/EC)

The manufacturer

HORSCH LEEB Application Systems GmbH
Kleegartenstraße 54 21
D-94405 Landau a. d. Isar

hereby declares that the product

Type: **Self-propelled crop protection sprayer**
Leeb 5.300 VL
Leeb 6.300 VL
Leeb 8.300 VL

this declaration refers to, conforms with all relevant fundamental health and safety requirements of the directive 2006/42/EC and 2009/127/EC.

Landau, 29/05/2020

Klaus Winkler

Theodor Leeb
Managing director

Documentation Representative
HORSCH Maschinen GmbH
Sitzenhof 1
D-92421 Schwandorf

Table of contents

| | | | |
|--|-----------|---|-----------|
| Introduction..... | 7 | Design..... | 40 |
| Foreword | 7 | Overview..... | 40 |
| Notes on representation | 7 | Hydraulics..... | 41 |
| Service..... | 8 | Lighting..... | 42 |
| Warranty claim processing | 8 | Instruction stickers..... | 44 |
| Consequential damage..... | 8 | | |
| Safety and responsibility | 9 | Components Chassis..... | 45 |
| Intended use..... | 9 | Engine | 45 |
| Qualification of personnel..... | 10 | Engine oil | 45 |
| Children in danger | 11 | Engine coolant | 46 |
| Personal protective outfit..... | 11 | Compressed air connection | 47 |
| Safety in traffic..... | 11 | Ribbed V-belt | 47 |
| Safety in operation..... | 12 | Fuel tank..... | 48 |
| Crop protection agents and liquid fertiliser ... | 16 | Fill up fuel / urea solution..... | 48 |
| Environmental protection..... | 17 | Exhaust gas system Leeb 5.300 / 6.300 VL .. | 49 |
| Retrofitting and conversions..... | 17 | Hydraulic oil tank | 52 |
| Care and maintenance | 17 | Steering | 54 |
| Danger zone | 19 | Brake system..... | 54 |
| Use on hillside locations | 20 | Mechanical release mechanism of | |
| Safety stickers | 21 | parking brake | 55 |
| | | Axles..... | 55 |
| Commissioning..... | 26 | Wheel drive..... | 56 |
| Delivery..... | 26 | Wheels and tires..... | 57 |
| Transport | 26 | Wheel change..... | 58 |
| Installation | 26 | Adjusting the track width..... | 59 |
| Adjusting the track width..... | 27 | Suspension (ComfortDriveFlex) | 59 |
| Mechanical track width adjustment..... | 27 | Mechanical release fixture folding boom | |
| Height adjustment..... | 29 | block / parallelogram and Load Sensing | |
| Mechanical height adjustment | 29 | activation | 60 |
| Initial commissioning of the service brake | | Mechanical release device spraying pump | |
| system | 30 | and fan..... | 60 |
| Assemble the wheels..... | 30 | Mechanical release device of access | |
| | | ladder | 61 |
| Technical Data Leeb 5.300 / 6.300 VL (Emission Standard Stage 5 Variant)..... | 31 | Mechanical release device for hydraulic | |
| Type plate | 35 | track width adjustment (TrackControl)..... | 62 |
| Dimensions..... | 36 | Mechanical release device hydraulic height | |
| Weight and tires..... | 36 | adjustment ClearanceControl (optional) .. | 62 |
| | | Maintenance access..... | 63 |
| | | Platform railing | 63 |
| | | Cooler package | 64 |
| | | Air filter | 64 |

| | | | |
|--|-----------|---|-----|
| Air conditioning system..... | 66 | Steering column..... | 85 |
| Refrigerant..... | 66 | Steering column adjustment | 85 |
| Drier cartridge air conditioning system | 67 | Multi-function switch | 86 |
| Pressure switch | 67 | Driving information..... | 88 |
| Condenser | 67 | Multi-function control panel..... | 89 |
| Checking refrigerant condition and filling quantity | 68 | Overview of operator functions | 90 |
| Windscreen washing system..... | 68 | Drive lever..... | 91 |
| Compressed air system..... | 68 | Transport / Service position | 91 |
| Compressed air system dryer cartridge..... | 69 | Travel direction switch | 91 |
| Electrics | 70 | Air conditioning / Heater | 92 |
| Battery | 70 | Switching on the air conditioner / heater.... | 92 |
| Battery main switch..... | 71 | Switching on the climate control system.... | 93 |
| Three-phase alternator | 71 | Setting the cabin temperature..... | 93 |
| Starter | 71 | Manual fan speed control | 93 |
| Transport and safety container..... | 72 | Activate ECON mode..... | 94 |
| Tool storage | 72 | Drying cabin windows with REHEAT mode..... | 94 |
| Cabin..... | 73 | Display outside temperature | 94 |
| Access ladder..... | 73 | Change temperature unit..... | 94 |
| Cabin door | 74 | Adjusting the air flow of the air conditioner | 94 |
| Overview..... | 75 | Malfunction and remedy Air conditioning system | 95 |
| Overview roof console | 76 | Error code table | 97 |
| Overview roof console | 77 | Running the air conditioner..... | 98 |
| Overview roof console / A-pillar | 78 | Operating terminal | 99 |
| Driver's seat..... | 79 | Machine terminal | 99 |
| Overview..... | 79 | Ignition lock..... | 99 |
| Weight adjustment | 80 | Pedal | 100 |
| Height adjustment..... | 80 | Emergency exit..... | 100 |
| Horizontal suspension | 80 | Open door completely..... | 100 |
| Longitudinal adjustment..... | 81 | Open door a crack | 101 |
| Seat inclination adjustment..... | 81 | Sun visor..... | 101 |
| Seat depth adjustment..... | 81 | Cabin lighting and reading lamp..... | 101 |
| Arm rest | 82 | Cooling box..... | 102 |
| Armrest inclination | 82 | Storage compartment..... | 102 |
| Backrest adjustment | 82 | Camera system | 103 |
| Lumbar support | 82 | Overview..... | 103 |
| Lateral horizontal suspension | 83 | Main menu | 104 |
| Seat heating / ventilation | 83 | Rear view camera (optional)..... | 105 |
| Stowage bag..... | 83 | Wheel camera (optional)..... | 105 |
| Seat belt..... | 83 | Nozzle camera (optional)..... | 105 |
| Instructor's seat | 84 | Outside rear view mirror | 106 |

| | | | |
|--|------------|---|------------|
| Mirror heating..... | 106 | Field mode..... | 136 |
| Sockets..... | 107 | Construction | 137 |
| Central electrical system, top | 108 | Overview..... | 137 |
| Central Electrics (CE) Machine..... | 110 | Superstructure components | 138 |
| Electrics Battery case | 112 | Spraying mixture container..... | 138 |
| Electrics Optional..... | 112 | Access steps..... | 138 |
| Circulating air filter..... | 113 | Maintenance access | 139 |
| Fresh air filter category 2..... | 113 | Dome | 139 |
| Cabin air filters category 4 (optional)..... | 115 | Fresh water tank..... | 140 |
| Radio | 120 | Hand washing tank | 140 |
| On / Off | 120 | Spraying pump | 141 |
| Multi-mode buttons | 120 | Centrifugal pump for cleaning..... | 142 |
| Volume knob | 120 | Illuviation valve | 142 |
| Station scan | 120 | Basic/CCS agitator | 144 |
| Saving the radio station | 121 | Agitator Basic Pro/CCS Pro..... | 144 |
| Playing media files..... | 121 | Filter..... | 144 |
| Software menu..... | 121 | Control unit | 146 |
| Bluetooth..... | 122 | Fittings | 147 |
| Engine operation | 123 | Water flow Basic / CCS | 147 |
| Before starting the motor | 123 | Ports | 147 |
| Requirements for motor start..... | 123 | External control terminal..... | 147 |
| Switch on ignition..... | 123 | Water flow Basic Pro / CCS Pro | 148 |
| Start the engine | 123 | Ports | 148 |
| Shut down the engine..... | 124 | External control terminal..... | 148 |
| Travel operation..... | 125 | Filter..... | 149 |
| General notes | 125 | Folding boom..... | 150 |
| Forward / reverse driving..... | 125 | Folding variants | 151 |
| Forward driving | 125 | BoomControl..... | 152 |
| Reverse driving..... | 127 | Transport lock | 153 |
| Reverse direction of travel..... | 128 | Collision protection | 155 |
| Brakes..... | 128 | Spraying line | 156 |
| Parking brake..... | 128 | Nozzle body | 157 |
| Service brake..... | 129 | Pulse width modulation (PresicionSpray) 160 | |
| Drive slippage control..... | 129 | Optional equipment..... | 162 |
| Travel modes..... | 130 | GPS receiver (optional) | 162 |
| Road operation | 130 | Edge and border nozzles..... | 164 |
| Field mode | 130 | NightLight (optional) | 165 |
| Cruise control | 131 | Direct filling (optional)..... | 166 |
| Road / field travel..... | 132 | Direct filling without pump..... | 166 |
| Towing..... | 133 | Direct filling with pump..... | 166 |
| Remote start / jump start | 133 | Wind meter (optional) | 166 |
| Machine terminal | 135 | Outside cleaning (optional)..... | 166 |
| Operation..... | 135 | N-Sensor bracket (optional)..... | 168 |
| Road mode | 135 | | |

| | | | |
|---|------------|--|------------|
| Safety package (optional)..... | 168 | bonyl diamide | 201 |
| Fire extinguisher (optional)..... | 169 | Canister cleaning | 202 |
| Operation..... | 170 | Spraying operation | 204 |
| Commissioning | 170 | Folding boom control | 205 |
| Parking | 170 | Control and regulation of spraying | |
| Transport position..... | 171 | functions | 205 |
| Multi-function control panel..... | 172 | Residual quantities..... | 208 |
| Overview of the operator functions for | | Technical residual quantities..... | 208 |
| spraying | 172 | Draining technical residual quantities | 208 |
| SectionBox (optional) | 173 | Draining technical residual quantities | 209 |
| Folding the folding boom | 174 | Water systems Basic, CCS, Basic Pro | |
| Unfolding..... | 175 | and CCS Pro..... | 209 |
| Folding in | 175 | Diluted residual quantity | 209 |
| Preparation for spraying operation | 176 | Diluting the residual quantity | 209 |
| Preparing the spraying mixture..... | 177 | Water systems Basic Pro and CCS Pro .. | 209 |
| Nozzle selection..... | 178 | Water systems Basic and CCS..... | 209 |
| Fluid circuit | 185 | Draining the fresh water tank..... | 210 |
| Design of water system Basic and | | Cleaning | 211 |
| water system CCS | 185 | Cleaning the filters | 212 |
| Fluid circuit | 189 | CCS - Continuous inside cleaning | |
| Design of Water system Basic Pro and | | (Continuous Cleaning System)..... | 214 |
| water system CCS Pro | 189 | Cleaning with drained spraying mixture | |
| Filling with water | 193 | container | 214 |
| Filling the spraying mixture container | | Cleaning with filled spraying mixture | |
| through the filling port | 194 | container | 216 |
| Water systems Basic Pro and water | | Procedure for machines of the CCS Pro | |
| system CCS Pro | 194 | and Basic Pro variant:..... | 216 |
| Water systems Basic and water | | Procedure for machines of the CCS | |
| system CCS..... | 194 | and Basic variant | 217 |
| Direct filling / External filling (optionally | | Folding boom cleaning with Air Valve | |
| without pump) | 195 | (optional)..... | 217 |
| Direct filling / External filling (optionally | | Cleaning the spraying mixture container | |
| with PowerFill pump) | 195 | only for machines of the CCS and | |
| Filling via the dome..... | 196 | CCS Pro variant..... | 217 |
| Filling the fresh water tank through the | | Outside cleaning (optional)..... | 217 |
| filling port | 196 | Care and maintenance | 219 |
| Illuviation of preparations..... | 198 | Faults..... | 222 |
| Illuviation valve | 198 | Superstructure maintenance overview | 223 |
| Flushing in liquid preparations during | | Overview of basic vehicle lubrication | |
| filling..... | 199 | points | 226 |
| Flushing in liquid preparations with full | | Folding boom 5-piece double folding..... | 227 |
| or partly filled spraying mixture container | 201 | Overview of lubrication points middle | |
| Illuviation of powdery preparations and car- | | section | 228 |
| | | Calibrating the flow meter | 230 |

| | |
|---|------------|
| Calibrating the flow meter | 231 |
| Inspection of the crop protection sprayer | 232 |
| Maintenance overview chassis..... | 233 |
| Fuels and lubricants..... | 237 |
| Maintenance of the hydraulic system | 238 |
| Inspection criteria for hydraulic hoses | 239 |
| Assembly and disassembly of hydraulic hoses | 239 |
| Storage | 240 |
| At the end of the season | 240 |
| Drain | 240 |
| Putting the sprayer system into winter storage | 241 |
| Residue drain | 241 |
| Winter storage | 242 |
| Before the new season | 243 |
| Waste disposal | 244 |
| Appendix | 245 |
| Anzugsdrehmoment | 245 |
| HORSCH Leeb metering cup | 247 |
| Determining the placing quantity in l/ha | 247 |
| Nozzle selection and control | 247 |
| Liquid fertiliser operation | 248 |
| Index | 250 |

Introduction

Foreword

We would like to thank you for the trust you have expressed in us by buying this machine. Congratulations for having purchased a quality product from HORSCH.

Before commissioning the machine, read and strictly comply with the operating instructions. In doing so, you will avoid accidents, reduce repair costs and downtime and increase the reliability and service life of your machine. Pay attention to the safety notes!

HORSCH will not assume liability for any damage or malfunctions resulting from failure of complying with the operating instructions.

These operating instructions will assist you in getting to know your machine and using it correctly for its intended purposes.

The operating instructions must be read and strictly adhered to by all persons working on or with the machine e.g.:

- Operation (including preparation, fault rectification during work, care)
- Maintenance (maintenance, inspection)
- Transport

Optionally, trained personnel of our service and sales partners will instruct you in the operation and care of your machine. By submitting the acknowledgement of receipt you have confirmed proper acceptance of the machine.

The warranty period starts with the date of delivery.

The operating instructions were prepared based on the EC Machinery Directive, EN Standards and German laws and regulations. The national laws and regulations must be observed when using the machine. National laws and regulations supersede the information of the operating instructions!

We reserve the right to alter illustrations as well as technical data and weights contained in these operating instructions for the purpose of improving the machine.

The illustrations in these operating instructions show different versions of the machine and different equipment variants.

Because of technical progress, the instructions may contain illustrations that do no longer correspond to the current series status.

Notes on representation

Warning notes

These operating instructions distinguish between three different types of warning notes.

The following **signal words with warning symbols** are used:

DANGER

Highlights a danger that **will lead** to death or severe injury if it is not avoided.

WARNING

Highlights a danger **that may lead** to death or severe injury if not avoided.

CAUTION

Highlights a danger that can lead to injury if not avoided.

Please read the warning notes given in these operating instructions!

Instructions



NOTE

Identifies important notes.

Take-action instructions are indicated by arrow points:

➤ ...

- Keep the order of the instructions. Alternatively, instructions may be numbered consecutively.

The designations *right*, *left*, *front* and *rear* apply as seen in travel direction.

Service

HORSCH Company would like you to be completely satisfied with your machine and our services.

If you encounter any problems, please feel free to contact your sales partner.

The service staff of our sales partners and the service employees at HORSCH will always be available to assist you.

In order to be able to solve technical problems as quickly as possible, we ask you kindly to support us.

Please help the service personnel by providing the following information to avoid unnecessary queries.

- Customer number
- Name of customer representative
- Name and address
- Machine model and serial number
- Purchasing date and operating hours or area performance
- Type of problem

Warranty claim processing

Warranty claim forms must be submitted to HORSCH through your local HORSCH sales partner.

Consequential damage

The machine has been manufactured by HORSCH with greatest care. However, despite the intended use deviations in placing quantity up to total failure may be caused by e.g.:

- damage caused by external influences
- wear of wear items
- missing or damaged tools
- incorrect travel speeds
- incorrect setting of the unit (non-observance of setting notes)
- failure to comply with the operating instructions
- blockages or seed bridging
- neglect and improper care and maintenance

Therefore, it is crucial to always check your machine before and during use for correct operation and adequate application accuracy.

Compensation claims for damages that have not occurred on the machine are excluded. This also means that any liability for consequential damages caused by travel and operating faults is excluded.

Safety and responsibility

The following warnings and safety notes apply to all sections in these operating instructions.

The machine has been built in accordance with latest technical standards and generally accepted safety regulations. However, risks for life and limb of the operator or third parties and impairment of the machine or other material assets can occur during use.

Please read and comply with the following safety notes, **before** you start to use the machine!

Intended use

The machine is intended for the application of fluids on agricultural areas. The application of crop protection agents and liquid fertilizers (AHL) on agricultural land is particularly important. The machine can be used to mix, dose and transport the biocatalyst to be placed on the application area.

The intended use also includes taking note of and observing the notes and instructions given in these operating instructions, observing all pictograms and warnings on the machine, observing all maintenance and repair intervals and complying with the defined technical limits and areas of application.

When participating with the machine in public road traffic, the respective national registration and traffic law must also be complied with.

The permissible axle loads must not be exceeded during road travel.

Any other kind of use of the machine contradicting the above, are considered not as intended, especially:

- filling the machine with flammable fluids other than those approved in the scope of the operating instructions
- exceeding the permissible technical total weight
- towing and retrieving other vehicles
- operating the machine while persons are still in the danger zone (this includes in particular transport rides on the machine)
- carrying out maintenance and/or repair work on a machine that has not been shut down or is not secured against restarting.

Horsch does not assume any liability for damages resulting from the unintended use of the machine.

Spare parts

Genuine spare parts and accessories from HORSCH have been specially designed for this machine.

Spare parts and accessories which are not delivered by us have not been tested or approved by us.

Installation or use of non-original HORSCH products may have a detrimental effect on specific design features of the machine and impair the safety of machine operators and the machine itself.

HORSCH will not assume liability whatsoever for damage resulting from the use of non-original parts and accessories.

If the component to be replaced is marked with a safety sticker, these stickers must also be ordered and attached to the spare part.

Operating Instructions

The operating instructions are a part of the machine!

Failure to comply with the operating instructions can result in severe or even fatal physical injuries.

- Read and follow the corresponding sections in the operating instructions before starting work.
- Store the operating instructions and keep for future use.
- Pass the operating instructions on to a later user.

Qualification of personnel

Unintended use of the machine can lead to severe or even fatal physical injuries. In order to prevent accidents, each person involved in work with the machine must meet the following general minimum requirements:

- The person must be physically able to keep the machine under control.
- The person is able to perform work with the machine safely within the scope of these operating instructions.
- The person is acquainted with the function of the machine within the scope of its work and is able to assess and avoid any work related dangers. The person is able to recognize and avoid work related dangers.
- The person has understood the operating instructions and is able to implement the information given in the operating instructions accordingly.
- The person is fully familiar with the safe operation of the vehicle.
- The person knows all applicable road traffic regulations and is in possession of a valid driving permit for road travel.
- A person being instructed must only work with or on the machine under the supervision of an experienced person.

The owner of the machine must

- regulate the area of responsibility, competence and monitoring of personnel.
- if necessary train and instruct the personnel.
- make the operating instructions accessible for the machine operator.
- ensure that the operator has read and fully understood the operating instructions.

Groups of operators

Persons who work with the machine must have been trained for the different activities involved.

Instructed operators

These persons must have been trained for their respective activities by the owner or other qualified experts. This refers to the following activities:

- Road transportation
- Application and set-up work
- Operation
- Maintenance
- Troubleshooting and repair

Operators trained by HORSCH

Furthermore, for certain activities the corresponding personnel must have been trained by service personnel from HORSCH. This refers to the following activities:

- Loading and transport
- Commissioning
- Troubleshooting and repair
- Waste disposal

Certain work concerning maintenance and repair must only be carried out by an expert workshop. Such work is identified with the additional comment *Workshop work*.

Children in danger

Children are not able to assess dangers and may behave unpredictably. Children are therefore especially endangered:

- Keep children away from the machine.
- Especially before drive off and before triggering machine movements you must make sure that the danger zone is free of children.
- Shut down the machine before leaving it. Children can trigger dangerous machine movements. An insufficiently secured machine parked without being attended poses a danger for playing children!

Personal protective outfit

WARNING

Health hazards caused by accidental contact with crop protection agents or spraying mixture!

Wear personal protective outfit:

- when preparing the spraying mixture
- when cleaning / replacing the spraying nozzles, during spraying operation, during all work for cleaning the machine after spraying operation.

To wear the required protective outfit always observe the operating instructions and the safety data sheet of the crop protection agent used.

Missing or incomplete protective equipment increases the risk of health damage. Personal protective equipment includes, e.g.:

- overall resistant to chemicals
- protective gloves resistant to chemicals
- shoes resistant to chemicals
- face protection
- safety goggles to protect against splashes

- Respirator
- Provide effective protective equipment in proper condition.
- Never wear rings, bracelets or other jewellery.

Wear the personal protective outfit stipulated in the safety data sheet of the crop protection agent last used when cleaning the self-propelled crop protection sprayer!

NOTE

The owner must provide the necessary personal protective outfit as specified by the manufacturer of the crop protection agent used.

NOTE

Do not enter the machine's cabin with contaminated protective outfit!

Safety in traffic

DANGER


No passengers are allowed to ride on the machine!

- Pay attention to the permissible transport widths and heights. Pay attention to the transport height when passing under bridges and low hanging overhead power lines.
- When driving on public roads comply with the respective national road traffic regulations!
- Do not exceed the permissible axle load, tire load bearing capacity and total weight, in order to ensure sufficient steering and braking capabilities.
- The weight and speed must be chosen so that the machine can be safely managed under any condition.

- Travel characteristics, steering and braking ability are influenced by attached or hitched up equipment and ballasting weights. You should therefore pay attention to sufficient steering and braking ability!
- Check the brake and hydraulic system for apparent faults before road travel.
- The parking brake must be fully released and the service brake functioning.

For road transport the machine must be set to transport position. The folding boom must be folded up and secured. The stroke of the parallelogram and the optional rear axle steering must always be locked during road travel.


- Check lighting, warning and protective features for functioning and cleanliness.

 The permissible maximum speed specified in the type approval must be complied with for transport on public roads!

The specifications in the type approval document or in the technical data are decisive for the design dependent top speed.

Always match the travel mode to the road conditions to avoid accidents and damage to the undercarriage.

Consider your personal abilities, carriage way, traffic, sight and weather conditions.

 In addition, pay attention to the notes in chapter *Commissioning*!

Safety in operation

Commissioning

The operational safety of the machine cannot be guaranteed without orderly performed commissioning. This can lead to accidents with severe or even fatal physical injuries.

- The machine must only be put into operation after receiving instructions by employees of the authorized dealer or a HORSCH employee.
- The machine registration form must be completed and returned to HORSCH.

All protective features and safety equipment, such as detachable protective devices (wheel chocks, etc.), must be correctly in place and reliably functioning before the machine is put into operation.

- Check nuts and bolts, especially on wheels, regularly for a tight fit and re-tighten if necessary.
- Check the tire pressure at regular intervals, see maintenance overview.

Damage to the machine

Damage to the machine can impair the operational safety of the machine and cause accidents. This can lead to severe or even fatal physical injuries.

The following machine parts are particularly important for safety:

- Hydraulics
- Brakes
- Connecting features
- Protective features
- Lighting

If in doubt about the safety-relevant status of the machine, e.g. in case of leaking operating fluids, visible damage or unexpected changes in travel behaviour:

- Immediately shut down and secure the machine.
- If possible locate and rectify the faults by following these operating instructions.
- Rectify possible causes for damage (e.g. remove dirt and tighten loose screws).
- Have damage that could affect safety and that cannot be rectified by you rectified by a qualified expert workshop.

Hydraulics

The hydraulic system is under high pressure. Escaping fluid can penetrate the skin and cause serious injuries. In the event of injury, consult a doctor immediately.

The machine's hydraulics has several functions, which can cause injury to persons or damage to the machine if operated incorrectly.

- Lock all hydraulically operated parts before any work on the hydraulic system. Depressurize the hydraulic system. Shut down the engine, engage the parking brake and pull off the ignition key.
- The hydraulic system is under high pressure. Check all lines, hoses and screwed connections regularly for leaks and any visible external damage!
- Use only appropriate means when searching for leaks. Repair any damage immediately! Oil sprays can cause injuries and fire!
- Power sockets and connectors on the hydraulic connections should be marked in order to exclude operating errors.
- In the case of injury, contact a doctor immediately!
- Secure and lock control units on the machine if not in use!
- Replace hydraulic hoses at the latest after six years, see *Maintenance overview*.

Pressure accumulator

The pressure accumulators installed in the hydraulic system are always under pressure. Always depressurize the pressure accumulator before starting work on the hydraulics.

- Do not open or work (welding, drilling) on pressure accumulators. Even when empty, the tanks are still preloaded by gas pressure.

The hydraulics must be depressurized before maintenance!

Electrics

Always disconnect the battery (negative pole) before starting work on the electric system!

- Use only the specified fuses. The use of fuses with too high a rating destroys the electric system and represents a fire hazard!
- Make sure that the battery is correctly connected. Connect the positive pole first and the negative pole after! When disconnecting disconnect the negative pole first and the positive pole after!
- Always lock the battery with the covering provided.
- Avoid sparking and naked flames in the vicinity of the battery.
- The machine can be equipped with electronic components and parts, the function of which may be affected by the transmission of electromagnetic waves from other equipment.

In case of a subsequent installation of electric appliances and/or components on the machine, with connection to the on-board power supply, the user is responsible for checking whether this installation will cause faults in the vehicle electronics or in other components.

Make sure that the subsequently installed electric and electronic components are in accordance with the valid issue of the EMC directive 2014/30/EC and are identified with the CE-sign.

Battery

- Maintenance work on the battery requires appropriate knowledge and proper tools!
- Keep open fire, burning matches and sparks away from the battery!
- Never check the charge level of the battery by connecting both poles to a metal object. Use a Voltmeter.
- Do not recharge a frozen battery, danger of explosion! Heat the battery up to at least 16 °C beforehand.
- Battery acid can cause severe injury by cauterization of skin and eyes. Wear protective clothing.

Cooling system

The heated up cooling system is under pressure! You should therefore only remove the radiator cap after the engine has been shut down and cooled down.

Brake system

The machine is equipped with a pneumatic or hydraulic service brake system.

- Always check the condition of the brake system before each travel.
- Immediately stop the machine in case of brake system malfunctions. Have the malfunction remedied immediately!
- Always release the parking brake before starting to drive.
- Secure the machine against rolling away and apply the parking brake.
- The brake system must be checked at regular intervals!
- Before starting work in the brake system park the machine safely and secure it against accidental lowering and rolling away (wheel chocks)!
- Be extremely careful when performing welding, torch cutting and drilling work near brake lines!
- After any setup and maintenance work on the brake system you must generally carry out a brake test!

Adjustments and repair work on the brake system must only be carried out in a professional workshop or by an operator, who has been specially trained by HORSCH for this purpose.

Overhead lines

When unfolding or folding the folding boom, the machine may reach the height of overhead lines. Possible voltage flashover to the machine may cause fatal electric shock or fire.

- Keep a safe distance to electric high voltage power lines when unfolding or folding the folding boom.
- Never unfold or fold the folding boom in the vicinity of power poles and power lines.
- With the folding boom unfolded and raised, keep a sufficient distance to electric high voltage power lines.
- Never leave or access the machine under overhead lines to avoid possible risks of electric shock or voltage flashover.
- When operating the sprayer under high voltage power lines disable the BoomControl and operate the slope compensation manually.

What to do in case of voltage flashover

Voltage flashover generates high electric voltages on the outside of the machine. This results in extreme voltage differences at the ground around the machine. Wide strides, laying on the ground or supporting yourself with your hands on the ground can cause life-threatening electric currents (pace voltage).

- Do not leave the cabin.
- Do not touch any metal objects.
- Do not create a conductive connection to ground.
- Warn persons: DO NOT come near the machine. Electric voltages at the ground can cause severe electric shock.
- Wait for professional rescuers. The overhead power line needs to be switched off.

If persons need to leave the cabin despite the voltage flashover, e.g. in case of a potential life-threatening risk of fire:

- Jump away from the machine. Ensure a safe stand when jumping. Do not touch the outside of the machine.
- Move away from the machine with short stepping strides.

Technical limiting values

If the technical limiting values of the machine are not complied with, the machine may sustain damage. This can lead to accidents with severe or even fatal physical injuries.

The following technical limiting values are of particular importance for safety:

- Permissible total weight
- maximum axle loads
- Top speed

See chapter *Technical data*, type plate and type approval.

Use in the field



No passengers are allowed to ride on the machine!

- Observe the national legislation and regulations on crop protection!
- The personal protective outfit stipulated in the safety data sheets of the crop protection agent manufacturers must be carried along and worn during work.
- Check the area immediately around the machine (for children!) before driving off and commissioning the machine. Ensure sufficient visibility.
- Check the condition of the folding boom and their mounting before use.
- Ensure sufficient stability of the machine in case of longitudinal or transverse inclination when working in uneven terrain. Observe the limit values of the machine.
- Do not remove any of the mandatory and supplied protective devices.
- Stay clear of the operating range of hydraulically operated parts.
- Use accessing aids and steps only at standstill.
- At the headland reduce the travel speed and disable spraying.
- Excessive, jerky steering movements at the beginning and the end of a curve will put extreme loads on the folding boom.
- The spraying agent may be blown away if the droplets are fine and the wind is strong. This may cause damage to people and nature!
- If the soil is very dry, the applied chemical can be blown away together with dust and cause damage. Ensure sufficient moisture of the soil!
- Ensure that the category of the tractor cabin is approved for the respective crop protection agent used.
- Always ensure a sufficient water supply in the machine to be able to wash off crop protection agent in events of emergency.
- Data concerning the preparations currently used must always be kept in the transport and safety container so that these are available for rescue services in case of accidents.
- Automatic steering must only be used for the purpose it is intended for. It must only be used in the field, away from public or semi-public roads, away from yard areas as well as far away from possibly endangered persons.

Changing equipment / wear items

- Only pulling tools may be attached that meet the technical requirements according to these operating instructions.
HORSCH does not assume any liability for damages resulting from the attachment of non-fitting pulling tools as well as incorrect mounting.
- For machines with valid type approval only pulling tools may be attached that are covered by the type approval. Attaching pulling tools not covered by the type approval will void the registration.
- Secure the machine against unintended rolling away!
- Secure raised frame parts you have to work under with suitable supports!
- Caution! Risk of injury caused by projecting parts (e.g. folding boom parts)!
- Assume ergonomic working postures with any assembly work.

Do not step on moving or other rotating parts to climb onto the machine. You could fall and be seriously injured.

Crop protection agents and liquid fertiliser

Improper handling of crop protection agents and liquid fertiliser may cause poisoning and death.

- Follow the specifications and instructions in the safety data sheet of the crop protection agent manufacturer. If necessary, ask the dealer for the safety data sheet or safety notes.
- Determine and provide the personal protective outfit as specified by the manufacturer of the crop protection agent.
- At the time the machine is manufactured the manufacturer is aware of only a few approved crop protection agents, which could have a damaging effect on the materials used in the self-propelled crop protection sprayer.
- Store all relevant information about the crop protection agents used (safety data sheets, instructions for use, etc.) in the document compartment.
- The water quality (the water hardness and mineral content in particular) influences the property of some fertilisers and crop protection agents. Precipitation and deflocculation can cause deposits in filters and nozzles.
Example: Extremely hard water reacts with sulphate-bearing fertiliser to form calcium sulphate (gypsum) and causes white deposits in the filters.
Pay attention to the conditions of use and the combination possibilities given by the corresponding manufacturers to avoid such problems!
- Observe the data on compatibility of crop protection agents with materials of the self-propelled crop protection sprayer!
- Do not spray any crop protection agents that have a tendency to agglutination or solidification!
- Wear the personal protective outfit stipulated in the safety data sheet when handling crop protection agents!
- Do not eat, drink or smoke while handling crop protection agents!
- Keep crop protection equipment and crop protection agents out of the reach of children!
- Always ensure a sufficient water supply in the machine to be able to wash off crop protection agent in events of emergency.
- In case of physical contact with crop protection agents you may need to consult a physician.
- Thoroughly clean hands and face after the end of work.
- Extended exposure time of crop protection agents may cause damages to plastic components of the self-propelled crop protection sprayer. Follow the notes of the crop protection agent manufacturers.
- The application notes of the crop protection agent manufacturers must be observed when mixing different crop protection agents.

Environmental protection

Crop protection agents and liquid fertiliser as well as operating materials such as hydraulic oil, lubricants, etc. can damage the environment and the health of persons.

- Do not allow operating materials to drain out into the environment.
- Pick up drained operating materials with absorbent material or sand, fill it into a leak tight container and dispose of in accordance with statutory regulations.
- Do not fill self-propelled crop protection sprayers with water from public bodies of water.
- Filling in water protection zones is not permitted, depending on the crop protection agent used! Inquire with the "Water board" to be on the safe side!
- Observe the national and country-specific regulations and standards (e.g. water protection areas).

Retrofitting and conversions

Structural changes not approved by HORSCH may affect the functionality and operational safety of the machine and will void any warranty claim.

HORSCH is not liable for damages to life and limb as well as property damages resulting from unapproved retrofitting and conversions.

- Do not make any structural changes or extensions that have not been approved by HORSCH.
- Modifications and extensions approved by HORSCH are only to be performed at an authorized workshop or by an operator who has been trained by HORSCH for this purpose.
- Comply with country-specific instructions for weights, weight distribution and dimensions.

For equipment influencing the weight or weight distribution the regulations concerning towing facility, axle loads and total weight must be checked and complied with.

In case of changes concerning data mentioned on the type plate, a new type plate with updated data must be attached.

In case of changes which concern the data in the type approval, this type approval needs to be renewed.

Care and maintenance

Inappropriate care and maintenance puts the operational safety of the machine at risk. This can lead to accidents with severe or even fatal physical injuries.



- **Danger of poisoning - Do not climb into the spraying mixture container!**

- Conform to prescribed schedules for repetitive tests or inspections.
- Service the machine according to the maintenance plan, see chapter *Care and maintenance*.
- Only perform the work described in these operating instructions.
- Cleaning, lubrication or adjustment work on the machine must only be carried out with the drive and engine shut down, the parking brake applied and the ignition key pulled off!
- After switching of the drives there is still a danger caused by the coasting down gyrating mass! Do not step close to the machine during this phase. Work on the machine may only be started once the machine is fully at standstill.
- Pay attention to the occurrence of mechanical, hydraulic, pneumatic and electric/electronic residual energies on the machine.

- Before starting maintenance and service work park the machine on level and firm ground and secure it against rolling away. Clean the self-propelled crop protection sprayer, especially the parts which are contaminated by spraying mixture. Wear the protective outfit stipulated in the safety data sheet when cleaning!
- Lock hydraulically operated parts and depressurise the hydraulic system.
- Prior to working on the electrical system, disconnect it from the electric current supply.
- When performing welding work on the machine, disconnect the cables from computers and other electronic components. The ground connection must be as close as possible to the welding point.
- Secure all operating media like compressed air and hydraulics against unintended commissioning.
- Secure the raised machine or raised machine parts against accidental lowering before starting maintenance, repair and cleaning work!
- Repair work inside the spraying mixture container must only be performed after thorough cleaning and wearing protective outfit with a respirator. This work must be monitored by a second person outside the spraying mixture container for safety reasons! Ensure sufficient ventilation of the spraying mixture container! Only approved qualified personnel may enter the spraying mixture container!
- Before cleaning the machine with high pressure cleaner cover all openings, which should stay clear of water, steam or cleaning agents for reasons of safety or function. Do not aim the water jet directly on electric or electronic components and bearings.
- When cleaning with high pressure cleaning equipment or steam jets keep a distance of at least 60 in. (150 cm) to machine components.
- After cleaning, check all hydraulic lines for leaks and loose connections.
- Check for chafing and signs of damage. Remedy any faults immediately!
- Screw connections loosened for the purpose of care and maintenance work must be retighten after work is completed.
- Dispose of oils, greases and filters according to regulations!
- If protective features are subjected to wear, they must be inspected at regular intervals and replaced in due time
- Do not clean new machines with a steam jet of a high pressure cleaner. The paint takes approx. 3 months to cure and could be damaged before this time.
- Pay attention to the following when repairing self-propelled crop protection sprayers which have been used with ammonium nitrate - carbonyl diamide solution:
residues of ammonium nitrate - carbonyl diamide solution may form salt on or inside the spraying mixture container through the evaporation of water. This results in pure ammonium nitrate and carbonyl diamide. In its pure form, ammonium nitrate in connection with organic matter, such as carbonyl diamide, becomes explosive, if critical temperatures (caused by e.g. welding work, grinding) are reached during repair work.
By thoroughly cleaning the spraying mixture container or the parts to be repaired with water, this risk can be eliminated, because the salt of the ammonium nitrate - carbonyl diamide solution is water-soluble.
- **All other maintenance and repair tasks, which are not described in the operating instructions, must only be carried out by an authorized professional workshop or by an operator who has been trained by HORSCH for this purpose.**


Danger zone

No person may be present in the danger zone while the machine is in operation!


The danger zone around the machine poses the following hazards:

- Accidental operation of the hydraulics can trigger dangerous movements of the machine.
- With the drive still running, machine parts may rotate or swing out.
- Hydraulically raised machine parts can lower slowly and unnoticed.
- By accidental rolling or driving of the machine.


Danger zone during operation of the machine:




Danger zone when folding the folding boom:




Danger zone when lifting/lowering the folding boom:



Danger zone with active BoomControl:



Danger zone with steering/all-wheel steering:



Failing to pay attention to the danger zone can result in severe or even fatal physical injuries.

- Do not stand under lifted loads. Lower such loads to the ground first.
- Before any machine movements ask persons to leave the danger zone of the machine.
- Before any work in the danger zone of the machine!

This also applies to temporary inspection work.

Many serious accidents happen because of carelessness and running machines!

- Pay attention to the information in all operating instructions.

Use on hillside locations

WARNING

Risk of toppling over when driving on slopes. Note the specifications regarding the maximum permissible grade in regard to the contour line of the slope! The operator must be buckled up! High speeds, sudden changes of direction as well as fast and tight cornering may increase the risk of toppling over.

The centre of gravity of the machine moves up when the tank is filled and the folding boom lifted.

NOTE

The following specifications refer to all machines of the variants Leeb 5.300 / 6.300 VL with permissible tires and adjusted air pressure.

Stability*

| Track width wider than 102 in. (2.600 mm) | | |
|---|-----------------------------------|----------------------|
| • Contour line | Without height adjustment or down | Height adjustment up |
| Travel direction to the left | 25% | 20% |
| Travel direction to the right | 25% | 20% |
| • Line of fall | | |
| uphill | 25% | 25% |
| downhill | 25% | 25% |

*Independent of folding boom height and barrel filling level

The values specified may be reduced further through certain influences. This includes:

➤ Travel mode not adjusted, e.g.:

- abrupt driving manoeuvres
- abrupt steering manoeuvres
- wobbly movements
- excessive speed
- cornering
- dynamic impact

➤ Poor ground, e.g.:

- deep tram lines
- uneven tram lines
- slippery ground
- non-load bearing ground

➤ Narrower track widths









➤ Air pressure in tires too low

➤ Undercarriage height

Safety stickers

Safety stickers on the machine warn of hazards at dangerous points and are an important part of the safety equipment of the machine. Missing safety stickers increase the risk of severe or even fatal injuries.

- Clean soiled safety stickers.
- Damaged or illegible safety stickers must be replaced immediately.
- Affix the specified safety stickers on spare parts.

| | |
|---|--|
| <p>No passengers are allowed to ride on the machine!</p>  <p>04001455</p> | <p>Never reach into areas where there is a risk of crushing as long as parts could still be moving!</p>  <p>04001683</p> |
| <p>Before commissioning the machine the operating instructions must be read and followed!</p>  <p>04002983</p> | <p>Stay clear of the operating range of foldable machine parts!</p>  <p>04002625</p> |
| <p>Caution for fluids spraying out under high pressure, follow the notes in the operating instructions!</p>  <p>04001682</p> | <p>The pressure accumulator is charged with gas or oil pressure. Dismantle and repair only in strict compliance with the instructions in the technical manual.</p>  <p>04001686</p> |
| <p>Do not open or remove protective features while the engine is running!</p>  <p>04001457</p> | <p>Shut down the engine and pull off the key before starting maintenance and repair work.</p>  <p>04002983</p> |

Danger of poisoning - Never climb into the spraying mixture container.



04001456

Keep sufficient distance to hot surfaces.



04001453

Do not remain inside the range of a lifted but unsecured load.



04002626

Keep sufficient distance to electric high voltage power lines.



04002983

Secure the machine with wheel chocks before uncoupling or parking.



04002983

Keep sufficient safety distance to the slewing range of the machine.



04001454

Before commissioning the machine the operating instructions must be read and followed!



04003747

Avoid any contact with hazardous substances!
Wear protective clothing!



04003745

Danger of poisoning - no drinking water!



04002623

Fill the hand washing tank only with clear water!



04002628

The maximum operating pressure of the hydraulic system is 2900 psi (200 bar).




04002983

Do not exceed the max. flow rate of 264 US gal lqd (1000 l/min) when directly filling the spraying mixture container!




04004094

Switch-over ball valve Inside/outside cleaning (only for machines with outside cleaning option)



60016560


Operate the battery main switch only 15 minutes after shutting off the diesel engine. Immediate shut-off only in emergency! Please also read *Engine Operation*.



04008125


Loading hook; hook the load suspension gear (chains, ropes etc.) into this loading hook during loading.





Safety stickers with the addition "2x" can be found on either side of the machine.

Position of safety stickers (depending on equipment)



Safety stickers with the addition "2x" can be found on either side of the machine.

Commissioning

NOTE

These work activities may be carried out only by persons trained by HORSCH for this purpose.

WARNING

Increased danger of accidents during commissioning.

- Pay attention to the notes from the safety chapter!

Delivery

The machine is normally delivered completely assembled on a low loader.

If parts or assembly groups had to be disassembled for transport purposes, these will be assembled locally by our distributor or field technician.

Lifting and lashing points are identified by labels. When using other lifting points pay careful attention to the centre of gravity and the weight distribution. These points must, in any case, only be on the frame of the machine.


With all machines, the hydraulic functions are possible without additional installation.

Pneumatic level suspension

To minimise the transport height, the folding boom for the level suspension may have been unhooked when delivered.

NOTE

The folding boom must be attached in standard operation! Bolt down the folding boom as shown.



Folding boom level suspension hooked up

Transport

Depending on country-specific regulations and working width the machine can either drive on public roads or be transported on a trailer or low loader.

- The permissible dimensions and weights for transport must be complied with.
- On a trailer or low loader, the machine must be secured with load straps or other means.
- Attach lifting tackle only at the marked points.

Installation

Instruction of the operator and initial installation of the machine will be carried out by our service technicians or distributors.

Any prior use of the machine is prohibited.

The machine can only be released for operation after the instruction session conducted by our service technician / distributor and after the operating instructions have been read.

WARNING

Increased danger of accidents during installation and maintenance.

- Read these operating instructions and become acquainted with the machine before starting this work.

Depending on the scope of equipment

- Take the unattached delivered parts off the machine!
- Check all important screw connections!
- Lubricate all grease nipples!
- Check air pressure in tires.
- Check all hydraulic connections and hoses for correct fastening and function!
- Immediately rectify any occurring damage or have it corrected!

Adjusting the track width

2 equipment variants (mechanical or hydraulic) are available to adjust the track width.

Depending on the equipment and variant of the vehicle, the track width can be set between 102 in. to 175 in. (2.60 to 4.47 m).

Mechanical track width adjustment

- The track width can be set via sliding axles as desired. Refer to the section *Mechanical track width adjustment*.

Hydraulic track width adjustment (TrackControl)

- The desired track width can be set via the terminal.

Mechanical track width adjustment

WARNING


Increased risk of accident when adjusting the track width!

- Pay attention to the notes from the safety chapter!
 - Always adjust the track width only one axle at a time; never raise the complete machine.
 - Use suitable lifting equipment to raise the machine.
 - Perform only on a level and firm surface.
 - Secure the vehicle against rolling.
 - Lower the vehicle with hydraulic height adjustment, see chapter *Height adjustment*.
 - Drain the spraying mixture container and the fresh water tank.
-

Releasing the sliding axle

Always start with horizontal clamping (1) when releasing!

- Lift the machine on a level and paved surface with lifting equipment to allow the axle to be clamped with zero clearance.
- Open the hexagon nut.
- Open the grub screws by approx. 60°. The sequence of the screws is from the machine centre toward the outside.
- If necessary, loosen the grub screws further.
- Now perform the same procedure on the vertical clamping (2).
- Adjust the sliding axle until the desired track width is reached.




1 From the outside to the machine centre / vertical clamping

2 Horizontal clamping

Clamping of the sliding axle

- Lift the machine on a level and paved surface with lifting equipment to allow the axle to be clamped with zero clearance.
- Adjust the sliding axle until the desired track width is reached.
- Pre-stress the grub screws with 36.8 ft lbs (50 Nm) for horizontal clamping. Screw sequences from the outside toward the machine centre.
- Pre-stress the grub screws with 36.8 ft lbs (50 Nm) for vertical clamping; screw sequences from the outside toward the machine centre.
- Tighten the grub screws for vertical clamping to a final tightening torque of 73.6 ft lbs (100 Nm). Screw sequence from the outside toward the machine centre.
- Repeat the final tightening torque action with 73.6 ft lbs (100 Nm). Screw sequence from the outside toward the machine centre.
- Tighten the grub screws for horizontal clamping to a final tightening torque of 73.6 ft lbs (100 Nm). Screw sequence from the outside toward the machine centre.
- Repeat the final tightening torque action with 73.6 ft lbs (100 Nm). Screw sequence from the outside toward the machine centre.
- Tighten the hexagon nut with 133 ft lbs (180 Nm).
- Lower the vehicle and continue with the second axle as described.



1 Hexagon nut

2 Grub screw

3 No adjustment required



NOTE

Make sure during the adjustment that the sliding tube at the left and right is set to the same width. (The axle must be aligned centred to the machine.) If necessary, perform the settings on the terminal for machines with automatic steering. The machine must be raised during loosening and clamping to allow the axle to be clamped with zero clearance. Refer to the notes in the maintenance table when performing maintenance.

Height adjustment

3 equipment variants are available for height adjustment:

No height adjustment

- No adjustment possible

Mechanical height adjustment

- The undercarriage can be lifted by 16 in. (400 mm) via a spacer (rod) if desired. Refer to the section *Mechanical height adjustment*.

Hydraulic height adjustment (Clearence-Control)


- The desired height can be selected via the terminal.

Mechanical height adjustment


WARNING

Increased risk of accident during height adjustment!

- Pay attention to the notes from the safety chapter!
- Always adjust the height only one axle at a time; never raise the complete machine.
- Use suitable lifting equipment for raising
- Perform only on a level and firm surface.
- Secure the vehicle against rolling.
- Drain the spraying mixture container and the fresh water tank.



Wheel suspension mechanical height adjustment, left front view



Locking screw detail

Height adjustment up procedure:

- Drain the spraying mixture container and the fresh water tank.
- Park the machine on level and paved ground.
- Secure the machine against rolling away.
- Place suitable lifting equipment to a suitable spot and apply light pressure.
- Remove the three locking screws (1) and screw them in again after the height adjustment. Tightening torque: 47 ft lbs (64 Nm)
- Do not loosen the screws (2), otherwise, the height between lifting bridge and suspension sled must be adjusted again. Contact HORSCH Service in this case.
- Raise the lifting equipment.
- Use the supplied rods (3) to thread in new wedge-type lock washers (Art. No. 00371059) and screws (4) with washers) and tighten. Tightening torque 736 ft lbs (1000 Nm).
- Thread in the screws (5) with wedge-type lock washers in the same way and tighten. Tightening torque 221 ft lbs (300 Nm).

- Lower the vehicle and continue with the second axle as described.

NOTE


Wedge-type lock washers may be used only once! If necessary, perform the settings on the terminal for machines with automatic steering. Refer to the notes in the maintenance table when performing maintenance. Retighten the screws (1), (4) and (5) after 100 operating hours.

Height adjustment down procedure:

- Drain the spraying mixture container and the fresh water tank.
- Park the machine on level and paved ground.
- Secure the machine against rolling away.
- Place suitable lifting equipment to a suitable spot and apply light pressure.
- Remove the three locking screws (1).
- Do not loosen the screws (2), otherwise, the height between lifting bridge and suspension sled must be adjusted again. Contact HORSCH Service in this case.
- Raise the lifting equipment, remove the rod (3) with screws (4) and (5).
- Store rod (3) and screws (4) securely.
- Install screws (5) with new wedge-type lock washers. Tightening torque 221 ft lbs (300 Nm)
- Lower the lifting equipment.
- Screw in the three locking screws (1) to secure the joint. Tightening torque 47 ft lbs (64 Nm)
- Retighten the screws (1) and (5) after 100 operating hours.



Mechanical height adjustment lower position, right rear view



Mechanical height adjustment upper position, right rear view.

Initial commissioning of the service brake system

NOTE

Test braking must be performed in the beginning with the crop protection sprayer empty and loaded to test the brake characteristics of the self-propelled crop protection sprayer. Compliance with the permissible total weight must be ensured.

Assemble the wheels

WARNING

Use only approved tires as specified in the technical data.

The rims matching the tires must be suitable for the respective loads!

Technical Data Leeb 5.300 / 6.300 VL

(Emission Standard Stage 5 Variant)

NOTE

Payload = permissible total weight - basic weight

DANGER

Exceeding the permissible payload is prohibited. Danger of accident caused by unstable driving! Carefully determine the payload and thus the permissible filling of the machine. Not all filling media allow a complete filling of the machine.

| Machine type | 5.300 VL | 6.300 VL |
|--|--|--|
| Chassis | | |
| Curb weight lbs (kg) | 28.600 - 32.000 (13.000 - 14.500) | 28.600 - 32.000 (13.000 - 14.500) |
| max. perm. total weight on road lbs (kg) PowerGear / HighPowerGear | 40.000 / 44.000 (18.000/ 20.000) | 40.000 / 44.000 (18.000/ 20.000) |
| max. perm. total weight on field lbs (kg) depending on tires | 53.000 (24.000) | 53.000 (24.000) |
| max. total length in transport position in. (mm) | 460 (11.700) | 460 (11.700) |
| Transport width in. (mm) in trans- port position at track 102 - 137 in. (2.600 - 3.500 mm) | 120 (3.050) | 120 (3.050) |
| Transport width in. (mm) in trans- port position at track 118 - 161 in. (3.000 - 4100 mm) + 3 in. (100 mm) for large transmission | 135 (3.450) | 135 (3.450) |
| Transport height with lowered pneumatic suspension* in. (mm) | approx. 152 (approx. 3900) | approx. 152 (approx. 3900) |
| Wheel base in. (mm) | 169 (4.300) | 169 (4.300) |
| Ground clearance* in. (mm) | 63 - optional 70 (1.600 - optional 2.000) | 63 - optional 70 (1.600 - optional 2.000) |

| Machine type | 5.300 VL | 6.300 VL |
|--|---|----------|
| Engine | | |
| FPT (Diesel) | N67 | |
| Power (kW / HP) | 230 / 310 | |
| Number of cylinders / cooling | 6 / water / turbo with intercooler | |
| Displacement ci. (cm ³) | 408 (6.700) | |
| Nominal speed (rpm) | 2000 (2000) | |
| Torque ft. lbs. (Nm) at rotary speed (rpm) | 855 / 1500 (1160/ 1500) | |
| Control | Electric SAE J1939 | |
| Tank volume gal lqd (L) | approx. 118 (approx. 450) | |
| Gearbox | | |
| Gearbox type | Wheel hub gearbox | |
| Work areas | Field / road | |
| Transmission | hydrostatic infinite | |
| Speed mph (km/h) | Field: 0 - 15 (0 - 25) folding boom folded in 0 - 20 (0 - 32) folding boom unfolded Road: 0 - 25 (0 - 40) optional 0 - 31 (0 - 50) | |
| Drive | permanent all-wheel drive | |
| | from 18 mph (30 km/h) on the road only via front axle | |
| Undercarriage / axles | | |
| Front axle / rear axle | Independent suspension on sliding frame | |
| Suspension | Pneumatic suspension | |
| Steering | | |
| Front axle | hydraulic | |
| Rear axle | hydraulic-electric automatic centring and interlocking for road travel | |
| Steering modes | only front axle steering / all-wheel steering auto- matically centring / manual steering / slope mode | |
| Brake system | | |
| Service brake front axle/rear axle | High performance brake + lamella | |
| Parking brake | Wet disc spring accumulator on all 4 wheels | |

| Machine type | 5.300 VL | 6.300 VL |
|--|--|---------------|
| Hydraulic system | | |
| 1 Main pump (spraying pump/fan) | quantity-controlled variable displacement pump | |
| 2 Main pump (working hydraulics) | quantity-controlled variable displacement pump | |
| Output gal lqd/min (L/min) | 84 (320) | |
| Working pressure psi (bar) | 2.900 (200) | |
| Hydraulic tank gal lqd (L) | approx. 26 (100) | |
| Vehicle electronics | | |
| Operating voltage | 12 V | |
| Battery | 12 V (180 Ah) | |
| Generator | 12 V / 200 A | |
| Starter | 12 V / 4 kW | |
| Design | | |
| min./max. Sections (pieces) | 6 / 42 | |
| Working height in. (mm)* | 11 - 9 (300 - 250) | |
| Centrifugal pump capacity gal lqd/min (litres/min) at 0 psi (bar) and suction height = pump height | 264 (1000) | |
| max. working pressure psi (bar) | 116 (8) | |
| Working speed mph (km/h) | 2.5 - 20 (4 - 32) | |
| Tank | | |
| Rated volume spraying mixture container gal lqd (litres) | 1.300 (5.000) | 1.600 (6.000) |
| Actual volume spraying mixture container gal lqd (litre) | 1.430 (5.400) | 1.700 (6.400) |
| Fresh water tank, gal lqd (litres) | 200 (750) | |
| Hand washing tank gal lqd (litres) | 4 (15) | |
| Illuviation valve, plastic gal lqd (litres) | 9 (35) | |
| Illuviation valve, stainless steel (option) (litres) | 14 (52) | |
| Spraying boom | | |
| Working widths | 17 / 30 m 5-piece | |
| | (17) / 36 m 5-piece | |
| | 58 / 100 ft 5-piece | |
| | (58) / 120 ft 5-piece | |

| Machine type | 5.300 VL | 6.300 VL |
|---|---|----------|
| Technical residual quantity incl. pump*** | | |
| • Level | On request | |
| • Contour line | | |
| 15% travel direction to the left | On request | |
| 15% travel direction to the right | On request | |
| • Line of fall | | |
| 15% uphill | On request | |
| 15% downhill | On request | |
| Central control | electric, pneumatic single nozzle control | |
| Spraying pressure adjustment | Electric | |
| Spraying pressure - adjustment range (bar) | 0.07-0.55 (1 - 8) | |
| Spraying pressure gauge | digital | |
| Pressure filter | 80 (50/100) meshes | |
| Agitator | adjustable / interruptible to 4 stages | |
| Placing quantity control | Speed dependent via job computer | |
| Jet height* at 62 in. (1.600 mm) ground clearance in. (mm) | 11 - 110 (300 - 2800) | |
| Jet height* at 78 in. (2.000 mm) ground clearance in. (mm) | 31 - 125 (800 - 3200) | |
| All dimensions and weights depend on boom width, tires and equipment. * Data with tires VF 520/85 R 46 ** Driving is possible on these slopes, but restrictions must be expected regarding technical residue, placement of the residue, emptying of the tank, indication of the filling level, placement accuracy *** depending on folding boom variant, incl. use of air function | | |

- NOTE:**
- Deviations due to technical further development reserved.
 - The dimensions may vary depending on the machine equipment and design of the folding boom.
 - The weight of the machine depends on the equipment.
 - The permissible transport heights and transport width for road traffic may differ from country to country. Comply with the national registration regulations.

Type plate

The type plate with the CE marking is located on the frame of the right machine side. Refer to the correct tape plate according to the series status!

Data on the type plate:

The diagram shows a HORSCH LEEB type plate with the following fields and labels:

- Approval number**: Points to the top left field.
- Type designation**: Points to the field below the approval number.
- Model designation**: Points to the field below the type designation.
- Empty weight**: Points to the field below the model designation.
- Year of construction**: Points to the field below the empty weight.
- Chassis number**: Points to the field below the year of construction.
- Total weight**: Points to the field below the chassis number.
- permissible axle load, front axle**: Points to the field A-1.
- permissible axle load, rear axle**: Points to the field A-2.
- permissible axle load, third axle**: Points to the field A-3.
- permissible axle loads***: Points to the table below the permissible axle loads.
- Engine power**: Points to the field P.
- System pressure, sprayer**: Points to the field p_{max} .
- Volume, spraying mixture container**: Points to the field V1.
- Volume, fresh water tank**: Points to the field V2.

The type plate includes the HORSCH LEEB logo, the company name Application Systems GmbH, the address Kleeartenstraße 5, D-94455 Landau a. d. Isar, the website www.horsch.com, and the CE marking. The table below the permissible axle loads is as follows:

| | T-1 | T-2 | T-3 |
|-----|-----|-----|-----|
| B-1 | | | |
| B-2 | | | |
| B-3 | | | |
| B-4 | | | |


*Permissible trailed loads (for machines with drawbar eye)

| | | | |
|-----|------------------------|-----|-------------------------------|
| B-1 | unbraked | T-1 | Drawbar-trailed vehicle |
| B-2 | inertia braking system | T-2 | rigid drawbar-trailed vehicle |
| B-3 | hydraulically braked | T-3 | central axle-trailed vehicle |
| B-4 | pneumatically braked | | |

Dimensions

Data in mm in. (mm)

Leeb 5.300 / 6.300 VL



- NOTE:**
- Deviations due to technical further development reserved.
 - The dimensions may vary depending on the machine equipment and design of the folding boom.
 - The weight of the machine depends on the equipment.
 - The permissible transport heights and transport width for road traffic may differ from country to country. Comply with the national registration regulations.

Weight and tires

The permissible total weight of the machine depends on the

- permissible axle load
- permissible tire load bearing capacity per wheel

The permissible total weight is the sum of

- the **smaller** value from
 - permissible axle load
 - tire load bearing capacity of both wheels

The values for determining the permissible total weight can be taken from the following tables.

| Permissible axle load of the fixed axle load | | | | |
|--|----------------------------|----------------------------|----------------------------|----------------------------|
| | PowerGear | | HighPowerGear | |
| Axle load lbs (kg) at 15.5 mph (25 km/h) | 19.841 (9000) | 26.455 (12.000) | 22.046 (10.000) | 26.455 (12.000) |
| Axle load lbs (kg) at 24 / 31 mph (40 / 50 km/h) | 19.841 (9000) | 26.455 (12.000) | 22.046 (10.000) | 26.455 (12.000) |
| Flange dimension in. (mm) | 82 / 88 (2.100 / 2.250) | 82 / 88 (2.100 / 2.250) | 82 / 88 (2.100 / 2.250) | 82 / 88 (2.100 / 2.250) |

| Track width with different wheel sets | |
|---|---|
| Track width | Wheel set |
| Track width 102 - 138 in. (2.600 mm - 3.500 mm) or 118 - 161 in. (3.000 mm - 4.100 mm) | Wheel set 380/90R46 Ceat Farmax RC, 165B |
| | Wheel set 380/105R50 Alliance 350 |
| | Wheel set IF 380/105R54 Alliance Agriflex 354 |
| | Wheel set VF 380/105R54 Mitas HC 2000 |
| | Wheel set VF 420/95R50 Michelin SprayBib |
| Track width 105 - 140 in. (2.670 mm - 3.570) mm or 120 - 164 in. (3.070 mm - 4.170 mm) | Wheel set VF 480/80R50 Alliance Agriflex 354+ |
| | Wheel set VF 480/95R50 Alliance Agriflex 354+ |
| Track width 106 - 141 in. (2.700 mm - 3.600 mm) or 122 - 165 in. (3.100 mm - 4.200 mm) | Wheel set VF 520/85R46 Alliance Agriflex 354+ |
| Track width 110 - 145 in. (2.800 mm - 3.700) mm or 125 - 169 in. (3.200 mm - 4.300 mm) | Wheel set 620/70R46 BKT Agrimax RT 765 |
| | Wheel set 620/70R46 Alliance Multistar 376 |
| Track width 116 - 152 in. (2.970 mm - 3.870) mm or 132 - 175 in. (3.370 mm - 4.470 mm) | Wheel set VF 750/70R44 Michelin AxioBib 2 |

With decreasing tire pressure, the tire load bearing capacity will also decrease!
In this case pay attention to the reduced payload of the machine!

| Load bearing capacity per wheel | | | | | | | | |
|---------------------------------|-----------------------------|-------------------|---|-----------------------------------|---|-----------------------------------|---|-----------------------------------|
| | Tires | Load index | 16 mph (25 km/h) | | 25 mph (40 km/h) | | 31 mph (50 km/h) | |
| | | | Permissible load bearing capacity lbs (kg) | at air pres- sure psi (bar) | permissible load bearing capacity lbs (kg) | at air pres- sure psi (bar) | permissible load bearing capacity lbs (kg) | at air pres- sure psi (bar) |
| 1 | Ceat Farmax RC 380/90R46 | 165 A8 / 165 B | 11.288 (5.120) | 51 (3.5) | 10075 (4.570) | 51 (3.5) | 9.413 (4.270) | 51 (3.5) |
| | | | 12.214 (5.540) | 58 (4) | 10891 (4.940) | 58 (4) | 10.185 (4.620) | 58 (4) |
| | | | 12.941 (5.870) | 64 (4.4) | 11530 (5.230) | 64 (4.4) | 10.781 (4.890) | 64 (4.4) |
| | | | 13.625 (6.180) | 70 (4.8) | 12147 (5.510) | 70 (4.8) | 11.354 (5.150) | 70 (4.8) |

| Load bearing capacity per wheel | | | | | | | | |
|---------------------------------|--------------------------------------|---------------|--|---------------------------|--|---------------------------|--|---------------------------|
| | Tires | Load index | 16 mph (25 km/h) | | 25 mph (40 km/h) | | 31 mph (50 km/h) | |
| | | | Permissible load bearing capacity lbs (kg) | at air pressure psi (bar) | permissible load bearing capacity lbs (kg) | at air pressure psi (bar) | permissible load bearing capacity lbs (kg) | at air pressure psi (bar) |
| 2 | Alliance 350 380/105 R50" | 168D / 171 A8 | 6.834 (3.100) | 17 (1.2) | 6.327 (2.870) | 17 (1.2) | 6.063 (2.750) | 17 (1.2) |
| | | | 9.215 (4.180) | 29 (2) | 8532 (3.870) | 29 (2) | 8.179 (3.710) | 29 (2) |
| | | | 11244 (5.100) | 41 (2.8) | 10.384 (4.710) | 41 (2.8) | 9.965 (4.520) | 41 (2.8) |
| | | | 13.007 (5.900) | 52 (3.6) | 12.015 (5.450) | 52 (3.6) | 11.530 (5.230) | 52 (3.6) |
| 3 | BKT Agrimax Spargo VF 380/105R50 | 179 D | 11.453 (5.195) | 32 (2.2) | 11.453 (5.195) | 32 (2.2) | 11.453 (5.195) | 32 (2.2) |
| | | | 12.644 (5.735) | 38 (2.6) | 12.644 (5.735) | 38 (2.6) | 12.644 (5.735) | 38 (2.6) |
| | | | 14.352 (6.510) | 46 (3.2) | 14.352 (6.510) | 46 (3.2) | 14.352 (6.510) | 46 (3.2) |
| | | | 15.212 (6.900) | 52 (3.6) | 15.212 (6.900) | 52 (3.6) | 15.212 (6.900) | 52 (3.6) |
| 4 | Mitas HC 2000 VF 380/105R54 | 168 B | 9.171 (4.160) | 17 (1.2) | 8.819 (4.000) | 17 (1.2) | 8.819 (4.000) | 17 (1.2) |
| | | | 10.891 (4.940) | 23 (1.6) | 10.472 (4.750) | 23 (1.6) | 10.472 (4.750) | 23 (1.6) |
| | | | 12.147 (5.510) | 29 (2.0) | 11.685 (5.300) | 29 (2.0) | 11.685 (5.300) | 29 (2.0) |
| | | | 12.842 (5.825) | 35 (2.4) | 12.346 (5.600) | 35 (2.4) | 12.346 (5.600) | 35 (2.4) |
| 5 | Michelin SprayBib VF 420/95R50 | 177 D | 11.354 (5.150) | 26 (1.8) | 11.354 (5.150) | 26 (1.8) | 11.354 (5.150) | 26 (1.8) |
| | | | 12.787 (5.800) | 35 (2.4) | 12.787 (5.800) | 35 (2.4) | 12.787 (5.800) | 35 (2.4) |
| | | | 14.606 (6.625) | 44 (3.0) | 14.606 (6.625) | 44 (3.0) | 14.606 (6.625) | 44 (3.0) |
| | | | 16.094 (7.300) | 52 (3.6) | 16.094 (7.300) | 52 (3.6) | 16.094 (7.300) | 52 (3.6) |
| 6 | Alliance Ag-riflex 354+ VF 480/80R50 | 171 D | 7.386 (3.350) | 12 (0.8) | 7.386 (3.350) | 12 (0.8) | 7.386 (3.350) | 12 (0.8) |
| | | | 9.370 (4.250) | 17 (1.2) | 9.370 (4.250) | 17 (1.2) | 9.370 (4.250) | 17 (1.2) |
| | | | 12.015 (5.450) | 26 (1.8) | 12.015 (5.450) | 26 (1.8) | 12.015 (5.450) | 26 (1.8) |
| | | | 13.558 (6.150) | 35 (2.4) | 13.558 (6.150) | 35 (2.4) | 13.558 (6.150) | 35 (2.4) |
| 7 | Alliance Ag-riflex 354+ VF 480/95R50 | 176 D | 8.543 (3.875) | 12 (0.8) | 8.543 (3.875) | 12 (0.8) | 8.543 (3.875) | 12 (0.8) |
| | | | 11.023 (5.000) | 17 (1.2) | 11.023 (5.000) | 17 (1.2) | 11.023 (5.000) | 17 (1.2) |
| | | | 13.228 (6.000) | 23 (1.6) | 13.228 (6.000) | 23 (1.6) | 13.228 (6.000) | 23 (1.6) |
| | | | 15.212 (6.900) | 32 (2.2) | 15.212 (6.900) | 32 (2.2) | 15.212 (6.900) | 32 (2.2) |

| Load bearing capacity per wheel | | | | | | | | |
|---------------------------------|--------------------------------------|----------------|--|---------------------------|--|---------------------------|--|---------------------------|
| | Tires | Load index | 16 mph (25 km/h) | | 25 mph (40 km/h) | | 31 mph (50 km/h) | |
| | | | Permissible load bearing capacity lbs (kg) | at air pressure psi (bar) | permissible load bearing capacity lbs (kg) | at air pressure psi (bar) | permissible load bearing capacity lbs (kg) | at air pressure psi (bar) |
| 8 | Alliance Agri-flex 354+ VF 520/85R46 | 170 D | 9.645 (4.375) | 15 (1.0) | 9.645 (4.375) | 15 (1.0) | 9.645 (4.375) | 15 (1.0) |
| | | | 10.748 (4.875) | 17 (1.2) | 10.748 (4.875) | 17 (1.2) | 10.748 (4.875) | 17 (1.2) |
| | | | 12.015 (5.450) | 20 (1.4) | 12.015 (5.450) | 20 (1.4) | 12.015 (5.450) | 20 (1.4) |
| | | | 13.228 (6.000) | 23 (1.6) | 13.228 (6.000) | 23 (1.6) | 13.228 (6.000) | 23 (1.6) |
| 9 | BKT Agri-max RT 765 620/70R46 | 162 D | 8.796 (3.990) | 15 (1.0) | 8.378 (3.800) | 15 (1.0) | 8.036 (3.645) | 15 (1.0) |
| | | | 9.888 (4.485) | 17 (1.2) | 9.414 (4.270) | 17 (1.2) | 9.028 (4.095) | 17 (1.2) |
| | | | 10.968 (4.975) | 20 (1.4) | 10.450 (4.740) | 20 (1.4) | 10.020 (4.545) | 20 (1.4) |
| | | | 12.048 (5.465) | 23 (1.6) | 11.475 (5.205) | 23 (1.6) | 11.001 (4.990) | 23 (1.6) |
| 10 | Alliance Multistar 376 620/70R46 | 162 A8 / 159 D | 8.708 (3.950) | 15 (1.0) | 8.047 (3.650) | 15 (1.0) | 7.716 (3.500) | 15 (1.0) |
| | | | 9.656 (4.380) | 17 (1.2) | 8.929 (4.050) | 17 (1.2) | 8.576 (3.890) | 17 (1.2) |
| | | | 10.582 (4.800) | 20 (1.4) | 9.767 (4.430) | 20 (1.4) | 9.370 (4.250) | 20 (1.4) |
| | | | 11.420 (5.180) | 23 (1.6) | 10.472 (4.750) | 23 (1.6) | 10.119 (4.590) | 23 (1.6) |
| 11 | Michelin AxioBib 2 VF 750/70R44 | 186 D / 183 E | 12.445 (5.645) | 12 (0.8) | 12.203 (5.535) | 12 (0.8) | 12.203 (5.535) | 12 (0.8) |
| | | | 14.253 (6.465) | 15 (1.0) | 13.977 (6.340) | 15 (1.0) | 13.977 (6.340) | 15 (1.0) |
| | | | 16.061 (7.285) | 17 (1.2) | 15.752 (7.145) | 17 (1.2) | 15.752 (7.145) | 17 (1.2) |
| | | | 17.868 (8.105) | 20 (1.4) | 17.516 (7.945) | 20 (1.4) | 17.516 (7.945) | 20 (1.4) |

NOTE

The specifications reflect the current status at the date of print of the operating instructions. Contact the respective tire manufacturer for more information.

NOTE


Die possible maximum speed depends on the registration of the vehicle!

WARNING

Never choose an air pressure lower than the one mentioned in the table above. Risk of accident! The stability of the vehicle is no longer ensured.

Design

Overview



- 1 Driver's cabin
- 2 Swivelling access ladder
- 3 Lighting
- 4 Working headlights
- 5 Diesel engine
- 6 Fuel tank (right side of machine)
- 7 Hydraulic oil tank
- 8 Maintenance access
- 9 Wheel gear (right and left machine side)
- 10 Steering
- 11 Suspension (right and left machine side)
- 12 Exhaust gas system
- 13 Battery
- 14 Cooler package
- 15 Air filter
- 16 Air conditioning system
- 17 Windscreen washing system
- 18 Storage compartment (right and left machine side)

 **DANGER**

Danger of serious accidents

Transport rides on the machine, especially the steps or maintenance access, are prohibited!

Hydraulics

WARNING

Accidental hydraulic movements (e.g. caused by passengers, children or air in the hydraulic system) can lead to severe accidents and injuries!

- Secure or lock the control units on the machine.
- Instruct persons to leave the slewing range of foldable machine parts.
- Switch all control units to the locked position before switching on the machine again.
- Connect the hydraulic lines only when the hydraulics are without pressure on the machine side. All connections must have been tightened before commissioning.
- When searching for leaks, never use your fingers to locate oily spots on hydraulic components.
- Vent the hydraulic system!

NOTE

- Operate the machine with mineral oils.
Do not mix mineral oils with organic or ester oils!
The hydraulic circulation of the machine must contain mineral-based hydraulic oil.
- Oil purity acc. to ISO 4406: 18/16/13
- Always connect all hydraulic lines! Otherwise components may get damaged because of interrelated functions.
- Ensure cleanliness and tight fit of all plug-and-socket connections!
- With all hydraulic movements slow down the control unit before the machine components reach the stop position.
- Observe the notes on hydraulics and pressure accumulator in chapter *Safety and responsibility*!

NOTE


The hydraulic cylinders must be filled again with hydraulic oil after carrying out installation work on the hydraulic system. This is done by selecting all hydraulic functions several times. Hydraulic cylinders must extend and retract without jerking.

- Danger zones must be blocked off during commissioning.
- When performing installation work, raised machine parts must be lowered completely, moved to a safe position or secured at the particular height by suitable means.

Lighting

NOTE

- Flashing indicator light to indicate a direction change during road travel.




Blinkers/hazard light system (each on the right and left side)

- 1 Blinkers/hazard light system
- 2 Outside blinker


NOTE

Driving light can only be switched on with the ignition activated.




Front headlamps for driving light and high beam (each on the right and left side)

- 3 High beam
- 4 Parking light / daytime running light / dimmed headlight




5 Trackfinder (each on the right and left side)(optional)




Working headlights (each on the right and left side)


- 6 Working headlights
- 7 Working headlights (optional)



8 Rotating beacon (each on the right and left side) (optional)




9 Rotation beacon folding boom middle section (optional)



10 Reversing light on pendulum frame(optional)



11 Folding boom headland lighting (each on the right and left side)(optional)



Rear light, reversing light, brake light and blinker / hazard light system (each on the right and left side)
(The design may vary according to the country.)

WARNING

Traffic accidents caused by defective lighting.

- Check the lighting before setting off.
- Check warning boards and lighting equipment for cleanliness.

Instruction stickers


- Clean soiled stickers.
- Damaged or illegible stickers must be replaced immediately.
- Apply the specified stickers to spare parts.

Retighten the wheel nuts / wheel bolts after 31 mi (50 km) or 10 hours. Retighten every day - see maintenance overview.



00380359

Tighten with torque 375 ft lb (510 Nm)




00385489

Components Chassis

Engine

The engine is located behind the cabin.



WARNING

The engine cover may only be opened when the engine has been shut down.

CAUTION

A mixture of dust, oil and plant residues in the engine compartment is a source of fire and thus increases the risk of fire.

- Always keep engine and engine compartment clean.
- If necessary clean out dirt and oil deposits.

Engine oil

A minimum oil level in the oil sump is mandatory to make sure that the engine is also lubricated in slanted position.

If the oil level is too low, the engine should not be started.


The oil level should always be between the min. and max. marks on the dipstick.

The oil level can be read from the dipstick (left side of the engine).

NOTE


Maintaining the required oil level is mandatory for the engine!

- Check the engine oil level only with the machine parked horizontally.
 - If the oil level is below the minimum the engine must not be started.
 - Fill up oil to the maximum mark on the oil dipstick.
 - Thoroughly clean the area around the oil dipstick before pulling it out.
 - After the oil level check reinsert the dipstick.
-
- If the oil level is too low, top up engine oil through the filler opening.
 - In case of too low oil pressure an audible warning signal will sound. Shut down the engine and perform troubleshooting.



Filler opening for engine oil


Engine oil and filter change



1 Drain plug

2 Oil dipstick

- Unscrew the drain plug on the bottom of the oil pan. Attach the supplied drain hose for the oil change. Attaching the hose will open the safety valve in the oil pan connection. Drain the oil.
- Screw the drain plug back into place.
- Refill new oil according to the maintenance table and check it with the dipstick. Follow the *Maintenance overview* section.




Engine oil filter

- Remove the oil filter.
- Wet the rubber seal of the new filter with clean oil.
- Tighten the filter quickly until it is just seated. Now turn the filter by another half turn.

NOTE

Change the engine oil and the engine filter after each 600 hours or annually.

Crankcase filter change



- Remove the screws on the housing.
- Remove the filter and introduce a new filter.
- Close the housing again with the screws.

Engine coolant

From the factory the cooling system is filled with a special coolant. This coolant protects against corrosion and offers anti-freeze protection down to -22°F (-30°C).

CAUTION

Risk of scalding when opening the cap while the engine is hot. Shut down the engine and wait until the engine has cooled down. Totally remove the filler cap!


NOTE

The cooling system must always be filled with engine coolant, irrespective of the time of year! Refer to the HORSCH maintenance log supplied for checks and maintenance!

It is mandatory to observe and comply with the specification of the engine manufacturer!

- Check the engine coolant by removing the filler cap. The coolant must reach the upper edge.
- If the filling level is too low, a warning message appears at the terminal. The filling level can also be read through the sight glass.

- In case of a too high coolant temperature an audible warning signal will sound. Shut down the engine and let it cool down. Check for the cause of overheating.
- Check the engine coolant level every day.



Sealing cap and sight glass for cooling liquid

Clean cooling system


Always keep air intakes and cooling nets clean. Shut the engine down for cleaning. If necessary clean with compressed air or a water jet.

NOTE

- The cooling fins of the cooler package must always be kept clean!
- Do not use high pressure cleaner for cleaning!
- Do not clean crosswise toward the fins!

Compressed air connection

There is a compressed air connection behind the cabin under the cover flap. A compressed air hose can be connected to it to blow out machine parts, e.g. air filters or radiators with compressed air.



Compressed air connection

CAUTION

Open the cover only when the engine is stopped! Make sure that the ignition key has been pulled out and that no other persons are in the cabin.


Ribbed V-belt

CAUTION

Check / tension / change ribbed V-belts only with the engine shut down. Make sure that the ignition key has been pulled out and that no other persons are in the cabin.

The ribbed V-belt drives the following components:

- Fan / water pump
- Generator
- A/C compressor



Ribbed V-belt

NOTE

Follow also the notes in the *Undercarriage maintenance overview* section.

Fuel tank

The fuel tank is located on the right-hand side of the machine.



Fuel tank (the figure shows the variant with Stage V engine and AdBlue tank)

- 1 Fuel tank
- 2 Filling opening with lid
- 3 AdBlue tank

Fill up fuel / urea solution

CAUTION

Danger of explosion when handling fuels! Shut down the engine! During refuelling, open fires must be avoided and smoking is strictly prohibited!

NOTE

Use only stipulated fuels. They are listed in the *Maintenance overview* section.

Quality and cleanliness of fuel and AdBlue are of fundamental importance for continuous good performance and a long lifetime of the engine. Always refuel every day after the end of work to prevent the formation of moisture and freezing of the fuel system.

- Shut the engine down before starting to refuel. Lower the suspension to the lowest level if necessary.
 - The filler neck is closed with the tank filler cap.
 - The tank is ventilated through a hole in the tank filler cap.
- Before removing the tank cap clean the area around it from crop residues and dust/dirt.
- Caution when handling easily inflammable fuels and AdBlue. During the refuelling process do not smoke, avoid naked flames and ignition sources!
 - Avoid fire by keeping the machine free of dirt and grease residues.
- Only refuel outdoors. Always wipe off any spilled fuel / AdBlue.
- Finish the fuelling process after the pump nozzle has shut off.
- Refuel according to the season of the year.

NOTE

Diesel fuel or AdBlue must not come into contact with the skin, eyes or clothing and must not be inhaled.


- Move any affected person to the fresh air after inhalation. Contact medical assistance in case of doubt.
- Wash with plenty of water and soap in case of skin contact.
- In case of eye contact, wash immediately and thoroughly with water and contact a physician. Remove contact lenses if applicable.
- If swallowed, rinse out the mouth immediately with lots of clear water and drink plenty of water. Do not induce vomiting.
- Change soiled clothes immediately.
- In case of allergic reactions consult a physician immediately.
- Keep fuel or AdBlue away from children.

NOTE


When the ignition is switched on, the fuel level and the AdBlue level can be read on the engine display.

Fuel filter


The engine has a fuel prefilter and a fuel filter.



Fuel master filter



- 1 Fuel prefilter sight glass
- 2 Fuel prefilter



AdBlue filter

Exhaust gas system Leeb 5.300 / 6.300 VL



- Emissions standard stage 5
- Emission treatment consists of:
- Oxidation catalyst
 - Particle filter with regeneration system
 - Selective catalytic reduction with AdBlue

AdBlue filter change

- Unscrew the lid of the AdBlue filter.




Figure: FPT©

- Remove the plunger of the filter.




Figure: FPT©

- Visually check the colour of the main filter.




Figure: FPT©

- Introduce the tool supplied into the filter. Use the correct side of the tool according to the colour (black or grey).




Figure: FPT©

- Pull out the filter with the tool.




Figure: FPT©

- Introduce the new filter.




Figure: FPT©

- Reattach the plunger of the filter.




Figure: FPT©

- Screw the lid of the AdBlue filter back on. Tightening torque: 14 ft lb \pm 3.5 (20 Nm \pm 5)



Figure: FPT©

Diesel filter change

NOTE

The diesel filter must be replaced every 600 operating hours or annually.
Vent the system after changing the filter!


Ventilation

- Fill the fuel tank with fuel.
- Open the vent screw.
- Pump with a hand pump until fuel escapes from the vent screw without forming bubbles.
- Close the vent screw, max. 6 ft lb (8 Nm).
- Continue operating the hand pump until a noticeable resistance is felt.
- Now start the engine.

NOTE

Never hold the ignition key longer than 10 seconds in the starting position. Wait 30 seconds before attempting the next start.



- Increase the speed to dispel the remaining air from the fuel system.
- Repeat the previous steps if air remains and the engine stalls.
- Carry out the process until the engine starts without problems.



- 1 Diesel filters
- 2 Venting screw
- 3 Hand pump

Hydraulic oil tank

The tank is located on the right-hand side of the machine.



Oil drain plug



Filling opening

Oil level inspection

- Fold in the spraying boom.
- Set the hydraulic height adjustment to street level. (optional)
- Shut down the engine. Oil must be visible in the sight glass. (depending on variant)
- The sight glass is located on the hydraulic oil tank (depending on variant).
- If the oil level is too low, a warning message appears at the terminal.



Example: Hydraulic oil tank sight glass of Leeb PT variant

NOTE

Prototypes do not have a sight glass. Oil level control: Lower the parallelogram, adjust the hydraulic height adjustment to street level while the engine is running. Oil must be visible at the lower edge of the screen of the filler opening.

Oil change

NOTE

Do not mix different oils. Use only the prescribed specification!
Before changing the oil type, you should consult the Customer Service.

We advise you not to use bio-hydraulic oils. Should the use of bio-hydraulic oils be necessary in isolated cases, you should strictly consult the Customer Service.

Refer to the *Maintenance* chapter and the HORSCH maintenance log for the first oil change and the further intervals.

- Place a suitable collecting vessel under the drain plug and on the drain hose.
- Open the drain plug and screw in the drain hose.
- Drain oil into a suitable collecting vessel and dispose of in accordance with regulations.
- Close the drain plug.
- Fill in new oil according to the maintenance table. Follow the *Maintenance overview* section in this regard.
- Check the oil level (oil must be visible in the sight glass) (depending on variant).
- Start the engine and run it for two minutes at idle speed.
- Set the hydraulic height adjustment to street mode. (optional)
- Check oil level once more, top up if necessary.

NOTE

You may hear pump noises temporarily. If these do not disappear after a short while, shut down the engine and consult our After Sales Service!

NOTE

Change the oil of the hydraulic tank every 1200 h or annually. Refer also to the *Undercarriage maintenance overview* section.

Change hydraulic oil filter


NOTE

Ensure strict cleanliness when changing the filter!

Replace filter element

- Replace the filter with every hydraulic oil change.
- Clean the area around the filter.

1. Unscrew four screws on filter housing.
2. Take out the filter.
3. Replace the seal ring.
4. Reinsert the new filter.
5. Assemble the housing cover.
6. Check the filter for leak tightness with the engine running.



Hydraulic oil filter

NOTE

You may hear pump noises temporarily. If these do not disappear after a short while, shut down the engine and consult our After Sales Service!

Clean hydraulic oil cooler

Always keep the hydraulic oil cooler clean. The engine must be shut down for cleaning the fins.





NOTE

- Do not use high pressure cleaner for cleaning!
- Do not clean crosswise toward the fins!

Steering

The machine is equipped with various steering combinations.

- Manual front axle steering
- All-wheel steering
- Slope mode

The vehicle has been designed with rear axle steering. The steering angle of the rear wheels depends on the travel speed.

- With travel speeds of less than 6.2 mph (10 km/h) the steering angle is identical for front and rear axle.
- With travel speeds between 6.2 and 12.4 mph (10 and 20 km/h) the steering angle of the rear axle is increasingly reduced.
- From 12.4 mph (20 km/h) up the rear axle steering is disabled. The axle remains in middle position.

The steering mode can be selected using the buttons on the multi-function control panel or the terminal.

Brake system



DANGER

Uncontrolled rolling of the machine may cause severe injuries by crushing or rolling over.

- Park the machine only on level ground with sufficient load bearing capacity.
- Secure the machine with wheel chocks against rolling before releasing the brake.



WARNING

Danger of crushing, cutting, being pulled in, being caught and impact caused by incorrectly functioning brake system!

Perform a function test of the brake system before each travel!



NOTE

Adjustments and repair work on the brake system must only be carried out in a professional workshop or by an operator, who has been specially trained by HORSCH.

The machine has a wet multi-disc brake on each wheel gear.

The brake is actuated via the foot pedal in the cabin.

The hydraulic parking brake in the wheel gear is actuated via a toggle switch in the cabin.

- After a short travel distance perform a brake test at low speed.
- Check for chafing points on the brake hoses!

Maintenance

- Check all flexible brake or hydraulic hoses for wear.
- Check all brake lines for damage.
- Check all threaded joints for leaks.
- Replace worn or damaged parts.



WARNING

Danger of traffic accidents caused by brake failure!

During commissioning or after long periods of rest:

- Start the engine to fill the pressure accumulator for emergency braking before starting to drive

Mechanical release mechanism of parking brake

DANGER


Danger of severe injuries caused by unprotected rolling of the machine when the parking brake is released!

Always use the wheel chocks provided when the machine is stopped!

NOTE

The active parking brake is deactivated. During maintenance work secure the machine with wheel chocks against accidental rolling away!


- In the event of faults of the engine or hydraulic pump, the vehicle may not build up the oil pressure necessary to release the parking brake. In this case the parking brake can be released manually.
- Press in the tappet (1) on the hydraulic pump.
- Operate the hand pump (2) until a noticeably resistance can be felt. The parking brake is now released.
- Due to a possible leakage later pumping may be necessary.
- The release fixture is deactivated per hydraulic oil pressure as soon as the engine is running again.



1 Tappet

2 Hand pump

The actuating lever for the hand pump is located in the storage box in the bin on the left side in the direction of travel.



Mechanical release fixture actuating lever

DANGER

The machine may start rolling when operating the mechanical release fixture! Secure the machine with wheel chocks!

Axles

NOTE


All maintenance and repair works must solely be carried out by expert personnel. Safety regulations must be strictly complied with!

The oil in the wheel gears must be changed at regular intervals. Check for leaks on the gears. Check the hoses for visible damages.

Remove all dirt from the steering knuckles once every day. For this purpose turn steering once completely to the left and the right.

Wheel drive

The wheel motor transmits its power to the wheel via the wheel gear.



Two gear variants – PowerGear (GFT 8130) and HighPowerGear (GFT 8144) – are available.

PowerGear (GFT 8130)



- Small variant
- 10 wheel nuts

HighPowerGear (GFT 8144)



- Large variant
- 12 wheel nuts

The correct amount of oil in the gears must be ensured depending on the variant!

Oil change

NOTE

Change the oil of the wheel gears after the first 100 hours and then after every 600 hours. Refer also to the *Undercarriage maintenance overview* section.


Refer to the *Maintenance* chapter and the HORSCH maintenance log for the first oil change and the further intervals.

In between, check the oil in the wheel hub gears regularly.

NOTE


Change the oil only with the gearbox at operating temperature!

- Park the machine on level ground.
- The wheel must be positioned so that the oil drain plug is at the lowest point. Then open the oil drain plug.
- Catch the oil in a suitable tank and close the drain plug.



Oil drain plug

- Turn the wheel until the filler plug is below the centre of the wheel gearbox (note the value in cm).
- Gear PowerGear (GFT 8130):
approx. 1.38 in. (3.5 cm)
- Gear HighPowerGear (GFT 8144):
approx. 1.38 in. (3.5 cm)
- Open the filler plug and fill in new oil up to the lower level.



Filler plug

- Close filler plug.
- Heat the gearbox to approx. 122 °F (50 °C) by driving.
- Then check the oil level and top up if necessary.

NOTE

Only use the specified gear oil with the correct viscosity. Follow the specifications in the *Undercarriage maintenance overview* section. Oils not approved may cause greater wear, poorer braking action and even failure of the wheel hub bears. Filling capacity per wheel hub gearbox:

- Gear PowerGear (GFT 8130):
approx. 4 x 64 fl oz (1.900 ml)
- Gear HighPowerGear (GFT 8144):
approx. 4 x 88 fl oz (2.600 ml)

Wheels and tires


- Check the tires every day for damage and air pressure, because the lifetime of tires depends on the air pressure.
- Have cuts or breaks in the tires repaired as quickly as possible or change the tires.
- Do not expose tires to oil, grease, fuel, chemicals as well as prolonged direct exposure to sunlight.
- Drive carefully! Avoid driving over sharp stones or edges.
- The prescribed tires and rims must be used.
- The difference in tire pressure between the tires of one axle must not exceed 1.45 psi (0.1 bar).
- During fast driving or hot ambient temperature the air pressure may rise by up to 14.5 psi (1 bar). Do not reduce the air pressure, because it may then drop too low when cooling down!
- Repair work on tires must only be carried out by experts and by using appropriate assembly tools.
- Assembly work requires appropriate knowledge and proper tools.

NOTE

Retighten the wheel fastening screws after the first hour and then after 20 operating hours. Subsequent regular checks!

Tight fit of wheel nuts:

| | |
|-------------------|------------------------|
| Front ft lbs (Nm) | 375 + 37 (510 + 50) |
| Rear ft lbs (Nm) | 375 + 37 (510 + 50) |



Air pressure of tires

The required air pressure in the tires depends on

- Tire size
- Load bearing capacity of the tires
- Travel speed

The performance of tires is reduced by:

- Overloading
- air pressure in tires too low
- air pressure in tires too high

Wheel change

WARNING

Danger to life caused by crushing and impact in case of unprofessional or incorrect operation. Instruct persons to leave the working and danger zone when working on the machine!

WARNING

- Use suitable lifting equipment to raise the machine!

NOTE

- Perform a wheel change only with profound expert knowledge and by using proper assembly tools.
- Preferable use auxiliary devices such as a wheel change cart to change wheels.
- When changing wheels without special devices, perform this task with a least 2 persons who are able to handle the wheel securely.
- Work only on level ground with sufficient load bearing capacity.
- Observe the accident prevention instructions when changing the wheels.
- When assembling new tires always use new tubeless valves or hoses.
- Remove any corrosion found on the wheel contact area of the rims before assembling a new / different tire.
- When travelling, traces of corrosion can cause damage to the rims.
- Always screw valve caps with integrated seal on the valves.
- Tighten the wheel screws with 375 ft lb (510 Nm).

Execution


1. Park the machine on a level and paved area.
2. Apply the parking brake.

3. Place the jack on the side of the wheel to be changed at the lifting point of the lifting device. Follow the *Lifting device* section in this regard. When using a hydraulic jack without safety lock, use a tripod trestle or similar support device in addition to secure the load against lowering.
4. Loosen the wheel nuts by half a turn.
5. Lift the axle with the jack until the wheel is clear.
6. Adjust the tripod trestle to the correct length and put it under the axle.
7. Loosen the wheel nuts and remove the wheel.

⚠ WARNING

- Never park the machine without securing it when the wheel(s) is/are dismantled!

8. Attach the new wheel and fasten it with the wheel nuts. Tighten all wheel nuts crosswise:



9. Remove the tripod trestle and lower the machine.
10. Tighten the wheel nuts with the torque wrench.

⚠ NOTE

- Retighten the wheel nuts after 6.2 mi (10 km).


Adjusting the track width

Refer to the *Commissioning* section for this purpose.

Suspension (ComfortDriveFlex)

Refer again to the *Commissioning* section for this purpose.

The pneumatic independent suspension includes a level control independent of the load condition.



Level valve with folding boom

To minimise the transport height, the folding boom for the level suspension may be unhooked. This must be done separately for each axle and each wheel.

⚠ NOTE

The folding boom must be attached in standard operation. Bolt down the folding boom as shown. This must be done separately for each axle and each wheel.

⚠ NOTE

Danger of crushing for body parts between undercarriage and body when lowering the machine!

Order persons to leave the danger zone around the machine.

⚠ WARNING

Mechanical release fixture


Danger of uncontrolled machine movements.

- The purpose of mechanical release devices merely is to bring the machine as quickly as possible to a HORSCH specialist workshop and to have a possible defect repaired.
- Mechanical release devices are not intended for continuous operation!


Mechanical release fixture folding boom block / parallelogram and Load Sensing activation

In case of faults of the parallelogram lift, for release of the folding boom block and for Load Sensing activation, mechanical release devices are located at the module block at the rear right, near the parallelogram connection. With these valves the safety valves can be bypassed as long as the hydraulic pressure supply is intact.

- To release the parallelogram lift and the folding boom block, manually actuate the hydraulic valve V80 (1) by removing the cap.
- To release the Load Sensing connection, actuate the hydraulic valve V20 (2) manually, turn down the small screw on top of the release device fully clockwise.
- After the repair has been carried out, reset the screw of the release device to its original state!




Release device



Hydraulic valve block lift, pumps, rear right, near parallelogram connection

Mechanical release device spraying pump and fan

In the event of an electrical defect, there is a hydraulic valve block at the right on the hydraulic pump for mechanically releasing the spraying pump. With this valve the spraying pump can be selected as long as the hydraulic pressure supply is intact.



1 Mechanical release of spraying pump
2 Mechanical release of fan

Spraying pump

- Screw in the small screw on the top of the release device (1) to the right until the spraying pressure in the spraying boom has the desired value.
- In this way any remaining chemical can, if necessary, be placed before a repair is carried out.
- After repair work has been carried out, unscrew the screw of the release device to the left.
- Contact HORSCH Service for troubleshooting.

Fan

In the event of an electrical defect of the valve on the hydraulic venting device, cooling of the engine, the hydraulics, the charge air and the A/C system will no longer work and the machine is therefore no longer cooled.

- Using the release fixture (2) a speed can be specified on the fan to cool the cooler package again.
- Turn in the screw of the release device (2) toward the right. This increases the fan speed and the machine cooling works again.
- After repair work has been carried out, unscrew the screw (2) of the release device to the left.


Mechanical release device of access ladder

In the event of an electrical defect, a valve for mechanical release is located on the hydraulic valve block for the access ladder. The hydraulic

valve block is located next to the cabin. With this valve the ladder can be raised and lowered as long as the hydraulic pressure supply is intact.



Mechanical release device of access ladder



Valve for mechanical release of access ladder

Access ladder


- Loosen the knurled screw.
- Lifting the ladder: Push in the small pin on top of the release device until the pin has engaged.
- Lowering the ladder: Pull out the small pin on top of the release device until the pin has engaged.
- Tighten the knurled screw to secure the ladder position.
- After the repair has been completed, return the screw of the release device to the centre position and secure with the knurled screw.
- Contact HORSCH Service for troubleshooting.

NOTE


The ladder can only be raised/lowered via the arm rest buttons when the door is closed.

Mechanical release device for hydraulic track width adjustment (TrackControl)

In the event of an electrical defect, a release device for hydraulic track width adjustment (optional), for the directional release, is located at the right rear near the parallelogram connection. With this valve the direction for pushing in/out can be released as long as the hydraulic pressure supply is intact.



Mechanical release device TrackControl



Valve for mechanical release of TrackControl


Track width adjustment

- Loosen the knurled screw.
- Track width narrower: Push in the small screw on top of the release device (1) and turn it to the right until it has engaged.
- Track width wider: Pull out the small screw on top of the release device (1) and turn it to the left until it has engaged.
- Tighten the knurled screw to secure the small screw.


- Start the engine. Select the desired adjustment in the TrackControl menu.
- After the adjustment has been completed, return the screw of the release device to the centre position and secure with the knurled screw.
- Contact HORSCH Service for troubleshooting.

Mechanical release device hydraulic height adjustment ClearanceControl (optional)

In the event of an electrical defect, mechanical release devices are located on the hydraulic valve block for the height adjustment, between the spraying mixture container and the parallelogram connection. The height adjustment can be lowered with these valves.



Hydraulic valve block ClearanceControl



Hydraulic valve block ClearanceControl, 4x release valves installed

ClearenceControl

- Turn in the small screw on top of the valves toward the right until the undercarriage has been completely lowered on all 4 struts.



Severe accidents by crushing!

- Nobody may be present in the danger zone during lowering!

Maintenance access

Maintenance access is via the swivelling access ladder.

The access ladder is lowered or raised from the driver's cabin.




Severe accident by falling down!

- No passengers are allowed to ride on the machine!
- When climbing on the maintenance access always maintain contact on at least 3 points (hands or feet) of the access steps.



Platform railing

The railing on both sides of the platform can be folded down or up by hand. It is imperative when working in the maintenance area to fold up the folding boom in the interest of one's own safety. The railing must be folded down to allow folding in the folding boom. Otherwise, the folding boom will fold down the railing when folding it in. This may damage the paint coat on the folding boom and the railing.



Railing at left folded up



Railing at right folded down



DANGER

Severe accident by falling down!

- No passengers are allowed to ride on the machine!
- The railing must be folded up when working in the maintenance area.

Cooler package

Always check the cooler package behind the cabin for soiling before driving off and clean with compressed air, if necessary.

Always keep the stainless steel screen under the step grille clean. To clean the screen, stop the engine and fold up the step grille. If necessary, remove the sieve and clean it with compressed air or water jet.



Stainless steel sieve and step grille

The cooling fins of hydraulic oil cooler, radiator, air conditioning cooler and charge air cooler must always be kept clean. Clean with much water and little pressure if necessary.



Cooler package

Air filter




WARNING

Danger of burning on hot engine components. Any maintenance work on the air intake system must only be carried out with the engine shut off and cooled down.

Pay attention to possibly contaminated dust in the filter. Do not inhale it and avoid skin contact. Do not blow out or suction out the filter. Dispose of filter properly.

The air filter is located behind the cabin under the covering. This must be checked regularly and replaced at the specified intervals, see chapter *Maintenance*. Pay attention to the above warning.

If the warning indicator lights on the terminal, the main filter element needs to be replaced.




NOTE

If the air filter is heavily contaminated, this is indicated by a warning symbol on the terminal. If the preliminary filter system (e) is heavily contaminated it must be dismantled and cleaned. A defect or missing Vacuator valve (f) must be replaced.

The tightening torque of the screw clamp (g) must be in the range of 2.6 ft lb (3.5 Nm) +/- 0.4 ft lb (0.5 Nm).

Overview of components


The air filter consists of the following components:



- (a) Housing lid with fastening clips
- (b) Main element / primary filter
- (c) Safety element
- (d) Housing
- (e) Preliminary filter system
- (f) Vacuator valve
- (g) Screw clamp

Disassembling / cleaning the air filter

Shut down the vehicle engine before starting work on the air filter. With all work make sure not to damage any seals and not to bring dirt into the housing.




1. Open the clips on the housing cover (a) and remove the lid.
2. Slide the main element (c) under a slight angle to the front.
3. Remove the main element (b).
4. Remove the safety element (c).

NOTE

Never wash out or brush off the main element (b). When blowing it out no dust should enter the inside of the main element. Do not continue to use a damaged element. If in doubt, use a new main element.

If the contamination indicator is still visible in the display after cleaning, replace the main element! Replace the main element after 1200 h or annually. Refer also to the *Maintenance* chapter.

Installing the air filter



NOTE

Check the main element (c) for damage, cracks and cuts before installation.

5. Install the safety element (c).
6. Insert the main element (b) into the housing and push it in under a slight angle.
7. Attach the housing cover (a) to the housing and close the clips.
8. Check visually.

NOTE

Change the safety element:

Replace the safety element (c) after 2 years or 2400 operating hours! See chapter *Maintenance*. Refer to the HORSCH maintenance log for records and enter when replacing!

Air conditioning system

Components

- Compressor (on the engine at the right in direction of travel, driven via ribbed V-belts)
- Condenser (via coolant cooler)
- Dryer cartridge (behind the cabin under the covering near the oil pan)
- Evaporator (under cabin roof)
- Pressure switch (on the dryer cartridge)
- Expansion valve (under cabin roof)
- Air conditioning unit (in cabin, roof console)

Refrigerant

NOTE

The air conditioning system is operated with the refrigerant R134a (tetrafluoro-ethane). This substance does not contain any chlorine atoms and is thus harmless for the ozone in the atmosphere.

The refrigerant must not simply be drained off, but must be professionally disposed of. Connecting lines must therefore not be disconnected. Have maintenance and repair work on the air conditioning system solely carried out by your HORSCH sales partner, when necessary, using appropriate waste disposal and recycling facilities.

| Refrigerant R 134a | |
|-------------------------------|--|
| Chemical designation: | 1,1,1,2-tetrafluoro-ethane |
| Chemical formula: | CH ₂ F CF ₃ |
| Freezing point: | -150 °F (-101.0 °C) |
| Critical temperature: | -150 °F(-101.1 °C) |
| Critical pressure: | 588 psi (40.60 bar) |
| Features: | non-toxic, not inflammable, inoffensive to ozone |
| Most important safety aspect: | Danger of suffocation in high concentrations, can cause frost injuries |

NOTE

Refer to the safety data sheet of the refrigerant for further details.


Drier cartridge air conditioning system

NOTE

The ambient temperature must be higher than the temperature set on the thermostat (normally 33.8 °F = +1 °C) so that the compressor will cut in.



Drier cartridge below the oil pan



Drier cartridge position

Pressure switch

The air conditioning system is equipped with a pressure switch, which switches the system off in case of overpressure or vacuum. This is attached to the drier cartridge.



Drier cartridge pressure switch

Condenser

- Check the condenser for soiling.
- Clean the condenser depending on the degree of contamination, but at least once per month
- Blow out the condenser with compressed air but take care to avoid damaging the fins.



NOTE

- Always keep the condenser clean!
- Do not use high pressure cleaner for cleaning!
- Do not clean crosswise toward the fins!

Checking refrigerant condition and filling quantity

Maintenance as needed

Have air conditioning system checked and, if necessary, repaired by an authorized expert workshop.

NOTE

Maintenance work on the air conditioning system, which requires intervention in the refrigerant circuit (e.g. refilling refrigerant, replacement of collector/dryer), must only be carried out by authorized expert workshops! It must be entered in the maintenance log!


Windscreen washing system

The tank is located behind the driver's cabin under the covering.

Open the lid of the tank to fill the windscreen washer system.

Fill the container for windscreen wiping water as required. Use only clean water, as otherwise the nozzles may get blocked.

Filling capacity max. 1 gal lqd (4 litres).



Windscreen washing system tank

It is recommended to add a windscreen washing agent to achieve a better cleaning effect.

NOTE

Drain the washing system in the winter or use windscreen cleaner with appropriate frost protection. Operate the windscreen cleaning system to empty all lines or to flush it with the windscreen cleaner containing the frost protection. Follow the manufacturer's specifications on the mixing ratio of frost protection: water.


Compressed air system

Two air reservoirs are installed on the machine. The first is located under the cabin, the second in the middle of the parallelogram. They must be drained daily before starting work by operating the valve!

On the right side in the middle section of the folding boom there is a filter-regulator combination. These must be checked daily and drained if necessary.

- Pull the drain valve until water stops running out from the air reservoir through the valve.

In case of contamination unscrew the drain valve from the air reservoir and clean the air reservoir. To do this, stop the engine and relieve the pressure beforehand.



Air reservoir under the cabin with drainage valve



Parallelogram air reservoir with drainage valve



Water separator and filter-regulator combination

NOTE

The filter-regulator combination will drain itself when full. However, the system can also be drained manually. Remove the collecting vessel of the filter regulator to this end. Release the pressure before drainage!

When preparing the machine for winter storage, check whether the filter-regulator combination is empty. Drain them manually if necessary.

NOTE

The dryer cartridge must be changed if water has collected in the air reservoir!

Compressed air system dryer cartridge


A dryer cartridge is located on the machine which cleans the compressed air provided by the compressor from water and other contaminations. This dryer cartridge must be replaced according to the maintenance interval.

Dryer cartridge replacement:

- Unscrew the dryer cartridge.
- Slightly oil the seal of the new dryer cartridge.
- Screw down the new dryer cartridge.



Compressed air system dryer cartridge position



Compressed air system dryer cartridge

NOTE

Refer to the information in the maintenance table regarding the maintenance interval.

Electrics

Battery

The battery is located on the right side of the machine behind the cabin under the covering. The self-propelled crop protection sprayer has one 12-Volt electrical system.

| 12 Volt - power supply | |
|------------------------|--------------|
| Generator power | 14 V / 200 A |
| Number of batteries | 1 |
| Battery voltage | 12 V |
| Battery capacity | 180 Ah |

NOTE

Further information on the electrical system (circuit diagrams etc.) is available from HORSCH Service.



12-volt electrical system (right behind the cabin)

Danger when handling batteries

CAUTION

- Only perform repair, care, maintenance and cleaning work with the machine at standstill. Shut down the engine. Pull out the ignition key. Secure the machine against rolling away.
- Repair and maintenance work must only be carried out by authorized experts.
- Avoid the creation of sparks or naked flames in the vicinity of the battery.
- When working on the electric system or on the engine you should always disconnect the earth cable or switch off the main battery switch.
- When removing the battery always disconnect the earth cable first and the plus cable after.
- Pay attention to the manufacturer's notes on dangers on the batteries!

NOTE

The following is generally valid: Always keep batteries clean from dust and crop residues!

Cleaning the batteries

- Clean the battery, if required.
- Remove possible oxidation from the terminal clamps with a brush.
- Use pole grease if necessary.
- Keep the ventilation openings in the plugs open.

Check general condition of batteries

- Check fluid level / acid level of the battery at regular intervals, top up if required.

Installing and connecting battery

- Always connect the battery with correct polarity.
- When installing a battery always connect the plus cable to the plus pole, then connect the minus cable to the minus pole.
- Failure to comply with the correct polarity between battery and three-phase alternator causes severe damage.

Battery main switch

On the right side of the machine, behind the cab, there is a main battery switch for immediate disconnection of the engine and vehicle electrical circuits.



For engines with exhaust stages 5, the main battery switch must not be switched off immediately after switching off the engine. Switching it off too early may cause an error message of the engine. Only after a time of approx. 15 minutes may the AdBlue system be switched on in order to ensure safe operation of the AdBlue system. Only use immediate shut-down in an emergency!

Three-phase alternator

- Always disconnect the battery main switch before starting work on the electric system. Then remove the negative cable from the battery to prevent damage.
- Protect the cable contacts of the positive cables against accidental contact with battery contacts.

Starter

- Always disconnect the battery main switch before starting work on the electric system. Then remove the negative cable from the battery to prevent damage.
- Protect the cable contacts of the positive cables against accidental contact with battery contacts.

Possible faults and proposed remedies


- Loose, dirty or corroded cable connections:
 - Clean the cable connections on the starter and tighten the connections.
 - Clean the earth cable on the engine and tighten the connections.
- Battery power too low:
 - Check for voltage drop on batteries, if necessary, recharge the battery.
- Discharged battery:
 - Charge the battery.
- Starter safety relay defective:
 - Replace the relay

NOTE

If the listed suggestions do not lead to the rectification of a damage, contact the HORSCH Service.

Transport and safety container

There is a transport and safety container on the right and left side of the machine. It is used to store personal protective outfit and accessories. Parts of the personal protective outfit may only be carried with the device if they are packed in a liquid-tight manner. Clean and contaminated protective outfits can thus be transported separately.



Transport container on the right side of the machine



Transport container on the left side of the machine

WARNING

To avoid contamination of the cabin, it must not be entered with used protective outfit!
The personal protective outfit must be stored packaged liquid-tight in the transport and safety container provided.

- In addition, the transport container contains a tool holder in which a metering cup, filter wrench, assembly wrench, etc. can be stored.

Tool storage

A storage compartment for tool storage is provided at the right front next to the cabin.



Tool storage compartment

Cabin

Access ladder

WARNING

Insufficient stability of access steps can lead to falls and injuries.

- Make sure the ladder is fully lowered when leaving the cabin.
- When climbing up and down, always maintain contact on at least 3 points (hands or feet) of the ladder. Always face the machine when climbing up or down.

WARNING

Danger of crushing by moving parts.

Riding on steps or platforms is not permitted.
Keep stepping areas / steps clean at all times!



folding access ladder



Multi-function control panel


- Access ladder foldable via pushbuttons on the multi-function control panel in the cabin (keep button depressed)

Button 1 = access ladder up

Button 2 = access ladder down

- In street mode the access ladder can be folded up to a speed of 2.5 mph (4 km/h).
- The access ladder can always be operated in field mode.
- When operating, make sure that there are no persons in the danger zone!
- Always use handles provided when climbing up or down!
- In case of a fault, the access ladder can also be folded manually.

On the machine display, the position on the access ladder is indicated with up / down arrow. If the ladder symbol flashes with a question mark, the position of the access ladder is not defined.



Cabin door

NOTE


The cabin door must be kept closed before driving off and throughout operation.

- Unlock with the key, press the button and pull on the handle.




Door handle from outside

- Press the door opener lever up




Door handle from inside

Overview




- 1 Steering column controls
- 2 Multi-function control panel
- 3 Ignition lock
- 4 Operating terminal
- 5 Machine terminal
- 6 Pedal
- 7 Driver's seat
- 8 Instructor's seat
- 9 Central electrics of machine
- 10 Storage tray/document box
- 11 Monitor for rear view camera (optional)



NOTE


Do not store any pointed, heavy objects on the floor of the cabin as they may cause the doors or front window to burst. Do not store any crop protection agent in the cabin.

Overview roof console



- 12 Operating elements Heating/air conditioning system
- 13 Adjustment of electrical outside mirrors
- 14 Switching driving lights on/off
- 15 Switching work lighting on/off
- 16 Switching rotating beacon on/off
- 17 Radio
- 18 Sun visor


Overview roof console




- 19 Storage compartment
- 20 Switch for hazard light system
- 21 Switch for road travel / field travel
- 22 top: Warning lamp for inside cabin pressure during air filtration Category 4 - Operation
- 23 Switch for parking brake
- 24 Cabin lighting and reading lamp
- 25 Circulating air filter
- 26 Central electrics of cabin



Overview roof console / A-pillar



- 27 Circulating air filter
- 29 adjustable fan nozzle
- 30 Radio loudspeakers



Driver's seat

A well-functioning and individually adjustable driver's seat is a prerequisite for keeping healthy. Regular care and function testing ensures the functionality of the driver's seat.

The function tests should at least be adapted to the maintenance intervals of the vehicle.

Wear items like rollers, shock absorbers and fastening elements must be checked from time to time.

CAUTION

Danger for persons due to a too small suspension range as a result of an incorrectly adjusted driver's seat.

- Before commissioning of the vehicle and with each driver change the weight setting must be adjusted to the individual weight of the driver. Do not store any objects in the suspension range of the driver's seat.
- Before commissioning check whether all adjustable features have been correctly locked in place. Do not operate any adjustable features during operation.

WARNING

Danger to persons in case of accidents by not wearing seat belts.

- Always wear your seat belt before commissioning the vehicle.

After an accident the seat belts must be replaced.

After an accident you should also have the driver's seat and its fastening checked by expert personnel.

WARNING

Danger to persons due to misuse of the seat occupancy detection.

Never load the seat area of the driver's seat with heavy objects as this could cause the vehicle to start moving without driver. In normal use relieving the seat area from any weight during travel brings the vehicle to a halt.

Overview



- 1 Right-hand arm rest with multi-function control panel
- 2 Seat area
- 3 Backrest
- 4 Left-hand arm rest with adjustable arm rest inclination
- 5 Seat belt

NOTE

Do not clean the driver's seat with a high pressure cleaner!

When cleaning the upholstery surfaces, soaking the cushions must be avoided.

- Test commercially available upholstery or plastic cleaners first in an inconspicuous place.

Weight adjustment



The respective driver's weight must be adjusted with the vehicle stopped and the driver's seat loaded by briefly pulling the automatic weight and height adjustment lever. Sit absolutely calmly when making the adjustment.

Height adjustment



The air-cushioned height adjustment can be infinitely adjusted.

The seat height can be changed by fully pulling or pushing the operating lever. If the top or bottom end stop of the height adjustment is thereby reached, the height will be automatically adapted to ensure a minimum suspension travel.



NOTE

To avoid damage operate the compressor for max. 1 min.

Horizontal suspension



Under certain operating conditions it is advantageous to switch on the horizontal suspension. This enables the driver's seat to better absorb impact loads in the direction of travel.

Position a = Horizontal suspension Off

Position b = Horizontal suspension On

- Once the position a has been set, the locking lever must engage in the desired position. Press the seat backward until it engages audibly.
- After locking it should be impossible to move the horizontal suspension to any other position.

Longitudinal adjustment

CAUTION

Risk of accident when operating the longitudinal adjustment while driving. Do not operate the locking lever while driving!



By pulling the operating lever up the longitudinal adjustment is released and the driver's seat can be moved forward or backward.

- Once the setting has been made, the locking lever must audibly engage in the desired position. The driver's seat should be locked against being moved to any other position.
- Do not lift the locking lever with your leg or calf.

Seat inclination adjustment



The inclination of the seat area can be individually adjusted.

Pull the left handle up to adjust the seat inclination. The seat can be inclined to the desired position by simultaneously putting weight on and off the front and rear seat areas.

Seat depth adjustment



The seat depth can be individually adjusted. Pull the right handle up to adjust the seat depth. The desired position is reached by simultaneously pushing the seat area forward or backward.

Arm rest



The left arm rest can be folded back and adjusted in height, if required.

To adjust the height of the arm rest pry off the round cap from the covering and loosen the hexagon nut (spanner width 0.5 in. = 13 mm) behind it. Move the arm rest to the desired position (5 increments) and tighten the hexagon nut (18 ft lb = 25 Nm). Replace the covering cap.

Armrest inclination



The longitudinal inclination of the arm rest can be changed by turning then hand-wheel. Turning towards the outside lifts the armrest at the front, turning towards the inside lowers it at the front.

Backrest adjustment



Pull the lever up to adjust the backrest. Do not press against the backrest while unlocking it. The desired position is reached by simultaneously loading and unloading the backrest. Release the lever to lock again.



NOTE

After locking it should be impossible to move the backrest to any other position.

Lumbar support



By pressing the Plus or Minus switch on the rear of the backrest, the bulge of the backrest can be adjusted individually.

Lateral horizontal suspension



Under certain operating conditions it is advantageous to switch on the lateral horizontal suspension. This enables the driver's seat to better absorb impact loads from the side.

The suspension comfort can be switched on and off via the locking handle.

Seat heating / ventilation



The seat heating is switched on by flipping the switch on the left side of the backrest upward. The seat heating is switched off again by returning the switch to the centre position 0.


Ventilation is switched on by flipping the switch down and switched off by returning the switch to the centre position 0.

Stowage bag

The back of the back rest is equipped with a stowage bag.

To open the stowage bag, first pull the tab up and then open the lid of the stowage bag backwards.

Seat belt



Both the driver's and the instructor seat are equipped with a seat belt each.

- Always wear the seat belt!
- Do not open the seat belt while driving
- Pay attention to and comply with the corresponding country specific regulations and directives!

1. Pull the seat belt out of the belt retractor without jerking it.
2. Guide the seat belt as low as possible over the hip bones in the pelvic area.
3. Snap the tongue into the belt buckle.
 - Make sure that the seat belt is not twisted or pinched.
 - Make sure that the seat belt does not run over sharp edges or easily breaking objects.
4. To remove the seat belt, press the button and return the tongue of the belt to the retractor.

Instructor's seat

NOTE

The instructor's seat must solely be used during the instruction drive. Apart from this, no other person, except the driver, must remain on the machine or inside the driver's cabin during operation of the machine (in the field).

The safety belt must always be fastened!



Instructor's seat

The backrest of the instructor's seat can be folded up when not in use.



Steering column

Steering column adjustment

WARNING

Risk of accident! The steering column must only be adjusted when the machine is at standstill. Never make adjustments to the steering column while driving!

The height and incline of the steering column can be adjusted to the driver.



Overview of possible adjustments

- (a) Swivel steering column
- (b) Tilt the steering column
- (c) Adjust the height of the steering wheel

Swivel steering column

- Grasp steering wheel by hand.
- Operate the lever (a) at the rear end with your foot.
With the lever (a) actuated, swivel the steering column by hand to the desired position.
- Release lever (a).

The desired position is now locked.

Tilt the steering column

- Grasp steering wheel by hand.
- Push lever (b) upwards.
With the lever (b) actuated, tilt the steering column by hand to the desired position.
- Release lever (b).

The desired position is now locked.

Adjust the height of the steering wheel

- Grasp steering wheel by hand.
- Turn the lid (c) a quarter turn to the left.
- Set the steering wheel to the desired position by hand.
- Turn lid (c) a quarter turn to the right.

The desired position is now locked.

Multi-function switch

The multi-function switch is used to operate the horn, windscreen wiper, windscreen washer system, direction indicator, high beam and headlamp flasher.



Horn

Press the button on the multi-function switch to operate the horn.



Windscreen wipers

- Check the cleaning effect of the windscreen wipers at regular intervals. A clear vision is mandatory for safe driving.
- Replace the wiper blades at the latest after one year.
- In case of dirty windscreen operate the windscreen washer system before wiping.
- Do not operate the windscreen wipers on iced up screens, because this could damage the wiper lips or even the wiper motor.
- To operate the windscreen wiper, turn the ring on the multi-function handle.
 - Stage I = Intermittent
 - Stage II = Continuous operation
- Turn the ring back to the initial position to deactivate the windscreen wiper.



Windscreen washing system

Press the ring on the multi-function switch to activate the windscreen washer system.



Travel direction indicator

Press the multi-function handle to activate the direction indicator at the front and rear of the machine.

- Lever up = direction indicator to the right
- Lever down = direction indicator to the left



Headlight flasher

To operate the headlight flasher, pull the multi-function handle up.



High beam


To operate the high beam, press the multi-function handle down.

To dim it down, return the multi-function handle to the centre position.



Driving information

Driving information is shown on the display.



- (a) Direction indicator lamp - Machine
- (b) Direction indicator lamp - Trailer
- (c) High beam indicator lamp
- (d) Generator indicator lamp
- (e) Main warning lamp
- (f) Engine indicator lamp

Multi-function control panel

The multi-function control panel and the arm rest, which form one common unit, are located inside the cabin to the right of the driver's seat.

NOTE

After adjusting driver's seat and steering column you should check whether the multi-function lever can be optimally operated. If not, adapt the adjustment as required.

Longitudinal adjustment

- Longitudinal adjustment of the armrest by pulling up the rear lever on the right of the multifunction control panel and holding it up.
- Move the multifunction control panel forwards or backwards. If the setting is correct, release the lever again. The multifunction control panel must lock into this position.

The desired position is now locked.



Height adjustment

NOTE

When the lever is pulled up, the multifunction panel automatically moves up to the highest position.

- This can be avoided by pressing lightly on the armrest and holding the multifunction control panel at a height.
- Infinite vertical adjustment of the armrest by pulling up the front lever on the right of the multifunction control panel and holding it up.
- This can be lowered by pressing down on the multifunction control panel.
- The multifunction control panel can only be raised by pulling the lever upwards.
- If the setting is correct, release the lever again.

The desired position is now locked.



Overview of operator functions

The multi-function control unit is used to control functions for travel operation, spraying functions and other conditions of the self-propelled crop protection sprayer:




- | | |
|--|---|
| 1 Drive lever | 11 Freely assignable button |
| 2 Multifunction operating panel for spraying | 12 Operation of machine terminal |
| 3 Freely assignable button | 13 Switch for direction of travel selection |
| 4 Rear axle steering on/off | 14 Maximum drive pedal speed control |
| 5 Rear axle steering manual on/off | 15 Folding the folding boom wing in/out: Left outside wing, left inside wing, right inside wing, right outside wing, depending on the design of the Boom Control folding boom guide |
| 6 Rear axle steering slope mode on/off | 16 Manual correction of rear axle steering with slope mode |
| 7 Height adjustment/ suspension in slope mode on/off (optional) | 17 Release button for travel drive |
| 8 Lift access ladder | 18 Not used |
| 9 Lower access ladder | 19 Activate/deactivate GPS steering |
| 10 Height adjustment transport- / service position (only with hydraulic height adjustment) | 20 Not used |

NOTE

The exact functions of the individual buttons and switches will be explained in the associated chapters!

Drive lever

The direction of travel and speed can be set with the drive lever. The release button on the rear of the drive lever must therefore be pressed in addition.



With manual steering, the rear axle is steered by moving the drive lever to the left or right. Reversing and headland management are then no longer possible.

Transport / Service position

The transport and service modes are only available on machines with hydraulic height adjustment and when the parking brake is engaged.

- Brief push of button:
The machine lowers to service mode. The height adjustment is driven all the way down. The spring accumulators remain filled with pressure.
- Long push of button:
The machine lowers to transport mode. The height adjustment is driven all the way down. The spring accumulators are emptied and run without pressure.
- In transport or service mode:
Brief push of button: The machine returns to normal suspension mode.
- In service mode:
Long push of button: The machine switches to transport mode.

Travel direction switch

After starting the engine and releasing the parking brake the travel direction must be selected. This is done via the travel direction switch.

- Lever forward = Pre-selection for forward travel
- Lever backward = Pre-selection for backward travel

Air conditioning / Heater

The climate control regulates the temperature and humidity in the cabin.

The following operating modes are available:

- Automatic temperature and fan control:
Ideal for high outdoor temperatures.
- Manual fan control:
Automatic temperature control with manual setting of the fan speed.
- ECON mode:
Ventilation and heating without cooling function.
- REHEAT mode
Dry cabin windows with continuous operation of the air conditioning compressor at maximum fan speed.



- 1 Display to show the desired cabin or outside temperature. Unit displayed in Celsius or Fahrenheit. In addition, the error codes for faults are shown on the display.
- 2 Function light indicates automatic mode.
- 3 Turn REHEAT mode on/off.
- 4 Toggles the display between the cabin temperature and the outside temperature.
- 5 Reduce cabin temperature or fan speed.
- 6 Currently set fan speed (based on a bar chart, max. speed corresponds to a 100% filled bar).
- 7 Increase cabin temperature or fan speed.
- 8 Shift key between manual and automatic fan control.
- 9 Switching on the ECON mode.

Switching on the air conditioner / heater

- Switch on ignition or start engine.

After switching on the ignition, the software version is shown in the display (1) for 3 seconds.



The device then carries out a self-test, which takes a maximum of 20 seconds. The buttons are then enabled for operation.

The operating mode and display after switching on always correspond to the settings before the last switch-off.

When the engine stops, the fan speed is reduced after 10 minutes.

This prevents excessive discharge of the battery.

NOTE

If the cooling compartment is open, temperature errors may occur in the climate control system.

- Close the cooling compartment flap again after opening.

Switching on the climate control system

In automatic operation, the air conditioning compressor, heating and ventilation are automatically controlled so that the specified cabin temperature is reached as quickly as possible and then kept constant.

This operating mode is ideal for high outdoor temperatures.



Activate climate control:

- Switch off REHEAT mode (3), manual fan control (8) and ECON mode (9). The function lights (3), (8) and (9) are off.
- The function light for automatic mode (2) lights up. Climate control is active.
- When outside temperatures are below 50 °F (10 °C), the climate control system switches off the air conditioning compressor.

Setting the cabin temperature

⚠ WARNING

If the outside temperature is very high, avoid too great a difference between the cabin temperature and the outside temperature.



The display (1) shows the currently set temperature.

- The temperature can be reduced by pressing the Minus key (5).

- The temperature can be increased by pressing the Plus key (7).
- 1x pressing corresponds to 1 °F or 1 °C.

The climate control automatically regulates the cabin temperature to the set value. The fan speed is slowly increased so that the cabin temperature reaches the setpoint value more quickly. When the cabin temperature approaches the setpoint, the fan speed is reduced again.

In ECON mode (9), the temperature cannot be lowered but only increased. The fan speed can be changed manually.

Manual fan speed control

The fan speed can be controlled manually.



Activate fan setting:

- Switch on manual fan control (8). The function light (8) lights. Manual fan speed control is active.
- The bar diagram (6) shows the currently set fan speed. Maximum speed corresponds to a 100% filled bar.
- The fan speed can be reduced by pressing the Minus key (5).
- The fan speed can be increased by pressing the Plus key (7).
- 1x pressing corresponds to 10%.

The changed setting is saved and activated after 5 seconds.

By switching off the manual fan control (8), the fan speed is automatically controlled again.

Activate ECON mode

In ECON mode, the air conditioning compressor is switched off. The cooling of the cabin is switched off. Heating and, depending on the setting, ventilation are automatically controlled.

This operating mode should be used when the cooling function is not required.



Activate ECON operation:

- Switch on ECON mode (9). The function light (9) lights.
- The function light for automatic mode (2) goes off. The ECON mode is active and the cooling function is off.

Drying cabin windows with REHEAT mode

To dry the cabin windows, the compressor is permanently switched on at maximum fan speed. The heating is controlled to the adjusted set point.




Dry the cabin windows:

- Close the cabin doors.
- Switch on REHEAT mode (3). The function light (3) lights. REHEAT drying mode is active.
- The fan is set to maximum power.
- If necessary, change the fan speed; see *Adjusting the fan speed manually*.

Display outside temperature

Press the shift key (4) to display the cabin or outside temperature.

The function light (4) lights. The display (1) shows the outside temperature.



Change temperature unit

Press and hold the shift key (4) to display the cabin or outside temperature and the minus key (5) to reduce the cabin temperature or fan speed simultaneously for 3 seconds.

The temperature display is switched to the °Fahrenheit unit.

Repeat to reset the unit to °Celsius .




Adjusting the air flow of the air conditioner

The air flow in the cabin is distributed by the fan nozzles (a), (b) and (c) above, to the right and left of the windscreen.


Each fan nozzle can be manually opened, closed and adjusted in any direction.

To heat the footwell, adjust the fan nozzles as follows:

- Close adjustable fan nozzles (a).
- Close upper fan nozzles (b).
- Open lower fan nozzles (c) completely.
- Align the blades of the fan nozzles (c) with the footwell.



Fan nozzles in the roof console



Fan nozzles in the A-pillar

Malfunction and remedy Air conditioning system

DANGER

Incorrect handling of refrigerant may result in death or serious injury.

- If refrigerant penetrates the skin or eyes, have the injury treated immediately by a specialist.

WARNING

Incorrect handling of refrigerant may result in death or serious injury.

- Only have work on the air conditioning systems carried out by a qualified specialist workshop.
- Avoid any contact with refrigerant.
- Wear protective gloves and safety goggles.
- Do not weld on the parts of the refrigerant circuit and in their immediate vicinity.
- Maximum ambient temperature for refrigerant 176 °F(80 °C).

| Fault | Cause, remedy |
|---|---|
| <p>Air conditioning switches off automatically.</p> <p>The warning light on the control element of the air conditioner lights up.</p> | <ul style="list-style-type: none"> • Enormously high outside temperature. <ul style="list-style-type: none"> ➤ Let the system cool down, then switch it on again. Close windows and doors. |
| <p>Air conditioner doesn't cool.</p> <p>Only uncooled air comes out of the fan nozzles.</p> | <ul style="list-style-type: none"> • Magnetic clutch does not engage. <ul style="list-style-type: none"> ➤ Have the coupling replaced. • Belt loose. <ul style="list-style-type: none"> ➤ Tension or replace belt. • Cable connections loose. <ul style="list-style-type: none"> ➤ Fasten interrupted cable connections. • Fuses defective. <ul style="list-style-type: none"> ➤ Replace fuse. • Compressor does not pump refrigerant, expansion valve is frozen. The moisture saturation of the filter drier is reached. <ul style="list-style-type: none"> ➤ Have the filter dryer replaced by qualified personnel. |
| <p>Cooled air flows in from the fan nozzles in the cabin.</p> <p>However, it is not sufficient to cool the cabin sufficiently.</p> | <ul style="list-style-type: none"> • Cabin air filter is soiled. <ul style="list-style-type: none"> ➤ Clean or replace cabin air filter. • Evaporator in cabin roof is soiled. <ul style="list-style-type: none"> ➤ Clean the evaporator. • Evaporator defective. <ul style="list-style-type: none"> ➤ Have the evaporator replaced by qualified personnel. • Condenser in front of the water cooler soiled. <ul style="list-style-type: none"> ➤ Clean the condenser. • Refrigerant level too low. White ball does not float, it is on the bottom. <ul style="list-style-type: none"> ➤ Have the air conditioning system checked by qualified personnel. • Outside air enters the cabin. <ul style="list-style-type: none"> ➤ Close windows and doors fully. |
| <p>Air conditioning brings cool air at times, shortly thereafter warm air again.</p> | <ul style="list-style-type: none"> • Ice formation in the expansion valve. • Filter dryer saturated. <ul style="list-style-type: none"> ➤ Have the filter dryer replaced by qualified personnel. |
| <p>Compressor too loud</p> | <ul style="list-style-type: none"> • Bearing of compressor damaged. <ul style="list-style-type: none"> ➤ Have the compressor replaced or repaired by qualified personnel. To do this, refrigerant must be sucked off and the system must be refilled. • Oil level in compressor too low. Recognizable by external leaks. <ul style="list-style-type: none"> ➤ Have the compressor repaired by qualified personnel. |
| <p>Moisture in the cabin</p> <p>Water drips through the fan nozzles.</p> | <ul style="list-style-type: none"> • Water drainage pipes blocked. <ul style="list-style-type: none"> ➤ Have the water drainage pipes repaired by qualified personnel. |

Error code table

In case of a malfunction of the automatic air conditioning system the display will show an error code.

| Error code | Fault | Cause, Remedy |
|------------|--|---|
| F0 | <ul style="list-style-type: none">• A room temperature sensor error is indicated by the flashing display.• Switching outputs are switched off.• The control unit is no longer ready for operation. | <ul style="list-style-type: none">• Check system for cable break or short-circuit, eliminate if necessary.• Check the correct connection of the temperature sensor and connect if necessary.• The cable of the temperature sensor is marked blue. |
| F1 | <ul style="list-style-type: none">• A blow-out temperature sensor error is indicated by the flashing display.• Switching outputs are switched off.• The control unit is no longer ready for operation. | <ul style="list-style-type: none">• Check system for cable break or short-circuit, eliminate if necessary.• Check the correct connection of the temperature sensor and connect if necessary.• The cable of the temperature sensor is marked yellow. |
| F2 | <ul style="list-style-type: none">• An outside temperature sensor error is indicated by the flashing display.• The control unit is still ready for operation. | <ul style="list-style-type: none">• Check system for cable break or short-circuit, eliminate if necessary.• Check the correct connection of the temperature sensor and connect if necessary.• The cable of the temperature sensor is marked red. |

Running the air conditioner

CAUTION

If the air conditioning system is used after a longer service life, damage to the compressor may occur.

- Before reuse, put the air conditioner into operation according to instructions.

To prevent compressor damage to the air conditioning system, run the air conditioning system regularly.



- Switch on the diesel engine and let it run on idle.
- Open all fan nozzles.
- Open both doors.
- Switch on REHEAT mode (3) to dry the panes. The function light (3) lights. REHEAT drying mode is active. The fan is set to maximum power.
- Set the lowest temperature using the Minus key (5).
- Run machine 5 - 10 minutes in idle speed.

The air conditioner can now be operated again as usual.


Operating terminal

Spraying operation and the vehicle settings are controlled via the terminal in the cabin.

The graphic user interface shows and controls current settings and measuring values of the spraying operation. In addition, vehicle settings can be made and data for road/field operation can be monitored.

- Input and monitoring of data in spraying operation
- Input and monitoring of vehicle data in road and field operation

The ISOBUS-compatible *Topcon X35* or *Touch 1200* terminal is used on the machine.



Other ISOBUS compatible terminals may alternatively also be used. However, this should be discussed with the HORSCH Service before use.

NOTE

- Instructions for operating the terminal are included in the supplied operating instructions!
- Instructions for operating the sprayer software are included in the supplied terminal operating instructions from HORSCH.
- When using an alternative terminal, the respective operating instructions issued by the manufacturer must be followed!


Machine terminal

Current values of the vehicle for road or field operation are displayed on the machine terminal. Settings for the vehicle can only be made via the operating terminal.




Ignition lock

For starting and stopping the engine of the machine.



- 1 Switch off ignition / shut-off diesel engine
- 2 Switch on ignition
- 3 Start diesel engine

Pedal



1 Foot brake pedal

2 Foot pedal

Pressing the switch foot brake pedal (1) brakes the machine.

Pressing the foot pedal (2) sets the machine in motion and accelerates it.

Emergency exit

On the right side of the cabin is the emergency exit of the machine. The door for it can be opened completely or only a gap.

Open door completely

- Pull the lever forward and push the window open. The window can be opened completely.



NOTE

The emergency exit cannot be operated if the machine is equipped with the External Filling Port 3 inches options at the front right next to the cabin. In this case, an emergency hammer is provided in the cabin that can be used to smash the right side window, if necessary.




Emergency hammer

Open door a crack

- Swing the lever up.

The window opens a crack. This position can also be used to ventilate the cabin.



Pull the cord to loosen the sun visor

CAUTION


If the spring mechanism is damaged, the sun visors can no longer be opened.

- If necessary, support the upward movement of the roller blinds by hand, but do not brake them.

Sun visor

In the event of incoming sunlight, undesirable reflections may occur in the window panes. To avoid this, the sun visors can be used.

- Hold the sun visor in the middle and pull down as far as necessary.




Pull the sun visor downwards as far as necessary

- Pull the cord to open the sun visor again. Hold on to the sun visor.

Cabin lighting and reading lamp

The cabin lighting and reading lamp are located on the right side of the roof covering inside the cabin.



The cabin lighting (1) is switched on and off via the switch (3). The lighting can also be switched on and off when the door is opened. When closing the door, the light will stay on for another few seconds.

The movable reading lamp (2) is switched on and off via the switch (4).

Cooling box

The cooling box is located below the instructor's seat.

➤ Switch the cooler on and off with the switch.



Storage compartment with integrated cooling function under the seat area of the instructor's seat.

Storage compartment

There is a document storage compartment under the driver's seat and in the roof console. The lid can be opened by pressing and pulling the snap fastener.



Storage compartment under the driver's seat



Storage compartment in the roof console


NOTE

Do not store any pointed, heavy objects on the floor of the cabin as they may cause the doors or front window to burst.

Do not store any crop protection agent in the cabin.

Camera system

The camera display is located in the cabin on the right side above the machine terminal.



Monitor for cameras in the cabin on the right

WARNING

Do not only use the camera display for manoeuvring! Persons or objects can be overlooked! This may cause severe or even fatal injuries.

- The camera system is an auxiliary tool. It does not replace the attention of the operator for the immediate environment. Use additional means such as mirrors to maintain a complete view of the areas relevant for safety.
- Before manoeuvring, ensure with a direct view that there are no persons or objects in the manoeuvring area!
- The camera inputs carry voltage. No moisture or other metallic objects may enter it.
- No other use of the camera monitor system while driving.

NOTE

Do not open the monitor housing since the function is otherwise no longer ensured. Maintenance and assembly work may only be carried out by qualified personnel.

The machine can optionally be equipped with three cameras. Switching between the rear view camera, the camera for wheelbase monitoring or the camera for spray cone monitoring is possible.

Overview



- 1 Main menu
- 2 Selection button
- 3 Left arrow button
- 4 Right arrow button

Button function with menu deactivated:

- Manual selection of view with the arrow buttons
- Display menu: Briefly press selection button
- Monitor OFF: Press selection button prolonged (3 seconds)
- Monitor ON: Press selection button

Button function with menu activated:

- Navigation with the arrow buttons, selection of a menu item with the selection button
- Change menu items with the arrow buttons, accept values/confirm with the selection button and related return to the next higher menu level



NOTE

The views are primarily activated via the trigger inputs (vehicle signals), where the assignments of triggers and views as well as their priorities are defined in the respective menus. This automatic activation can be bypassed manually at any time, but only until the trigger is activated again. If no trigger is active, the view last selected manually is displayed again. This selection is only cleared again by restarting the device.

Main menu

Display


In the *Display* menu, individual settings can be made for each camera.

- **Brightness:** Adjusting the brightness, numeric value from 0-99
- **Contrast:** Adjusting the contrast, numeric value from 0-99
- **Colour:** Adjusting the brightness, numeric value from 0-99
- **NTSC Tint:** Colour corrections (only for NTSC cameras)

Cameras

In the *Camera* menu, an individual name can be assigned to each camera. It is shown on the image when the respective camera is activated. In addition, the camera image can be mirrored and markings can be shown on the camera image. The position of the markings can be adjusted horizontally and/or vertically and their spacing can be changed.


- **Name:** camera name can be freely defined, e.g. Front
- **Mirroring:** determines for all views whether the camera is mirrored or not
- **Marking:** Showing and positioning of markings in the form of two lines, arranged as travel corridor.



Views / Split and PIP arrangement

The *Split and PIP Arrangement* menu allows determining how the cameras are split and displayed on the monitor.

- **Split:** Configuration of the multiple views
- **PIP arrangement:** Selection of the cameras



Views / Triggers and Priorities

The *Trigger and Priorities* menu allows determining which split display shall be activated with a trigger.

- **Trigger:** Activation condition
- **Priorities:** Ranking of the views

System / Load Settings

The *Load Settings* menu allows loading various predefined and stored settings:

- **Factory setting:** Resets the monitor to the factory setting
- **User-defined:** Reset the monitor to the setting saved by the user

System / Night Settings

The *Night Settings* menu allows adjusting the values for dimming at night.

- **Brightness:** Determines to which value the display shall be dimmed at night (the lower the darker)
- **Limit:** Determines at which ambient brightness the monitor switches from day to night mode. If the limit is set to low, the monitor switches between day and night mode at low ambient brightness. The monitor is always in day mode when setting the limit to 0. The monitor is always in night mode when setting the limit to 99.

Trigger Input Setup

In the *Trigger Input Setup* menu the trigger inputs are adjusted to the connected vehicle signals.

- **active high:** the assigned view is activated when voltage is applied to the trigger input
- **active low:** the assigned view is activated when no voltage is applied to the trigger input

Rear view camera (optional)


The rear view camera is located on the middle section of the folding boom. The rear view camera starts automatically when driving backwards.



Rear view camera in folding boom middle section

Wheel camera (optional)


The wheel camera helps entering the track. The camera is located on the fender of the right front wheel, with view onto the field entry.



Wheel camera on the right front wheel fender

Nozzle camera (optional)


The nozzle camera is used to monitor the spraying cones. The camera is located on the bracket for Night Light cleaning.



Nozzle monitoring camera

Outside rear view mirror


- The outside mirrors can be heated.




Left hand outside mirror and start-up mirror



Right hand outside mirror and start-up mirror



- Turn the switch up, down and to the side until the outside mirror is optimally adjusted:



NOTE

Adjust both drive off mirrors so that the ground area next to the right or left front wheel can be checked before driving off.

Mirror heating

Both outside mirrors can be electrically controlled. The switch is located in the roof console.



Switch for adjusting the outside mirrors

- Turn switch to left or right to select the side of the outside mirror.

Sockets

Cabin sockets

Three 12 V sockets (1 and 2) are located in the cabin to the right behind the driver's seat, below the ignition lock.



Cabin sockets


Two optional USB ports (3) with the outputs DC 5 V 2.1 A and DC 5 V 1.0 A are installed.



USB ports (optional)

Electrical vehicle socket outlets

The vehicle socket outlets are located on the right side of the cabin under the multi-function control panel. To do this, open the lid of the central electrical system.



Vehicle socket outlets (the figure shows emission standard stage 5, machines with emission standard 3a have a different vehicle socket for engine diagnostics (4))

- 1 Vehicle socket outlet for engine OBD diagnostics
- 2 Vehicle socket outlet for vehicle diagnostics
- 3 InCabin Connect - CAN1 ISOBUS
- 4 Vehicle socket outlet for engine diagnostics

NOTE

Do not damage socket outlets by trying to plug in unsuitable plugs!

The cigarette lighter is located on the right rear side of the cabin.



Cigarette lighter

The socket of the cigarette lighter can be used to connect other consumers with a rating of 12 Volt and max. 15 A. This discharges the battery when the engine is stopped. When using optional appliances use the specified plug.


Connected electric accessories must comply with DIN VDE 40 839 with respect to electro-magnetic compatibility.

Central electrical system, top

The fuses on the circuit board are located under the covering in the upper left corner of the cabin.



- Switch off and secure the machine.
- Open the covering of the central electrical system.
- Remove the covering.
- The central electrical system is now freely accessible.




- Then reinsert the lid and lock it.

| No. | Ampe- rage | Function |
|------|---------------|---|
| F001 | 15 A | A/C compressor |
| F002 | 15 A | Maintenance headlights |
| F003 | 7.5 A | Instrument lighting |
| F004 | 7.5 A | Side light left |
| F005 | 7.5 A | Side light right |
| F006 | 15 A | Front windscreen wiper supply |
| F007 | 15 A | Brake light |
| F008 | 10 A | Windscreen wiper left |
| F009 | 15 A | Vehicle lighting control |
| F010 | 15 A | Pathfinder supply |
| F011 | 15 A | Reserve |
| F012 | 15 A | Cabin platform working headlights |
| F013 | 15 A | Stubble lighting |
| F014 | 15 A | Additional driving light |
| F015 | 15 A | Dimmed headlight right |
| F016 | 15 A | Dimmed headlight left |
| F017 | 15 A | High beam left |
| F018 | 15 A | High beam right |
| F019 | 20 A | Working headlight railing left inside |
| F020 | 20 A | Work headlight railing right inside |
| F021 | 20 A | Rear working headlights |
| F022 | 15 A | Working headlight roof left down |
| F023 | 20 A | Working headlight headland left |
| F024 | 20 A | Working headlight headland right |
| F025 | 20 A | Working headlight railing right outside |
| F026 | 20 A | Working headlight railing left outside |
| F027 | 10 A | Windscreen wiper rear |
| F028 | 30 A | Fan supply |
| F029 | 10 A | Mirror supply |
| F030 | 20 A | Rotating beacon relay output |
| F031 | 3 A | Safety switch |
| F032 | 10 A | Radio |
| F033 | 10 A | Windscreen wiper right |

| No. | Ampe- rage | Function |
|------------|---------------|--|
| F034 | 7.5 A | Radio 15 |
| F035 | 15 A | Travel direction indicator |
| F036 | 15 A | Radio 30 |
| F037 | 15 A | Radio 30 |
| X49 | | Fuse test |
| K001 | | Relay high beam |
| K002 | | Relay working headlight railing outside |
| K003 | | Relay maintenance headlight |
| K004 | | Relay Pathfinder |
| K005 | | Relay working headlight rear |
| K006 | | Relay working headlight steering axle |
| K007 | | Relay working headlight headland lighting |
| K008 | | Relay working headlight stubble lighting |
| K009 | | Relay working headlight cabin platform |
| K010 | | unused |
| K011 | | Relay rotating beacon |
| K012 | | Relay brake light |
| K013 | | Relay climate coupling |
| K014 | | Relay driving light |
| K015 D | | Relay ignition |
| K015 DD | | Relay ignition |
| K016 | | Relay additional driving light |
| K017 | | Relay working headlight railing |
| K047 | | Flasher relay USA |
| K048 | | Flasher relay Europe |

Central Electrics (CE) Machine

The fuses on the circuit board are located under the covering to the right of the driver's seat in the cabin.



| No. | Ampe- rage | Function |
|------|---------------|--|
| F048 | 3 A | Terminal 30X time relay main battery switch (BHS) |
| F049 | 15 A | Mirror heating supply |
| F050 | 15 A | Parking brake system supply (FBA) |
| F051 | 10 A | Machine terminal supply terminal 15 |
| F052 | 10 A | ISOBUS terminal supply terminal 15 |
| F053 | 7.5 A | Terminal 15 supply ESX-3XM (HECU) |
| F054 | 3 A | Terminal 15 supply RC20-10/30 Master/Slave |
| F055 | 3 A | Supply charging indicator light; rotary encoder steering wheel |
| F056 | 10 A | Engine control unit supply terminal 15 |

| No. | Ampe- rage | Function |
|------|---------------|-------------------------------------|
| F057 | 10 A | Armrest supply terminal 15 |
| F058 | 10 A | Cool box supply |
| F059 | 15 A | Driver seat supply |
| F060 | 10 A | Roof switch supply |
| F061 | 15 A | ISOBUS ECU-PWR supply |
| F062 | 15 A | GPS-set-up supply terminal 15 |
| F063 | 15 A | Supply PVED-CL |
| F064 | 10 A | Cabin outlets supply |
| F065 | 15 A | Reserve terminal. 15 |
| F066 | 15 A | Reserve terminal. 30 |
| F067 | 10 A | Machine terminal supply terminal 30 |
| F068 | 10 A | ISOBUS terminal supply terminal 30 |
| F069 | 10 A | Armrest supply terminal 30 |
| F070 | 15 A | GPS-set-up supply terminal 30 |

| No. | Ampe- rage | Function |
|------|---------------|---|
| F071 | 15 A | GPS-set-up supply terminal 61R/Field mode |
| F072 | 15 A | Reserve terminal 61R/Field mode |
| F073 | 15 A | 61R/Field mode on CE roof supply |
| F074 | 15 A | Trackfinder left supply |
| F075 | 15 A | Trackfinder right supply |
| F076 | 15 A | Rear working headlights supply |
| F077 | 15 A | Reversing light supply |
| F078 | 15 A | Reserve terminal. 30 |
| F079 | 20 A | Engine sensors supply AGN (via K049) |
| F080 | 20 A | Engine exhaust flap supply (via K049) |
| F081 | 35 A | Performance supply RC20-10/30 Master (travel drive) |
| F082 | 35 A | Hydraulic height adjustment supply (optional) |
| F083 | 7.5 A | Relay amplification supply D+/61 terminal 30 |
| F084 | 10 A | Relay LS-release Start supply |
| F085 | 15 A | Cigarette lighter/ cabin socket supply |
| F086 | 25 A | Cabin socket supply |
| F087 | 7.5 A | Ignition start switch supply ZSS terminal 30 |
| F088 | 5 A | Supply UE+ ESX-3XM (HECU) |
| F089 | 15 A | Performance supply +UB1 ESX-3XM (HECU) |
| F090 | 15 A | Performance supply +UB2 ESX-3XM (HECU) |
| F091 | 15 A | Performance supply +UB3 ESX-3XM (HECU) |
| F092 | 5 A | Electronics supply RC20-10/30 Master (travel drive) |
| F093 | 5 A | Electronics supply RC20-10/30 Slave (suspension) |
| F094 | 15 A | Start relay 5050 supply |
| F095 | 30 A | Engine control unit supply terminal 30 |
| F096 | 35 A | Relay supply ATS K049 (exhaust aftertreatment) |
| F097 | 5 A | Diagnostics plug supply FPT terminal 30 |
| F098 | 15 A | Forced ventilation supply terminal 15 |
| F099 | 15 A | Daytime running light supply |
| F102 | 125 A | Main line supply CE roof |


| No. | Ampe- rage | Function |
|-------------|---------------|--|
| F103 | 100 A | Back-up fuse terminal 30 CE bottom |
| F200 | | Jumper for dimmed headlight diode |
| K015 | | Ignition terminal. 15R |
| K016 | | Engaging the parking brake relay (FBA) |
| K017 | | Parking brake relay (FBA) self-holding |
| K018 | | Parking brake relay (FBA) solenoid valve |
| K020 | | LS relief relay Start |
| K021 | | Relay field/road |
| K022 | | Start interlock relay |
| K023 | | Relay reversing light |
| K024 | | Trackfinder left relay |
| K025 | | Trackfinder right relay |
| K026 | | Working head lights rear |
| K027 | | Relay Reserve 2 |
| K028 | | Relay Reserve 2 |
| K029 | | Daytime running light relay |
| K030 | | Mirror heating relay |
| K031 | | Time relay with drop-off delay main battery switch (BHS) |
| K049 | | ATS relay (sensor supply EDC) |
| K050 | | Starting relay |
| K061 | | Relay Gain D+ |
| P1 Buzzer | | Beeper HECU error |
| P2 Buzzer | | Light warning feature |
| R10 | | Back-up resistor intake air grille heating |
| R11 | | Back-up resistor fuel heating |
| R12 | | Replacement resistor engine warning lamp |
| R54.55 | | Pull down resistors direction indicators |
| R56. 57. 58 | | Pull down resistors forced ventilation settings 1, 2, 3 |
| R59. 60 | | Pull down reserve resistors |

Electrics Battery case

The fuses for the battery case are located behind the cabin under the cover.



ISOBUS Cut-off relay




| Nr. | Strom- stärke | Funktion |
|-----|------------------|-------------|
| 1 | 200 A | Cabin fuse |
| 2 | 60 A | Fuse ISOBUS |
| 3 | 60 A | Reserve |

Electrics Optional


Puls width modulation (optional)

The fuses for the pulse width modulation (PrecisionSpray) are located in the middle section of the boom under the black covers.

- If several nozzles fail simultaneously, check fuses and relays for function and replace them if necessary.



Position fuses pulse width modulation



Fuses and relays Power supply PWM nozzles / PrecisionSpray Boom middle section



Main fuse Power supply PWM nozzles/control unit PrecisionSpray optional (battery case)

HINWEIS

The blue button (2) can be used to release the fuse manually if necessary.


If the main fuse is released, it can be reset by pressing the yellow trigger mechanism (1) back.

Circulating air filter


NOTE

Replace the air recirculation filters every 3600 h.

On the right side in the roof console there is a large circulating air filter.



Two additional air recirculation filters are located on the right and left of the roof console above the driver's seat.



- Remove the air recirculation grille.
- Suck-off, tap or blow out soiled filters on the surface with compressed air.
- Replace damaged filters.
- Reinstall air recirculation grille.

Fresh air filter category 2

NOTE

The activated-carbon filter must be replaced every 3 months, regardless of the operating hours. The pocket filter must be replaced every 6 months.

WARNING


Any maintenance work on the filter system must only be carried out with the engine shut down. Pay attention to possibly contaminated dust in the filter. Do not inhale it and avoid skin contact. Do not blow out or suction out the filter. Dispose of filter dusts properly.

An activated-carbon filter is located on the left side of the machine in the upper outside area of the cabin. This filter protects the vehicle driver inside the cabin against dust and suspended contaminants outside the cabin.



Activated-carbon filter position

Commissioning



- 1 Activated carbon plates
- 2 Activated carbon grilles

The activated carbon plates are shipped packaged. Unpack only shortly before installation!

- Open the covering on the cabin roof at the left. If necessary, the covering is secured with a transport screw. This It must be removed the first time it is opened and is not required for normal use.
- Remove the pocket filters.
- Insert two activated carbon plates each in a filter grille.



- Introduce the grilles with the activated-carbon filters into the pocket filters.



- Attach the pocket filters with the activated-carbon filters again.
- Close the covering.



Activated-carbon filter with pocket filter

WARNING

If the air filter is incorrectly installed or defective, dust and fine dust from the placed crop protection agent will enter the cabin. These are inhaled and cause damage to health.

- Make sure the filter is tightly seated.
- Replace defective air filter immediately.

- Open the covering to clean, replace or check.
- Unlock and remove the filter.
- Suck-off, tap or blow out soiled filters on the surface with compressed air.
- Damaged filters and sealing profiles must be replaced.
- Insert the filter.
- Close the covering again.

NOTE

In case of inadequate maintenance, the filter will become extremely contaminated and must be changed.

Clean / change air filter

Carry out checks and filter changes only outside the contaminated area and with the ignition deactivated. Wear gloves.

- Disconnect the central plug from the housing to interrupt the power supply.
- After removing the used filters, clean the housing with a damp cloth.
- Check housing and seals for damage.
- Insert new filters.
- Ensure that the inserted filter is securely seated to ensure complete sealing.
- Ensure that the housing cover is securely seated.
- Make sure that the order of the filter elements is observed.
- After changing the filters, operate the cabin air filters at the lowest setting.

Cabin air filters category 4 (optional)

NOTE

Standard air filtering category 2 is obsolete if the machine is equipped with the option cabin air filtering category 4. Instead of the pocket filters and activated-carbon filters, closing coverings are installed on the cabin roof.

The filter system serves to protect the operator in the cabin from air pollution. The ambient air is cleaned by one or more filter stages and freed from dust, aerosols or gases. The filter system has an integrated fan which transports the filtered fresh air into the cabin. At the same time, a certain overpressure is generated in the cabin.

The filter system can optionally be mounted as category 3 (without activated-carbon filter) or category 4 (with activated-carbon filter). If the filtration is to pass as category 3 only, the activated-carbon filter must be removed and the empty frame installed.

WARNING

Any maintenance work on the filter system must only be carried out with the engine shut down. Pay attention to possibly contaminated dust in the filter. Do not inhale it and avoid skin contact. Do not blow out or suction out the filter. Dispose of filter dusts properly.

CAUTION


Safety risk from wrong spare parts!
Wrong spare parts may affect the safety and function of the filter system and cause damages.

- Check the spare parts before installation
- Use only original spare parts of the manufacturer

NOTE

To generate adequate overpressure in the cabin, the default ventilation must also be activated when selecting Cat 4 filtering! The fan speed of the default ventilation must be increased in the event of inadequate cabin overpressure. Refer to the section *Air conditioning / Heater*.

Overview



The arrow indicates the flow direction.



- 1 Activated-carbon filter
- 2 Aerosol filters
- 3 Dust filter
- 4 Empty frame

The arrow indicates the flow direction



Activated-carbon filter (shipped packaged, unpack before installation!)



Aerosol filters



Dust filter



Empty frame

Maintenance

NOTE

The activated-carbon filter must be replaced every 3 months, regardless of the operating hours.

The dust filter and aerosol filter must be replaced after 6 months.

Clean filter system

- Do not use high-pressure cleaners to clean the inside of the filter box to prevent damage to the filter elements, fan and electronic components.
- Do not use high pressure cleaners to clean areas with stickers on them.


Perform visual check of the filter system

- Check air ducts for leaks and damages.
- Check cable routing for chafing.
- Repair any damages to the paint coat or any corrosion that has been detected professionally.
- Deactivate the filter system if damages such as cracks can be detected and contact the sales partner.

Replace the filter


- Make sure that the machine is outside the contaminated area.
- Switch off the ignition.
- Clean the filter box.

- Release the catch (3) of the plug (1).
- Pull off the plug (1) from the filter box (2) to interrupt the power supply.




Remove the filter

- Unlock the snap locks (1) and open the lid (2) of the filter box.



- Depending on the maintenance interval, remove the filter in the order dust filter (3) aerosol filter (2), activated-carbon filter (1).
- Clean the housing with a moist cloth.
- Check housing and seals for damage.




Install the filter




WARNING

Entry of toxic substances into the cabin due to fitting the filter box with wrong inserts. Risk of poisoning!


- Make sure that the inserts fitted into the filter box meet the cabin category on the identification.
- Adapt the identification of the cabin category when modifying the filter system.
- Insert new filters in the activated-carbon filter (1) aerosol filter (2), dust filter (3). Make sure the seal of the filters points upward.
- Ensure that the filters are seated securely.



- Close the lid (2) of the filter box and lock the snap locks (1).



- Connect the supply plug (1) to the filter box (2).
- Close the catch (3) of the plug.



- After having changed the filters, operate the cabin ventilation on the lowest fan setting.

Decommissioning and disposal


Once the product or its components reach the end of their useful life, the components must be disposed of properly. The regulations of the responsible local authorities must be observed.

The operating materials and contaminated filters require special disposal and must not be released into the environment. Further information regarding disposal can be obtained from the responsible local authority, the qualified specialist workshop or the sales partner.

- Do not dispose of products with the symbol (1) in household waste at the end of their useful life.



- Recycle used materials with the symbol (2) according to their identification.



- Recycle and reuse packaging materials and do not throw away with household waste.
- Recycle, reuse and dispose of plastics marked with the material designation, such as PP TV 20, and do not throw them in the household waste.
- Sort and recycle used metals according to type, recycle them and do not throw them in the household waste.
- Dispose of electrical and electronic components properly or hand them in at a collection point. Do not throw electrical and electronic components in the household waste.
- After using the filter elements with pesticides or similar agents, refer to the safety data sheets and disposal regulations of the respective manufacturers.
- Observe the regulations of the responsible local authorities.

Pressure monitoring

A system for pressure monitoring is installed in the cabin.


If the internal cabin pressure drops below the pressure required for category 4 cabin filters, the warning lamp on the roof console lights up at the right.



Cabin air filtration pressure monitoring

Pressure monitoring is controlled on the machine terminal:

- Select *Cabin Filter Cat. 4 Settings* in the *Vehicle Settings* submenu.
- The internal cabin pressure can be set automatically or manually.




Cabin Filter Category 4 Settings

Radio

The radio is installed in the centre of the roof console.



Overview




- 1 Switching on/off / Selecting the source / Rejecting or ending calls
- 2 Select radio frequency range / answering calls
- 3 Volume knob
- 4 Open the software menu
- 5 next radio station /audio track / fast forward
- 6 previous radio station/audio track/rewind
- 7 Play/Pause with media files
- 8 Stop with media files
- 9 Repeat for media files
- 10 Shuffle media files
- 11 navigate to the previous folder for media files
- 12 navigate to the next folder for media files
- 7 - 12 stations stored in radio mode

On / Off




Briefly press the power button to turn on the unit. Press and hold the power button for one second to turn it off.

Multi-mode buttons




In radio mode, stations can be stored here. In media mode (USB or SD card), playback can be controlled here.

Volume knob




Turn the knob to adjust the volume. Pressing the volume button briefly accesses the audio menu items *Balance*, *Fader*, *Bass* and *Treble*. In the menu, the volume knob is used to navigate to the individual points.

Station scan



Use the arrow keys to search for radio stations. Short pressing automatically searches for the next available frequency. Press and hold the button to start the manual station search. The radio will return to automatic station scanning if no button is pressed for 3 seconds.


Saving the radio station



Press and hold one of the preset buttons to store the currently set station. A stored station can be called up by briefly pressing one of the keys. A stored station can be overwritten at any time by setting another station.

The Radio Data System (RDS) is available for many stations. RDS functions such as *AF* (Alternative Frequency), *TP* (Traffic Program) or *TA* (Traffic Announcement) can be activated or deactivated. RDS is only available in the FM frequency range.


Playing media files



Music files on a USB stick or SD card can be played by connecting them to the appropriate slot on the device. If data carriers are connected, they are automatically played back. The *SRC* button allows selecting between *Radio*, *Media* or *AUX*. If media is connected to both slots, the last slot played is played back.

Use the *left* and *right* arrow keys to scroll through the individual music files. The *F+* and *F-* keys can be used to jump to the previous or next folder.

Software menu




The menu is called up by briefly pressing the button to the right of the volume knob. On access, the display shows available menu items. The *Reset-confirm* entry is used to restore the default settings.

- The menu key can be used to navigate up one level in the menu. Alternatively, this can be done using the left arrow key.
- Turn the volume knob to navigate to the next or previous point.
- Press the volume knob briefly to access a menu item. Settings can be confirmed there. Also, navigating one level in the menu is possible. Alternatively, this can be done using the right arrow key.

Press and hold the menu key to exit the software menu.

Bluetooth



To use the Bluetooth hands-free function, a mobile phone must be paired with the radio. To pair the mobile phone with the radio, it must be switched on. Search the phone for the available Bluetooth device. Pairing is done by means of the passcodes 1234 or the respective code displayed on the mobile phone. The successful pairing is then displayed on the mobile phone. After successful pairing, most mobile phones can automatically re-establish the Bluetooth connection the next time the radio is switched on.

Calls can be accepted via the button with the green telephone handset. Calls can be ended or rejected using the button with the red handset. An internal microphone is integrated in the radio. Prolonged pressing of the button with the green handset activates a new dialling of the last number.



NOTE

Any other information as well as settings can be found in the supplied instruction manual for the radio.

Engine operation

Before starting the motor

WARNING

- Always make sure that there are no persons in the working range of the machine. Blow the horn if necessary.
- Never run the engine inside closed rooms without fume extraction system.
- Ensure sufficient ventilation.

Requirements for motor start




Main switch for electric power supply

The main battery switch for the power supply is located at the right side in the direction of travel behind the cabin.

- Switch on the main switch for the electric power supply

Switch on ignition

The ignition lock has 3 positions:



- 1 Switch off ignition / shut-off diesel engine
- 2 Switch on ignition
- 3 Start diesel engine

Start the engine

NOTE

Start the engine only from the driver's seat.

- Turn the ignition key to position (3) and hold it until the engine starts.
- Release the key as soon as the engine is running. Never hold the key longer than 20 seconds in starting position (3).

NOTE

When the ignition key is returned to position (2) before the engine is started, wait with the next starting attempt until the engine has come to a stop. In this case turn the ignition key first to position (1) and then repeat the attempt.

Shut down the engine



NOTE

For engines with exhaust stages 5, the main battery switch must not be switched off immediately after switching off the engine. Switching it off too early may cause an error message of the engine. Only after a time of approx. 15 minutes may the AdBlue system be switched on in order to ensure safe operation of the AdBlue system. Only use immediate shut-down in an emergency!



NOTE

Before parking the machine allow the engine to run 1 - 2 minutes at low speed range so that all important engine parts can cool down.

- Each time the engine stops the hand brake is automatically applied!



NOTE

Shut off the engine only from the driver's seat.

- Turn the ignition key to position (1).

Travel operation

General notes

WARNING

Danger to life or severe injury by losing control over the vehicle!

- In case of a warning message (red) on the terminal, stop the machine and eliminate the fault. Should this not be possible, contact HORSCH Service or the authorized dealer.
- Attention! Vehicle swings out when cornering.
- Due to the vehicle dimensions, the driving characteristics of the machine demand certain training.
- You should never store any objects in the area of the pedals, so that full pedal travel is ensured at all times.
- Always match the travel speed of the machine on the road and in the field to the prevailing conditions.
- Reduce the travel speed when driving down-hill. Do not exceed the permissible angles of incline. Refer to the section *Use on hillside locations*.
- In downward sloping terrain or smooth ground the vehicle may be lifted off by the transported load when braking.

Forward / reverse driving

NOTE

The driver can switch between pedal and drive lever at any time. This change takes place fully automatically.

Forward driving

Driving via foot pedal

After starting the engine, the travel drive is in neutral position.

- Release the parking brake via the switch at the right-hand side on the roof console.




Parking brake

- Turn the direction of travel switch on the multi-function armrest forward.



Switch for direction of travel selection


- Press the foot pedal to start moving and accelerating the machine.
- Change the speed by adjusting the foot pedal.



Pedal

Driving via drive lever

- Press and hold the release button on the rear of the drive lever.



Drive lever release button

- Move the drive lever forward to select the direction of travel and set the machine in motion.



Drive lever

- The drive lever returns to middle position when released. The speed remains constant.
- Move the drive lever forward to accelerate the machine further.
- Pull the drive lever back to brake the machine. The machine decelerates till stopped.

Reverse driving

Driving via foot pedal

After starting the engine, the travel drive is in neutral position.

- Release the parking brake via the switch at the right-hand side on the roof console.




Parking brake

- Turn the direction of travel switch on the multi-function armrest backward.



Switch for direction of travel selection


- Press the foot pedal to start moving and accelerating the machine.
- Change the speed by adjusting the foot pedal.



Pedal

Driving via drive lever

- Press and hold the release button on the rear of the drive lever.



Drive lever release button

- Move the drive lever toward the back to select the direction of travel and set the machine in motion.



Drive lever

- The drive lever returns to middle position when released. The speed remains constant.
- Move the drive lever backward to accelerate the machine further.
- Move the drive lever forward to decelerate the machine. The machine decelerates till stopped.



NOTE

The following applies for forward and backward travel:

- When the foot pedal is pressed, the pedal takes over the specified speed. When the drive lever is actuated, it will take over the specified speed.

Reverse direction of travel

The direction of travel can be reversed by pressing the release button and simultaneously moving the driving lever to the left. This means that the vehicle will not stop at 0 mph (0 km/h), but will automatically change the direction of travel.



Drive lever

With manual steering, the rear axle is steered by moving the drive lever to the left or right. Reversing and headland management are then no longer possible.

Brakes

Parking brake

Always release the parking brake before setting of on road travel or before starting in the field. Travel operation with the parking brake applied is not possible!

The release switch for the parking brake is located at the right hand side of the roof console.

- To release the parking brake, actuate the console switch.

NOTE

The parking brake can be engaged at any time while driving. It can also be used for emergency braking.



Parking brake

The current status of the parking brake is displayed on the machine terminal.



- Red: Parking brake engaged
- Grey: Parking brake released

Service brake

WARNING

Danger to life or severe injury by losing control over the vehicle! Check the function of the service brake each time before setting off!

- Release foot pedal.
- Press the brake pedal to decelerate or brake the vehicle.



Pedal

NOTE

Maintain the required safety distances depending on load and speed!

Drive slippage control

The self-propelled machine comes with fully automatic drive slippage control (ASR).


NOTE

Manual intervention in difficult terrain is not required!

Travel modes

With the self-propelled crop protection sprayer one differentiates between two different travel modes. Switching between road travel and field mode is possible.

- Switching to the desired travel mode is done via the console switch on the right-hand side of the roof console. It may take some time after switching until the machine has reached all states (suspension up/down, etc.).



On the machine terminal, the current driving mode can be seen from the surface.

Road operation


Rear axle steering can be activated when driving under 9 mph (15 km/h). The rear axle centres above 9 mph (15 km/h), and axle steering is deactivated automatically. When driving slower again than 9 mph (15 km/h), the driver must reactivate rear axle steering.

Field mode

When field mode is activated, rear axle steering can be switched on and off using the *Rear axle steering on/off* key.



The current status of the rear axle steering is displayed on the terminal.



- Pressing the *Rear axle steering on/off* button activates rear axle steering.
- Pressing the *Rear axle steering on/off* button again deactivates rear axle steering again.
- With travel speeds of less than 3 mph (5 km/h) the *button Rear axle steering on/off* must be pressed and held until the rear axle has reached its target position.
This serves as a safety control to avoid personnel damage.
- The *Manual on/off* button can be used to activate/deactivate steering for the manual mode.

- The *Rear axle steering slope mode on/off* button can be used to activate/deactivate steering for the slope mode.
- A manual correction for drift on the slope can be made on the rotary wheel. This has a proportional influence on the rear axle steering.



Manual correction for drift on a slope

Cruise control

WARNING

Danger of accident caused by improper operation of the cruise control function! Drive assistance systems have been developed to support the driver. However, they cannot replace his awareness!

When driving the vehicle, the driver takes on full responsibility and must always pay attention to the current traffic situation!

Cruise control settings can be made and changed through the terminal or with the drive lever on the multi-function control unit.

NOTE

Two speeds can be set and saved both in road mode and in field mode.

Setting via the drive lever

- Accelerate to the desired speed.
- Press and hold button until an audible signal sounds. The desired speed for cruise control 1 has thereby been saved.
- The procedure for cruise control 2 is identical.



- The currently set cruise control is displayed on the terminal.
- Quit the cruise control setting by braking, actuating the foot pedal or drive lever.

Setting via the terminal

- Select the button on the terminal and save the desired speeds.
- Activate the cruise control using the buttons on the control lever.
- Quit the cruise control setting by braking, actuating the foot pedal or drive lever.

Road / field travel

NOTE

When driving on roads / in the field, the chapter *Safety notes* must also be observed!

Check before road / field travel:

- the light system for damage, function and cleanliness.
- the brake and hydraulic system for apparent defects.
- the function of the brake system.
- the overall machine for cleanliness.

WARNING

Danger of crushing, shearing, cutting, cutting off, being caught, wound up, pulled in and impact by accidental movements of the machine.

- Check the folding devices of the machine for correct locking of the transport locks.
- Secure the machine against accidental movements before starting road / field travel.

WARNING

Danger of crushing, cutting, being caught, being pulled in and impact due to insufficient stability and tipping over.

- Adjust the personal travel mode in such a way that you will at any time have control over the vehicle.

Be aware of your own abilities, account for the road, traffic, sight and weather conditions as well as the driving characteristics of the machine!

WARNING

Danger of falling off the machine in case of impermissible transport ride!

It is not allowed to ride on the machine as a passenger and/or to climb on machines in operation. Direct persons out of the danger zone before starting the machine.

WARNING

Danger of damage due to inadequate stability and inadequate steering and braking ability of the machine if used for purposes other than those intended!

- These hazards cause severe or even fatal injuries.
- Pay attention to the maximum payload and the permissible axle loads of the machine.
- Observe the total weight of the machine.
- If necessary drive with the tank only partly filled.

CAUTION

- In order to maintain a sufficient safety distance to overhead lines, the total height of the machine must not exceed 13 ft (4 m).
- When driving or towing on public roads you must comply with the national traffic regulations.

Towing

DANGER


Danger of severe injuries caused by the machine rolling away! Always use the wheel chocks provided when the machine is stopped!

The vehicle can be towed by four towing eyes on the frame.

These are located at the front and the rear on the axles.




Towing eye shown at front left is identical with right



Rear towing eyes

- Before towing drain the spraying mixture container by pumping it over.
- Operate the hand pump to release the parking brake. Refer to the section *Releasing the parking brake*.
- Maximum permissible towing speed: 3 mph (5 km/h).
- The vehicle must not be towed more than 1.2 mi (2 km) to the next parking opportunity!
- The diesel engine must be running throughout the towing process, so that steering system and service brake are fully functional.

- With the engine stopped no braking effect can be guaranteed and the steering is very hard to move in the emergency steering mode. Towing must in any case be performed only with the help of a towbar.
- Three-point hitching should in any case be used for towing.



Example of three-point hitching

Remote start / jump start

The self-propelled crop protection sprayer has one 12 Volt electrical system.

CAUTION

Danger of explosion caused by inappropriate charging processes with jump leads or battery chargers! Avoid contacting the battery acid with skin and textiles, avoid eye contact!

The following notes must strictly be followed and complied with when starting the vehicle from an assisting source!

- Avoid the creation of sparks or naked flames in the vicinity of batteries.
- When handling batteries wear eye protection and protective clothing.
- Use a booster battery with the same voltage. Its capacity (Ah) should not be considerably lower than the capacity of the discharged vehicle battery.
- Do not disconnect the discharged battery from the vehicle network.
- Defrost a frozen battery before connecting the jump leads (see chapter *Safety*).
- Switch off unnecessary consumers.
- Never lean over the battery during this process.
- In case of assist starting, the vehicles must not touch each other.

- The pole clamps of the individual cables must never come into contact with one another.
- For starting assist you must first connect the positive cable with the positive pole on the external battery and then with positive pole on the discharged battery. Then connect the negative cable with the negative pole on the external battery and the end of the negative cable with a earth contact point on the vehicle.
- When coupling the positive terminals and connecting the negative terminal of the assisting battery to the frame of the vehicle, the engine should be switched off on both vehicles.
- When starting from a different source, first switch on the assisting vehicle and then the receiving vehicle. It is recommended that the lighting be switched on for the receiving vehicle to protect the electronics from overvoltage.
- After successful starting disconnect the cables in reverse order.

If the batteries of the 12 Volt vehicle electrical system are discharged, recharge them by running the engine after remote starting.

If the battery has been discharged and no work is due on the machine which necessarily requires the engine to run, the battery can be charged with the aid of a battery charger.

CAUTION

Do not charge via jump starting! This may cause the battery to explode.




NOTE

The battery must be serviced in accordance with the battery manufacturer's specifications.

Machine terminal

Current values of the vehicle for road or field operation are displayed on the machine terminal.



Machine terminal in the cabin

Operation

The machine terminal is operated via the rotary pushbutton knob and the buttons on the multi-function control panel.



- Turn the knob to navigate to the individual symbols. There the values can be changed in the submenu.
- A function can be selected by pressing the rotary knob.
- Press the ESC key to return to the main screen.

Road mode

The following screen is displayed for road operation.




- 1 Rotational speed display
- 2 Speed display
- 3 Target speed


When a speed is specified using the drive lever / foot pedal, the red dot indicates the target speed and the speedometer the actual speed.

Field mode

The following screen is displayed for field operation.



- 4 Suspension in field mode setting
- 5 Cruise control setting
- 6 Headland management setting
- 7 Vehicle settings
- 8 Display info/settings
- 9 Engine revolutions per minute
- 10 Current speed
- 11 Cruise control 2 speed
- 12 Cruise control 1 speed
- 13 Steering angle front axle bar graph
- 14 Steering angle rear axle bar graph
- 15 Hydraulic pressure currently applied to wheel
- 16 Height of the wheel



- 17 Hydraulics temperature
- 18 Hydraulic pressure of the travel drive
- 19 Air pressure
- 20 Engine utilisation
- 21 Engine temperature
- 22 Fuel consumption
- 23 Level of AdBlue tank
- 24 Filling level of fuel tank
- 25 Status of access ladder
- 26 Speed setting (foot pedal or drive lever)
- 27 Driver seat switch
- 28 Status of parking brake
- 29 Display of direction of travel
- 30 Time
- 31 Date
- 32 Outside temperature
- 33 operating hours
- 34 Warning messages




Warning message – diesel containing water (example)

NOTE

For a list of all warning messages and for the operation of the machine software, refer to the corresponding terminal operating manual with the respective software version.

Construction

Overview



- 1 Spraying mixture container
- 2 Dome spraying mixture container
- 3 Fresh water tanks left and right
- 4 Hand washing tank
- 5 Spraying pump
- 6 Centrifugal pump for cleaning, optional
- 7 Swivelling illuviation valve
- 8 Agitator
- 9 External control terminal
- 10 Filling connections
- 11 Storage compartment (right and left machine side)
- 12 Maintenance access
- 13 Outside cleaning right side of machine (optional)
- 14 Folding boom

 **DANGER**

Danger of serious accidents

Transport rides on the machine, especially the steps or maintenance access, are prohibited!

Superstructure components

Spraying mixture container

WARNING

Danger of poisoning - Do not climb into the spraying mixture container!

- Only approved technical personnel may enter the spraying mixture container.
- Before entering the spraying mixture container, it must have been completely drained and cleaned with the cleaning agents specified by the spraying agent manufacturer.
- Comply with the national regulations and laws for work in tight spaces!

WARNING

Danger of falling off when climbing on the spraying mixture container!

- Do not climb on the spraying mixture container.

The spraying mixture container is designed to retain water, spraying agents and fertilisers. With the aeration and venting system, the spraying mixture container is aerated during spraying and vented during filling.

The internal cleaning nozzles clean the spraying mixture container with fresh water after the spraying process.

The agitator mixes the spraying mixture inside the spraying mixture container and ensures a homogeneous mixture.

The current contents of the spraying mixture container can be read via the control terminal in the cabin and the external control terminal.

Access steps

The dome of the spraying mixture container is accessible via the swivelling access ladder and the maintenance access.

The access ladder is lowered or raised from the driver's cabin. The railing must be folded up when working when the folding boom is unfolded.



Ascent to maintenance access

- When climbing on the maintenance access always maintain contact on at least 3 points (hands or feet) of the access steps.

WARNING

Risk of crushing when folding the access ladder.


- Never reach into the crushing area of the ladder.

Maintenance access

DANGER


Severe accident by falling down!

- No passengers are allowed to ride on the machine!
- When climbing on the maintenance access always maintain contact on at least 3 points (hands or feet) of the access steps.



Maintenance access

The dome is fitted with a sieve to prevent the ingress of impurities when the spraying mixture container is filled via the dome.



- 1 Dome cleaning nozzle
- 2 Folding boom circulation return
- 3 Pressure filter return
- 4 Dome screen

NOTE

The dome screen must be checked daily and cleaned as necessary!
A cleaning nozzle is installed to facilitate cleaning of the dome screen.

Dome

DANGER

- Danger of injury by poisonous vapours! Do not climb into the spraying mixture container!



Dome

Fresh water tank

The fresh water tanks serve to retain fresh water. The capacity is 200 gal lqd (750 litres). It is used for:


- dilution of residual quantity in the spraying mixture container.
- cleaning (rinsing) the entire crop protection sprayer.
- cleaning the suction fitting as well as the spraying lines with the tank filled.
- Outside cleaning of the machine.



Fresh water tank left and right on the machine


The current contents of the fresh water tank can be read via the control terminal in the cabin and the external control terminal (only with Basic Pro and CCS Pro).

The filling port is located to the left of the illuviation valve.



Filling port (Basic shown, other water systems identical)

The tank lid with ventilation for the fresh water tank is located at the top side.



Ventilation

WARNING

Danger of accident when performing repair work on the fresh water tank! Open the maintenance opening only for maintenance work and by trained personnel.

Hand washing tank

The hand washing tank is designed to retain clear water.

WARNING

Danger or poisoning by contaminated water in the hand washing tank!

Do not use the water in the hand washing tank as drinking water!

The hand washing tank is located on the left-hand side of the machine on the maintenance access.



Hand washing tank

The drain valve of the hand washing tank is located on the left-hand side of the access ladder.



Drain for hand washing tank


A soap dispenser for cleaning the hands is located to the right of the access ladder under the first step to the maintenance access.



Soap dispenser

Spraying pump

The crop protection sprayer is equipped with a centrifugal pump for the spraying system. This is located behind the illumination valve. The pump is hydraulically driven via a proportional valve and adjusts to the required quantities.



Spraying pump (Basic shown, other water systems identical)

The pump used does not require pulsation damping, because centrifugal pumps generate continuous flow and pressure.

- The spraying pump installed in this machine is nearly maintenance-free!
- The spraying pump is not equipped with dry running protection and may therefore be operated only temporarily without fluid!

NOTE

Fill the pump with fluid before initial commissioning and after each draining before switching on.

Technical data:

| | |
|--|--------------------|
| Type | Hypro 9316C3U-M10 |
| Flow rate in gal/min (l/min) at 0 psi (bar) | approx. 220 (1000) |
| Flow rate in gal/min (l/min) at 72 psi (5 bar) | approx. 120 (550) |
| Maximum pressure in psi (bar) | 116 (8) |

The pump has a cavity with sealing fluid as dry running protection and for cooling.

➤ Check the liquid sealant level annually.


NOTE

Slight leaks may occur initially with new spraying pumps. Slight formation of oil drops on the pump housing may occur until the mechanical seal has been broken in.

Check the oil level of the pump regularly and top it up if necessary.

Centrifugal pump for cleaning

The centrifugal pump (1) is located behind the filling port.



1 Centrifugal pump (Basic shown, other water systems identical)

Functions of the pump:


- Draws in fresh water during continuous inside cleaning (CCS).

| Technical data: | |
|---|------------------|
| Type | Hypro 9302C |
| Flow rate in gal/min (l/min) at 0 psi (bar) | approx. 48 (220) |

Illuviation valve


The pivotable illuviation valve is used to pour in, dilute and draw in crop protection agents and carbonyl diamide.

The illuviation valve can be swivelled to the working and transport position with the handle.




Illuviation valve with stainless steel funnel and folding rest

- 1 Hinged lid
- 2 Handle to swing the illuviation valve
- 3 Parallelogram arm for swivelling the illuviation valve to the working and transport position
- 4 Switching fitting for canister flushing / closed circuit flushing / shock nozzle and washing gun
- 5 Switch-over ball valve for sucking-off and external filling devices



- 6 Connection external filling devices
- 7 Washing gun
- 8 Activate/deactivate the canister flushing

- 9 Activate/deactivate the washing gun
- 10 Activate/deactivate the shock nozzles
 - The shock nozzles support the illuviation of difficult to dissolve crop protection agents.
 - Two rinsing nozzles and the shock nozzles in the lower area of the Illuviation valve are activated.
- 11 Activate/deactivate the washing nozzles




- 12 Filling level gauge
- 13 Suction opening
- 14 Rinsing nozzles for dilution and illuviation of crop protection agents
- 15 Shock nozzles for dilution and illuviation of crop protection agents
- 16 Pressure plate
- 17 Rotating canister flushing nozzle to flush out canisters or other containers

NOTE

Depending on the position of the ball valve of the suction side, water exits from the fresh water tank or spraying mixture from the spraying mixture container on the canister flushing. Activate canister flushing to this end (8) and push the pressure plate (16) down. Water or spraying mixture exits at the rinsing nozzle (17).

Washing gun

The illuviation valve can be cleaned after filling with the washing gun. Apart from this, deposited residues can be flushed out of the canisters.



Washing gun

- To fix the handle actuation press the button (18) during operation.
- Press the handle to release.
- After switching off (9) relieve the residual pressure.

NOTE

Depending on the position of the ball valve of the suction side, water exits from the fresh water tank or spraying mixture from the spraying mixture container on the washing gun. Activate the washing gun to this end (9) and clean the illuviation valve.

Retaining clip for metering cup

The retaining clip serves for a safe and firm stand of the metering cup.

- Fold down the retaining clip.
- Place the metering cup inside in order to be able to meter the crop protection agent in it.



Retainig clip


Basic/CCS agitator

The spraying mixture container is equipped with a hydraulic agitator. Special injector nozzles in the agitator tube reinforce the stirring intensity. The switched-on agitator mixes the spraying mixture inside the spraying mixture container and thus generates a homogeneous mixture.

The agitator can be set to circulation/spraying/stirring (2) via the pressure side switch-over ball valve (1).

The intensity of the agitator is adjusted via the valve (3).

In addition, the spraying mixture can be kept homogeneously during circulating / spraying and road travel.



Agitator position


To minimise the residual quantity in the spraying mixture container, the agitator can also be completely disabled.

Agitator Basic Pro/CCS Pro

The spraying mixture container is equipped with a hydraulic agitator. Special injector nozzles in the agitator tube reinforce the stirring intensity. The switched-on agitator mixes the spraying mixture inside the spraying mixture container and thus generates a homogeneous mixture.

The agitator can be operated via the external control panel or the main terminal.

The intensity of acceleration can thus be set. In addition, the spraying mixture can be kept homogeneously during circulating / spraying and road travel.



External control panel

To minimise the residual quantity in the spraying mixture container, the agitator can also be completely disabled.

Filter

NOTE

Use all specified filters of the filter equipment. Clean the filters at regular intervals.

Trouble-free operation of the crop protection sprayer is only ensured with flawless filtration of the spraying mixture. Appropriate filtering considerably influences the treatment success of the crop protection measure.

Pay attention to the permissible filter combinations or mesh sizes. The mesh size of self-cleaning pressure filters must always be smaller than the nozzle opening of the nozzles used.


Please note that the use of pressure filter elements with 80 or 100 meshes/inch² may cause the separation of biocatalysts with some crop protection agents.

Follow the notes of the crop protection agent manufacturers.

Pressure filter

The pressure filter prevents contaminants from entering into the nozzle line. Different degrees of fineness are available to suit each application. The filter is fitted with an 80 meshes/square inch element as standard.

In case of applications with liquid fertiliser or when using larger nozzles it is recommended to use coarser elements in order to keep the pressure drop in the filter as low as possible.



1 Pressure filter

The self-cleaning pressure filter prevents blocking of the nozzle filters in front of the spray nozzles.


Electrical pressure filter flushing option:

When the *spraying main switch* is off in circulation mode, the inner surface of the pressure filter element is continuously flushed. Undissolved spraying agent and dirt particles are caught in the dome screen when the spraying mixture is returned to the spraying mixture container.

Mechanical pressure filter flushing option:

Depending on the valve's (1) intensity setting, the inner surface of the pressure filter element

is continuously flushed. Undissolved spraying agent and dirt particles are caught in the dome screen when the spraying mixture is returned to the spraying mixture container.



1 Pressure filter flushing intensity



NOTE

In the event the placing quantity can no longer be reached, the intensity can be reduced to correct this problem.


Auxiliary pressure filter

An additional pressure filter is installed on the centre piece of the folding boom.

With certain spraying agent combinations, it can happen that due to chemical reactions flocks form in the long lines and clog the nozzles. The auxiliary pressure filter shortens the line lengths between filter and nozzle and thus prevents flocculation.

If the first pressure filter is defective, for example due to excessive water pressure, the auxiliary pressure filter can be used to retain the dirt from the nozzles.

The pressure filter is equipped with 80 meshes/inch² insert as standard. Depending on the use, additional filter inserts with 50 or 100 meshes/inch² insert are available.



- 1 Auxiliary pressure filter
- 2 Shut-off lever
- 3 Pressure filter backwash
- 4 Drain valve

Clean the auxiliary pressure filter as needed. Lower the parallelogram for this purpose. Turn the lever (2) by 90° to thus block the flow to the pressure filter. Close the valve (3) to block the return line and thus preventing a return flow. Open the valve (4) and collect any draining agent. Dispose of the agent if necessary or return it to the spraying mixture container. Open the filter housing with the pressure filter wrench. Clean the auxiliary pressure filter.

Repeat all steps in the opposite order after cleaning.

Mechanical pressure filter flushing option:

Depending on the valve's (3) intensity setting, the inner surface of the pressure filter element is continuously flushed. Undissolved spraying agent and dirt particles are caught in the dome screen when the spraying mixture is returned to the spraying mixture container.



NOTE

In the event the placing quantity can no longer be reached, the intensity can be reduced to correct this problem.

Dome screen

The dome screen prevents contaminants from entering into the spraying mixture container during filling through the dome. Likewise, contaminants are retained in the spraying mixture container during circulation and pressure filter flushing. The screen has a standard mesh size of 0.04 in. (1 mm). The dome screen must be checked daily and cleaned as necessary! A cleaning nozzle is installed to facilitate cleaning of the dome screen.

Suction filter

The suction filter filters the water / spraying mixture before the spraying pump (mesh size 0.035 in.) (0.9 mm). Different mesh sizes are available depending on the application.

Overview of pressure filter elements

| Meshes/ square inch | Nozzle size | Mesh size in. (mm) |
|------------------------|-------------|-----------------------|
| 32 | | |
| 50 | from '03' | 0.0138 (0.35) |
| 80 | '02' | 0.0079 (0.20) |
| 100 | up to '015' | 0.0059 (0.15) |


Cleaning of the filters, see chapter *Care and Maintenance*.

Control unit


A distinction is made here between the water flows:

- Basic / CCS
- Basic Pro / CCS Pro

Fittings



The filling ports, external control terminal, filters and the illuviation valve are located on the left side of the machine.




- Spraying pump on/off
- High pressure cleaner on/off (optional)

The following functions can be operated via the switch-over ball valves.


Water flow Basic / CCS

Ports

Overview of the ports




- 1 Direct filling, spraying mixture container residue drain
- 2 Spraying mixture container pressure output
- 3 Filling port for fresh water tank
- 4 Spraying mixture container lock valve



- 1 Switching between internal and outside cleaning
- 2 Stirring intensity during spraying/circulating
- 3 Pressure filter flushing intensity with mechanical pressure filter flushing
- 4 Selection: Spraying mixture container filling, cleaning, pressure output, illuviation valve, circulation / spraying / stirring,
- 5 Suction side of spraying mixture container or fresh water tank
- 6 Filling the fresh water tank

External control terminal

The crop protection sprayer is operated via the external control terminal. The following functions are operated via the keys on the external control terminal.




7. Opening/closing the spraying mixture container
8. Pressure filter locking lever
9. Pressure filter flushing drain
10. Suction filter drain valve

Water flow Basic Pro / CCS Pro

Ports


Overview of the ports



- 1 Direct filling, spraying mixture container residue drain
- 2 Spraying mixture container pressure output
- 3 Filling port for fresh water tank
- 4 Spraying mixture container lock valve

The following functions can be operated via the switch-over ball valves:

- Switching between internal and outside cleaning
- Stirring intensity during spraying/circulating
- Pressure filter flushing intensity with mechanical pressure filter flushing
- Selection: Spraying mixture container filling, cleaning, pressure output, illuviation valve, circulation / spraying / stirring,
- Suction side of spraying mixture container or fresh water tank
- Filling the fresh water tank



5. Pressure filter locking lever
6. Pressure filter flushing drain
7. Suction filter drain valve

External control terminal



The crop protection sprayer is operated via the external control terminal. The following functions are operated via the keys on the external control terminal.



- Circulation off
- Suction, stirring, illuviation valve, pulling suction, wash program, pressure information, fresh water switch-over, high pressure cleaner / outside cleaning, winter storage
- Refer also to the information in the terminal operating instructions.

Filter


Overview of filters



- 1 Pressure filter
- 2 Cleaning pump suction filter (only with CCS variant)
- 3 Spraying pump suction filter
- 4 Filter for high pressure cleaner and NightLight cleaning (optional)

Folding boom

Proper condition of spraying boom and suspension have a considerable influence on the distributing accuracy for the spraying mixture. Complete wetting is achieved by correctly adjusted spraying height of the folding boom to the crop.



- 1 Spraying boom with spraying lines
- 2 Nozzle protection tube
- 3 Parallelogram
- 4 Middle section
- 5 Collision protection
- 6 Folding boom lock
- 7 Parallelogram lock
- 8 Slope compensation
- 9 Folding boom rest



WARNING

Danger of crushing and impact for persons when lifting or lowering for height adjustment of the spraying boom!

Instruct persons to leave the danger zone around the machine before lifting or lowering the spraying boom by means of the height adjustment.



NOTE

Adjust the spraying height (distance between nozzles and crop) as per currently applicable guidelines.

Always adjust the spraying boom parallel to the ground, because the specified spraying height can only be achieved in this condition.

Carry out all adjustment work on the spraying boom conscientiously.

Folding variants

Folding boom, 5-piece with reduced working width 17 m



55 ft (17 m)



100 ft / 120 ft (30/36 m)

BoomControl

WARNING

Danger caused by unexpected movements in automatic mode. Never come close to the ultrasonic sensor while the BoomControl is in automatic mode!

During spraying operation under high voltage power lines disable the BoomControl and operate the slope compensation manually!

No persons may be present under the folding boom and in the danger zone!

The BoomControl function must be disabled when leaving the cabin!

The BoomControl folding boom control is used for the automatic distance control of the spraying boom.


Ultrasonic sensors measure the distance to the ground or the crop and the folding boom is then adjusted in accordance with the nominal distance values. An automatic height and inclination control thus adapts the folding boom distance to the crop. The crop should be closed and not show any gaps.

The scanning width of a sensor is approx. 7 in. (0.5 m). If a gap in crop or a trench wider than 7 in. (0.5 m) is detected under the sensor, the corresponding boom segment will be lowered (danger of damages).

When passing over exceptionally smooth surfaces, such as e.g. water puddles, the ultrasonic signal may be reflected. The control must in these areas be deactivated.

➤ BoomControl does not relieve the driver from his responsibility to constantly check the position of the folding boom and to interfere manually, if needed!

The folding boom can be equipped with up to 6 sensors for height adjustment and slope compensation.



Ultrasonic sensor on the folding boom

NOTE

When the spraying boom is switched off at the headland, the spraying boom is automatically raised by a previously defined value. When switched back on, the spraying boom will return to its set height.

BoomControl modes

Various equipment versions are available. Depending on the mode, there are different designs.

BoomControl

Design with 2 or 4 sensors for height adjustment and slope compensation.

BoomControl PRO

Design with 4 or 6 sensors for height adjustment, slope compensation and angle adjustment.

BoomControl PRO Plus


Design with 6 sensors for height adjustment, slope compensation and angle adjustment of the outside wings.

NOTE

In case of irregular population and/or empty spaces in the population, the folding boom control must be deactivated or manually overridden to avoid unintended lowering of the folding boom!

BoomControl Pro (optional)

Automatic folding boom control with active adjustment by the sensors on the folding boom wings. This ensures minimum drift at the lowest possible working height, even at high speeds, on flat or slightly hilly terrain.



Active adaptation of the folding boom via middle section height guidance and independent bending of both folding boom halves (controlled by 4 sensors, distributed over the entire folding boom).

Transport lock




The folding boom package must be locked and checked during each road travel!

Folding boom lock

The folding boom lock is used to lock the folded folding boom during road travel. It prevents accidental unfolding.



Folding boom lock open



Folding boom lock closed

Folding boom rest

The folding boom rest is used to rest the folded folding boom during road travel and prevents accidental unfolding.



Bow for folding boom rest




Folding boom rest




Folding boom put down

Parallelogram lock

The stroke of the parallelogram must always be locked during road travel. The parallelogram is locked automatically as soon as the folded folding boom is in the end position of the rest. When the folded folding boom is lifted from the rest, the parallelogram is first unlocked automatically.



Parallelogram interlock open (sample figure)



Parallelogram interlock locked (sample figure)


Slope compensation

The folding boom is aligned horizontally via the slope compensation.

If the terrain is uneven, the centre of gravity of the folding boom can be changed using the hydraulic slope compensation (1). Changing the centre of gravity allows the folding boom to be positioned parallel to the ground on a slope. The slope compensation must always be locked before road travel.

Slope compensation is locked automatically as soon as the folding boom is folded.

When unfolding the folding boom, the slope compensation is unlocked automatically after successful folding.



The slope compensation consists of two hydraulic cylinders that are locked or unlocked via lock valves.

Uniform transverse distribution is only achieved with the slope compensation unlocked.

NOTE

Before starting road travel make sure that the folding boom is locked and rests securely in the folding boom rest. In addition, the parallelogram and the slope compensation must be locked.

Collision protection

The collision protection protects the folding boom against damage caused by collision with a solid obstacle. The joint mechanism enables escaping a collision in travel direction and in opposite direction.



Sample figure

After the escape movement the collision protection will swing back to the initial position.

NOTE

Collision protection only with fully extended working width. With reduced working width pay attention to any obstacles around the outside of the machine!

Spraying line

The spraying line is made of stainless steel pipe. The nozzle control has been designed as pneumatic single nozzle control for all versions. Section separation is achieved by combining the control of several nozzle bodies.

The spraying line can be fitted with single or multiple nozzle bodies.

Circulation system

Due to the permanent circulation of the biocatalytic solution through the complete folding boom while the sprayer is switched off, spraying fluid is permanently applied to the nozzle.

When switching on individual sections or the entire spraying line for the first time, the biocatalytic solution is directly and well mixed available. This circulation successfully prevents the formation of deposits and blockage.


Cleaning of nozzle pipe and nozzles

The spraying line is cleaned by the circulation system. The suction side of the crop protection sprayer is set to fresh water for this purpose. The nozzle line is flushed with fresh water.

To clean the nozzles, all nozzles must be open for approx. 3 sec.


Circulation

PS = Pressure supply RT = Return spraying mixture container



Spraying


PS = Pressure Supply



Nozzle body

Single nozzle body with pneumatic control valve

If a pressure of more than 4 bar is applied to the compressed air connection (4), the valve will open and fluid can flow out. Without pressure the valve is closed.



- 1 Nozzle body
- 2 Seal attachment
- 3 Diaphragm
- 4 Pneumatic control valve
- 5 Bayonet connection
- 6 Rubber seal
- 7 Bayonet cap
- 8 Nozzle
- 9 Compressed air connection

New control valve must be installed with all nozzle bodies.

Multiple nozzle body manual triple

The triple nozzle body is used if more than one nozzle type is used. Only the vertically arranged nozzle will be supplied.

By turning the nozzle body, another nozzle is brought into use.


In intermediate positions the nozzle body is switched off.



NOTE

Flush the spraying lines and the active nozzle before turning the triple nozzle body to another nozzle type!

Fluid always escapes on all vertical nozzles. If a pressure of more than 58 psi (4 bar) is applied to the compressed air connection (4), the valve will open and fluid can flow out. Without pressure the valve is closed.



- 1 Nozzle body
- 2 Diaphragm
- 3 Pneumatic control valve
- 4 Compressed air connection
- 5 Bayonet connection
- 6 Rubber seal
- 7 Bayonet cap
- 8 Nozzle

Multiple nozzle body pneumatic

These multiple nozzle bodies are installed in the form of dual or 4-fold versions.

In this case it is possible to switch the desired nozzle from the terminal. You may even switch on several nozzles at a time. The pneumatic control valves are integrated in the nozzle carrier. If a pressure of 58 psi (4 bar) is applied to the compressed air connection (4), the valve will open and fluid can escape. Without pressure the valve is closed.



- 1 Nozzle body
- 2 Diaphragm
- 3 Pneumatic control valve
- 4 Compressed air connection
- 5 Bayonet connection
- 6 Rubber seal
- 7 Bayonet cap
- 8 Nozzle
- 9 Hinged clamp

Multiple nozzle body manual quadruple

The 4-fold nozzle body is recommended if more than only one nozzle type is used. Only the two vertical nozzles will be supplied. They can be activated individually via the terminal.

By turning the nozzle body, the other two nozzles are used.

In intermediate positions the nozzle body is switched off.

NOTE

Flush the spraying lines and the active nozzle before turning the 4-fold nozzle body to another nozzle type!

Fluid always escapes on all vertical nozzles. If pressure greater than 58 psi (4 bar) is applied to the compressed air connection (4), the valve will open and fluid can escape. Without pressure the valve is closed.



- 1 Nozzle body
- 2 Diaphragm
- 3 Pneumatic control valve
- 4 Compressed air connection
- 5 Bayonet connection
- 6 Rubber seal
- 7 Bayonet cap
- 8 Nozzle

Nozzle assembly and cleaning


Nozzle assembly

⚠ CAUTION

CAUTION Spraying mixture running out!

Use appropriate protective outfits. Catch spraying mixture in a suitable container and dispose of it.

1. Insert the nozzle (8) into the bayonet cap (7).
2. Insert the rubber seal (6) above the nozzle (8).
3. Press the rubber seal (6) into the seat of the bayonet cap (7).
4. Position the bayonet cap (7) on the bayonet connection (5).
5. Twist the bayonet cap (7) against the stop position.



⚠ NOTE

Observe the correct installation of the nozzle during assembly! Observe the specifications of the nozzle manufacturer.

Nozzle replacement

- Turn the nozzles each by approx. 45° (to end position) to remove and install them.
- Use the delivered tool for this purpose:



Cleaning nozzles

- Clean the nozzles, if required.
- Do not damage nozzles and nozzle filters when cleaning.

⚠ CAUTION

CAUTION Spraying mixture running out!

Never blow out the nozzles with your mouth.

Removing the diaphragm valve on dripping nozzles

Deposits on the diaphragm seat are the cause of nozzles dripping after the folding boom has been switched off.

In this case clean the corresponding diaphragm as follows:

1. Unscrew the pneumatic control valve (3) from the nozzle body (1).
2. Take out the diaphragm (2).
3. Clean the diaphragm seat.
4. Insert the diaphragm (2) again in the pneumatic control valve (3).
5. Screw the pneumatic control valve (3) again on the nozzle body (1).


⚠ CAUTION

CAUTION Spraying mixture running out!

Use appropriate protective outfits. Catch the spraying mixture in a suitable container and dispose of it properly.

Pulse width modulation (PresicionSpray)

Pulse width modulation (PWM) is used for more precise control of the spray liquid. The flow rate is controlled by fast opening and closing of electrically controlled nozzle valves. In this way, the same spray nozzle can be used to spray different quantities at the same pressure and with the same drop size. The spray rate remains unchanged.




- 1 Pulse nozzle switching valve
- 2 Status light
- 3 Nozzle carrier

Pulse width modulation is possible with the following nozzle control:

- 1-0 with 3-fold nozzle body manual
- 1-1 with 3-fold nozzle body manual

Design of pulse nozzle switching valves



- 1 O-ring
- 2 Outlet Seal
- 3 Valve body
- 4 O-ring
- 5 Valve piston with closing spring
- 6 Closure cap

Maintenance



Valve piston (5) new (left), worn (right)

HINWEIS

Replace worn valve pistons according to the manufacturer's instruction every 500 h or as required!

If additives, e.g. salts, are applied, always use an additional pressure filter to protect the valve pistons from foreign bodies.

Clean the pulse nozzles regularly, especially if powdery crop protection agents are used. For cleaning, disconnect the nozzles and open them using the tools supplied in the accessory pack (Art.No. 60009829).



Opening the nozzle switching valves

Examples nozzles and travel speeds

Example 1: Nozzle control 1-0 (50 spacing, nozzle Lechler IDKT 12005, 44 psi (3 bar)):

Application quantity: 16 gal lqd/ac (150 l/ha)
Travel speeds: from 3 to 9.8 mph (4.8 to 15.8 km/h) possible at the same pressure and application quantity.

Application quantity: 21 gal lqd/ac (200 l/ha)
Travel speeds: from 2.2 to 7.3 mph (3.6 to 11.8 km/h) with the same pressure and application quantity possible.

At 6.2 mph (10 km/h) application quantities between 8 gal lqd/ac (72 l/ha) and 26 gal lqd/ac (240 l/ha) can be achieved.

Example 2: Nozzle control 1-0 (50er spacing, nozzle Teejet AIC 11005, 58 psi (4 bar))

Application quantity: 16 gal lqd/ac (150 l/ha)
Travel speeds: from 3.3 to 11 mph (5.4 to 18 km/h) with the same pressure and application quantity possible.

At 6.2 mph (10 km/h) application quantities between 9 and 29 gal lqd/ac (80 l/ha and 270 l/ha) can be achieved.

Example 3: Nozzle control 1-1 (25er spacing, nozzle Teejet AIC 1105 and Lechler IDKT 12005 in mixed stock, 3 bar)

Application quantity: 21 gal lqd/ac (200 l/ha)
Travel speeds: from 4.5 to 15 mph (7.2 to 23.6 km/h) with the same pressure and application quantity possible.

Application quantity: 32 gal lqd/ac (300 l/ha)
Travel speeds: from 3 to 9.8 mph (4.8 to 15.8 km/h) with the same pressure and application quantity possible.

At 8.7 mph (14 km/h) application quantities between 10.7 and 36 gal lqd/ac (100 l/ha and 340 l/ha) can be achieved.


Optional equipment

GPS receiver (optional)

The description applies to the GPS receiver version of Müller Elektronik A101. Additional versions of other manufacturers may deviate.

Description

The GPS receiver serves to determine the exact position of the machine.



- 1 GPS receiver
- 2 Metal plate
- 3 Magnetic base
- 4 Self-adhesive plate
- 5 Connecting cable

Meaning of the LED light

The GPS receiver indicates the quality of the connection via a status LED:

- Red: The GPS receiver is connected to the terminal but cannot receive a GPS signal
- Orange: The GPS receiver can receive GPS signals but the differential signal is absent. Accuracy is therefore very low.
- Green: The GPS receiver receives GPS signals and differential signals.

Installation

⚠ CAUTION

Risk of crushing from very powerful magnet on the base of the GPS receiver!

When installing the GPS receiver, hold it firmly with both hands to make sure no fingers get between the magnetic base of the GPS receiver and a metal surface!

⚠ NOTE

The GPS receiver requires unobstructed view of the sky!


Mount the GPS receiver on the spraying mixture container of the crop protection sprayer. A pre-installed bracket is available there for the GPS receiver.

Shadowing of the GPS receiver is to be avoided.



Bracket for the GPS receiver

Assembly accessories



- 1 GPS receiver
- 2 Metal plate
- 3 Magnetic base
- 4 Self-adhesive plate

1. Thoroughly clean the location where the GPS receiver shall be mounted with alcohol.
 - Installation on the fresh water tank
2. Glue the double-sided self-adhesive plate (4) on the cleaned surface.
3. Clean the metal plate (2).
4. Pull the paper off the self-adhesive plate (4) and glue the metal plate (2) onto it.
5. Screw the magnetic base (3) into the GPS receiver (1).
6. Position the GPS receiver (1) with the magnetic base on the metal plate (2).



GPS receiver mounted on spraying mixture container

Connecting the GPS receiver to the terminal

⚠ CAUTION

The plug of the terminal carries voltage. Damages to the terminal may occur from a short-circuit. Switch off the terminal before connecting the connecting cable of the GPS receiver to it!

1. Switch off the terminal.
2. Route the connecting cable of the GPS receiver into the vehicle cabin.
3. Connect the connecting cable to the RS232 port on the terminal.
 - For more information about the fitting connection, refer to the HORSCH Terminal TOUCH 1200 operating instructions.
4. During initial starting it may take up to 30 minutes until the GPS receiver has reception. For all other starts it will only take approx. 1 - 2 minutes.

⚠ NOTE

Information on the configuration of the GPS receiver is provided in the HORSCH brief instructions GPS Setting.

Technical data

Features


| | |
|---------------------|------------------|
| Operating voltage | 7 - 36 VDC |
| Current consumption | 249 mA at 12 VDC |
| Power consumption | < 3 W at 12 VDC |
| GPS Standard | NMEA 0183 |

Configuration

| | |
|---------------|---------------------|
| Frequencies | 5 Hz (GPGGA, GPVTG) |
| | 1 Hz (GPGSA, GPZDA) |
| Transfer rate | 19200 Baud |
| Data bits | 8 |
| Parity | no |
| Stop bits | 1 |
| Flow control | none |

Edge and border nozzles


Each folding boom has a border and an edge nozzle. They are located 4 in. (10 cm) outside of the last main nozzle.



Border and edge nozzle


- 1 Border nozzle
- 2 Edge nozzle

- A border nozzle can always be activated in addition via the terminal. All main and auxiliary nozzles remain in use.



Border nozzle

- If an edge nozzle is activated via the terminal,
 - with 1-fold nozzle bodies, level 1 of the first or last main nozzle is switched off.
 - with 2-fold nozzle bodies, levels 1 and 2 of the first or last main nozzle are switched off.
 - with 4-fold nozzle bodies, levels 1 and 2 of the first or last main nozzle are switched off.



Edge nozzle

Example: When an edge nozzle is activated, the first blue and the first yellow nozzle are automatically switched off.



NightLight (optional)

Extremely bundled light (LED spotlight) to illuminate the spraying cones.

When the spraying process is switched off at the headland the lights are automatically cleaned by a washing facility (optional).


The LED spotlights are controlled via the terminal.



NightLight with cleaning nozzle (figure similar)


The cleaning cycle can be set as to whether it shall be run. If the cleaning cycle is activated, cleaning is automatically enabled when switching off the nozzles (e.g. at the headland). With each cycle the pump sucks in fresh water through a filter for approx. 4 seconds. At this, the pump delivers approx. 13.5 fl oz (400 ml) of fresh water with approx. 36 psi (2.5 bar) to the cleaning nozzle.

The filter is located behind the illuviation valve.



Filter NightLight cleaning

The pump is located behind the illuviation valve next to the filter.



Pump NightLight cleaning

NOTE

The cleaning cycle can also be activated in the daytime when the NightLight is switched off. This avoids deposits on the spreading disc also during daytime.

Direct filling (optional)

Direct filling without pump


At the direct filling port fluid from an external tank can be pressed directly into the spraying mixture container. It is installed at the right side of the machine in the front and next to the cabin. The spraying mixture container filling level can be read via the control terminal.



Direct filling connection

Direct filling with pump

At the direct filling port, fluid can be sucked into the spraying mixture container. It is installed at the right side of the machine in the front and next to the cabin. The filling pump can be started/stopped via the control terminal.



Direct filling connection

Wind meter (optional)

A wind meter can be mounted on the top side of the spraying mixture container. It provides current values on wind speeds. Drifting can thus be prevented to reach optimal treatment success of the crop protection measure.

The current values can be read on the terminal.



Wind meter (figure may differ depending on the machine variant)

Outside cleaning (optional)

NOTE

Wash the machine for the first time after 3 months at the earliest with a steam jet or high-pressure cleaner to avoid damage to the paintwork.

When using a water jet, keep a distance of at least 4 ft (1.5 m) from electronic components, terminals, electronic ports in the cabin or sensors.

After cleaning, check the hydraulic lines for leaks and firm connections. Retighten screw connections if necessary. Relubricate all lubrication points.

With outside cleaning, undesired contamination is removed and the unintentional dripping of adhering crop protection agents is prevented.

NOTE

Outside cleaning is supplied with fresh water via the centrifugal pump. (With standard water system depending on the valve position)

WARNING

Danger through accidental contact with spraying mixture!

Wear personal protective outfit!

Before using the outside cleaning system the cleaning programs of the field sprayer must be cycled through since the residual chemical still contained in the water system is pumped off via outside cleaning before fresh water arrives at the cleaning gun.

CAUTION

Risk of fluids escaping under pressure.
The external cleaning system may be contaminated with spraying mixture deposits!

Secure the washing gun with the lock against accidental spraying:


- before each spraying pause
- before the washing gun is stored again in its holder after cleaning is finished.

NOTE

- Wear suitable protective outfit when cleaning. Follow the specifications of the crop protection agent manufacturers.
- Cleaning water must not enter surface water or the sewage system.
- Perform cleaning therefore on an unpaved and green area.

With the external cleaning system two optional variants are available:


1/2" hose with hose reel and washing gun



- 1 Hose reel
- 2 Pressure hose
- 3 Washing gun with interlocking

- Water escapes from the washing gun as long as the handle is pressed.
- To fix the handle actuation press the tappet during operation.
- Press the handle to release.
- After switching off relieve the residual pressure.

High pressure cleaner (optional)



High pressure cleaner (figure may differ depending on the machine variant)

- 1 Hose reel
- 2 Pressure hose
- 3 Washing gun
- 4 Grip with lock

Operating pressure: 2.175 psi (150 bar)
Water output: approx. 4 gal lqd/min (15 l/min)

- Water escapes from the washing gun as long as the handle is pressed.
- To fix the handle actuator engage the lock during operation.
- Press the handle to release.
- After switching off relieve the residual pressure.

Oil change

- Use approx. 15 oz (415 g) of "AGIP GAMMA 30" for oil filling.
 - First oil change after 1000 operating hours.
 - Further oil changes annually or every 1000 operating hours
1. Place a suitable collecting vessel under the drain plug.
 2. Carefully unscrew the drain plug.
 3. Collect the entire oil and dispose of properly.
 4. Screw down the drain plug again.
 5. Fill in new oil (AGIP GAMMA 30, approx. 14 fl oz = 400 ml) via the filling opening.
 6. Check the oil tank for leaks.

N-Sensor bracket (optional)

The bracket for the N-Sensor is located on the front of the cabin roof. The N-Sensor measures the chlorophyll and adjusts the placing quantity accordingly.



N-Sensor bracket

NOTE

The bracket only fits the Yara-N-Sensor Series ALS.

Safety package (optional)

Warning triangle, safety vest, warning lamp incl. battery and first-aid kit are located in the storage compartment under the driver's seat.



Storage compartment under the driver's seat

Fire extinguisher (optional)

The fire extinguisher is located at the right hand side of the cabin.



Fire extinguisher

Maintenance of the fire extinguisher must be performed according to the national regulations by the customer.

Operation



Whenever working on the machine pay attention to the associated safety notes in the chapter "Safety and prevention of accidents" as well as the accident prevention instructions!

Commissioning



NOTE

Before commissioning the machine, the operator must have read and understood the operating instructions.



NOTE

The machine must comply with the regulations of the national road traffic regulations. Vehicle owner (operator) as well as driver (operating person) are solely responsible for complying with the statutory regulations of the national road traffic directives.



WARNING

Danger caused by crushing, shearing, cutting, winding up, being pulled in and caught in the area of hydraulically or electrically actuated components.

Do not block any actuators on the machine, which serve the purpose of directly executing hydraulic or electric movements of components. The respective movement must stop automatically once the operator releases the corresponding actuator. This does not apply to movements of equipment which

- are continuous or
- automatically controlled or
- require a floating or pressure position because of their function.

Prerequisites for the suitability of the machine are in particular:

- optimal functioning of the brake (brake test)
- compliance with the permissible total weight
- the tire load bearing capacity

Secure the vehicle against accidental starting and unintended rolling before starting work on the machine.

All interventions on the machine, such as (e.g. assembly work, adjustments, rectification of faults, cleaning, maintenance and repair) are prohibited,

- while the machine is driven.
- as long as the vehicle is not secured with parking brake and/or wheel chocks against accidental rolling.
- if moveable parts have not been blocked to prevent unintended movement.



WARNING

Dropping or lowering machine parts can cause severe crushing injuries etc.! Instruct persons to leave the danger zone.

Parking



DANGER

Danger of severe accidents when manoeuvring. Keep an eye on your environment.

- Keep persons (children) out of the manoeuvring range of the machine.



WARNING

Leaking hydraulic fluid can cause serious injuries! Danger of injury by unwanted machine movements.

NOTE

The machine must only be parked on a level and firm surface when loaded and, preferably, also when empty. Observe the load bearing capacity of the tires in the section *Weight and tires*.

Transport position

NOTE

- Transport the machine only with suitable vehicles such as low loaders. Note the total weight and centre of gravity of the machine when loading.
- Observe the operating instructions of the transport vehicle.
- All tanks of the sprayer must be empty during transport.
- Note the strapping points in the section *Safety stickers*!

WARNING

Danger of road accidents caused by losing the machine or machine parts.

- Check all interlocks before starting to drive.
- Release the parking brake and check the service brake (option).

NOTE

- Make sure before driving on public roads that the machine meets all respective applicable national road traffic regulations.

NOTE

Check the following prior to road travel:

- the light system for damage, function and cleanliness.
- the brake and hydraulic system for apparent defects.
- the parking brake must be fully released.
- the function of the brake system.
- Check whether the illumination valve has been swivelled to the transport position.
- The access ladder must be folded up and in transport position.
- the overall machine for cleanliness.

WARNING

Danger of crushing, cutting, being caught, being pulled in and impact due to insufficient stability and tipping over.

- Adjust the travel mode in such a way that you will at any time have control over the vehicle.

Be aware of your own abilities, account for the road, traffic, sight and weather conditions as well as the driving characteristics of the machine.

Multi-function control panel

Overview of the operator functions for spraying

The spraying functions are operated on the drive lever of the multi-function control panel.



- | | |
|--|--|
| 1 Open / close spraying nozzles | 11 Application quantity +/- 5% (optional assignment) |
| 2 Lift parallelogram | 12 Activate / deactivate cruise control 2 |
| 3 Lower parallelogram | 13 Activate / deactivate cruise control 1 |
| 4 Lift right slope compensation | 14 Activate/deactivate BoomControl |
| 5 Lift left slope compensation | |
| 6 Add sections to left | |
| 7 Add sections to right | |
| 8 Switch off sections to right | |
| 9 Switch off sections to left | |
| 10 Application quantity +/- 5% (optional assignment) | |



NOTE


The exact functions of the individual buttons will be explained in the associated chapters!

SectionBox (optional)

The SectionBox is available in the versions with 13 or 18 switches. Border/edge nozzles or sections can be assigned to the switches (1).

The SectionBox can be used in addition to the drive lever (main sprayer switch) or alone to operate the sections. The switch (2) allows switching between the input devices.

Active sections or border/edge nozzles can be identified by the illuminated LED of the respective switch (3).



HORSCH SectionBox, 13 sections

- When the main switch (4) is activated, all active sections or border/edge nozzles are enabled.
- When the main switch (4) is deactivated, all active sections or border/edge nozzles are in the *preselected* state.

Pay attention to the allocation of the respective sections or border/edge nozzles to the switches of the SectionBox, the *Terminal Operating Instructions*, software version 1.4.7 (or higher).

Installation

The SectionBox can be connected with a Sub-D connector for Cab-In and only in connection with a Terminal Touch 1200.

NOTE

- At the terminal the SectionBox must always be switched to AUX-N.
- For the combination terminal + SectionBox, the following connection sequence must be observed!
 - 1 ISOBUS
 - 2 SectionBox
 - 3 Terminal

Folding the folding boom

WARNING

Dropping or lowering machine parts can cause severe crushing injuries etc.!

- Folding the folding boom is only allowed from the driver's seat!
- No persons may stay under raised machine parts!
- Order persons to leave the danger zone around the machine. Make sure before folding that no persons are present in the danger zone.
- Comply with the accident prevention instructions.

CAUTION

Damages to the machine and the supporting surface!

When carrying out a folding process on a slope where uniform folding of the wings cannot be performed the machine may topple over.

- Fold the machine only on a level and firm surface.

WARNING

Danger of crushing, being pulled in, being caught or impact for operator and third parties may arise if third parties remain in the operating range of the folding boom when unfolding or folding in the folding boom and are caught by the moving parts of the folding boom!

These hazards can cause severe and possibly also fatal injuries.

Keep a sufficient safety distance to moving parts of the machine as long as the engine is running. Make sure that persons keep a sufficient safety distance to moving parts of the machine.

Order persons to leave the slewing range of the machine.

Immediately release the actuator for unfolding or folding in the folding boom, if a person enters into the slewing range of the folding boom.

DANGER

Always keep a sufficient distance to overhead power lines when unfolding or folding in the spraying boom! Contacting overhead power lines can cause fatal injuries.

WARNING

Avoid folding under high voltage power lines. When folding under high voltage power lines, the minimum distances between folding boom and the line must be observed during the folding process. The minimum distances to be observed are in accordance with national laws and guidelines regarding the current strength of the overhead line.

CAUTION

There are shearing and crushing points on all hydraulically actuated folding components! Folding or unfolding the spraying boom while travelling is prohibited!

Only drive with the machine in locked transport position.

NOTE

The folding boom is operated via the terminal. In folded and unfolded condition of the folding boom, the hydraulic cylinders for boom folding maintain the corresponding end position (transport and working position).

NOTE

The folding boom must be flushed through before folding it to avoid contamination of the machine. Check the diaphragm valve at regular intervals to prevent subsequent dripping of the nozzles. Refer to the section *Nozzle assembly and cleaning*.

NOTE

The folding process must be performed while the machine is at standstill since the folding boom may otherwise sustain damages or breakage.

- If the folding boom is not secured at a travel speed greater than 1.2 mph (2 km/h) the warning message *Check folding boom position* is displayed on the terminal.
- If the folding process is carried out at a travel speed greater than 1.2 mph (2 km/h) the warning message *Fold only while stopped* is displayed on the terminal.
- If the folding process is carried out at a travel speed greater than 3 mph (5 km/h) and the folding boom is not secured, an alarm message is displayed on the terminal and the folding process stops automatically!

Bring the machine to a stop and press the button for folding again to continue the folding process.

NOTE

- Instructions for operating the terminal are included in the supplied operating instructions!

The folding boom is folded via the terminal. Access the *Folding* page for details.

Unfolding

1. Call up the folding menu on the terminal.
2. Select the *Unfold folding boom* function.
3. The folding boom lock opens.
4. The parallelogram lock opens.
5. The folding boom is lifted from the rest.
6. The wings fold to the outside.
7. The slope compensation is unlocked.

Folding in

1. Call up the folding menu on the terminal.
2. Select the *Fold in folding boom* function.
3. The folding boom is lifted.
4. The slope compensation is locked.
5. The wings fold to the inside.
6. The folding boom lock closes.
7. The folding boom is placed in the rest.
8. The parallelogram lock closes.

NOTE

- Move the machine to transport position before road travel, see *Transport position*.

Preparation for spraying operation

WARNING

Danger due to accidental contact with crop protection agents / spraying mixture!

Wear personal protective outfit

- when preparing the spraying mixture.
- when cleaning / replacing spray nozzles.
- during all work for cleaning the crop protection sprayer after spraying operation.

When wearing the required protective outfit always follow the instructions of the manufacturer, the product information, the instructions for use, the safety data sheet or the operating instructions for the crop protection agent to be handled.

NOTE

Basic prerequisite for the proper application of crop protection agents is the proper function of the crop protection sprayer.

- The prescribed maintenance tasks and legal regulations on crop protection sprayers must be complied with. Rectify apparent faults immediately. Have the crop protection sprayer checked, as requested.
- Before starting with spraying check the following value on the control terminal:
 - The spraying pressure range defined on the terminal must agree with the permissible spraying pressure range of the spraying nozzles installed.
- Use all specified filters.
- Clean the filters at regular intervals.

Trouble-free operation of the crop protection sprayer is only ensured with flawless filtration of the spraying mixture. Appropriate filtering considerably influences the treatment success of the crop protection measure.

- Pay attention to the permissible filter combinations or mesh sizes.

The mesh sizes of pressure filters and nozzle filters must always be smaller than the nozzle opening of the nozzles used. Notes given by the manufacturer of the crop protection agent must be followed.

The standard pressure filter element used in the pressure filter has a mesh size of 0.007 in. (0.18 mm) with 80 meshes/inch². This pressure filter element is adequate for a nozzle size from 02'.

The pressure filter element with 100 meshes/inch² is required for nozzle sizes '015' and '01' (special equipment).

- Remember that the use of pressure filter elements with 100 meshes/inch will have the effect that with some crop protection agents active components may be filtered out. Contact the crop protection agent manufacturer in the respective case.
- Generally clean the crop protection sprayer before placing a different crop protection agent.
- Flushing nozzle line and nozzles:
 - with each nozzle change
 - before installing other nozzles
 - before turning the manual three-fold / five-fold nozzle head to another nozzle.
- Take appropriate action if an error message appears in the display during spraying operation.
- Check the displayed spraying pressure during spraying operation.
- Make sure that the displayed spraying pressure does under no conditions deviate from the specified spraying pressure from the spraying table by more than $\pm 25\%$, e.g. when changing the application quantity.
- More significant deviations from the specified spraying pressure will adversely affect the optimal treatment success of the crop protection measure and/or cause environmental damage.
- Reduce or increase the travel speed, until the permissible spraying pressure range (of the intended spraying pressure) is reached again.

Preparing the spraying mixture

DANGER

Danger caused by accidental contact with crop protection agents and/or spraying mixture!

When preparing spraying mixture there is the highest risk of coming into contact with crop protection agent.

- Use the stipulated protective outfit!
 - Follow the notes of the crop protection agent manufacturer.
 - Observe the national and country-specific regulations and standards (e.g. water protection areas).
-
- Generally, illuviate the crop protection agents through the illuviation valve into the spraying mixture container.
 - Swing the illuviation valve to the filling position before crop protection agent is filled into the illuviation valve.
 - Follow the safety regulations when handling crop protection agents and when preparing the spraying mixture: Read the instructions for use for the crop protection agent.
 - Do not prepare the spraying mixture in the vicinity of wells or surface waters.
 - Avoid leakages and contamination with crop protection agents and / or spraying mixture by acting appropriately and by wearing appropriate body protection.
 - Do not leave the prepared spraying mixture, unused crop protection agent, uncleaned crop protection agent canisters and the uncleaned crop protection sprayer unattended to avoid dangers to other persons.
 - Protect contaminated crop protection agent canisters and the contaminated crop protection sprayer against precipitation.
 - Ensure sufficient cleanliness during and after spraying mixture preparation to keep the risks as low as possible (e.g. thoroughly wash off and dispose of used gloves. Dispose of washing water and cleaning fluid in a proper manner).

NOTE

Besides the generally valid information listed hereunder, you should also follow the product-specific procedures described in the instructions for use of the crop protection agents!

- Pay attention to the prescribed water and preparation application quantities as per instructions for use for the crop protection agent.
- Follow the instructions for use of the preparation and the specified precautions!
- Carefully determine the required filling or refill quantities to avoid residual quantities, because environmentally friendly disposal of residual quantities is very difficult.

Use the Filling table for residual areas to calculate the required refill quantity for the last spraying mixture container filling. In this case, subtract the technical, undiluted residual quantity in the spraying boom from the calculated refill quantity.

- In this context see chapter *Filling table for residual areas*.
- Thoroughly rinse emptied preparation containers (e.g. with canister flushing agent) and mix in the flushing water to the spraying mixture!

General procedure

1. Determine the required water and preparation application quantity as per instructions for use for the crop protection agent.
2. Calculate the filling or refill quantity for the area to be treated.
3. Fill half of the spraying mixture container with water.
4. Switch on the agitator.
5. Add the calculated preparation quantity.
6. Top up the water shortfall.
7. Before starting the spraying operation stir up the spraying mixture as instructed by the crop protection agent manufacturer.

Nozzle selection

NOTE

For the selection and use of nozzles you should also follow the data and recommendations of the respective nozzle manufacturer!

General

This chapter describes two possibilities for determining the appropriate nozzles and their characteristics as per ISO 10625.

NOTE

All application quantities (in l/ha) mentioned in the spraying tables apply for **water**.

For liquid fertiliser these application quantities must first be converted:

For conversion to ammonium nitrate - carbonyl diamide solution multiply the application quantity with 0.88.

For conversion to NP-solution multiply the application quantity with 0.85.

$$\begin{array}{l} \text{H}_2\text{O} \xrightarrow[\text{x } 1.14]{\text{x } 0.88} \text{Ammonium nitrate - carbonyl diamide solution} \\ \text{H}_2\text{O} \xrightarrow[\text{x } 1.18]{\text{x } 0.85} \text{NP-solution} \end{array}$$

The diagram (a) serves the purpose of selecting the suitable **nozzle type**.

The nozzle type is determined by

- the intended travel speed
- the required application quantity
- the required atomizing characteristic (fine, medium or large drops) of the crop protection agent used for the crop protection measure to be carried out.

The universal table (b) serves the purpose of determining

- the **nozzle size**
- the required **spraying pressure**
- the required individual nozzle output for volumetric measurement of the crop protection sprayer.

Procedure

- The tables apply to 50 cm nozzle spacing.
- Nozzle sizes and colour coding acc. to ISO 10625

With diagram and universal table

- 1 Determine application quantity, travel speed and atomizing characteristic.

Nozzle type → diagram (a):

- 2 Determine the operating point. The operating point is the intersection of travel speed and application quantity.
- 3 Draw a vertical from the operating point down.
- 4 Choose the suitable nozzle type for the required atomizing characteristic. For this purpose follow the classification in the left diagram (fine, medium, coarse drops). Pay attention to the possible nozzle sizes.

Characteristics → Universal table:

Change to the universal table for a more accurate determination of the characteristic values.

- 5 In the column with the determined application quantity find the line with the determined travel speed (if necessary use an approximate value).
- 6 In the right hand line read the nozzle output and the suitable nozzle sizes with the associated pressure.

Example:

- to 1. Application quantity: 200 l/ha
Travel speed: 8 km/h
Atomization characteristic: coarse droplets
- to 2 / 3. See diagram (a)
- to 4. Nozzle type: ID/AL
Possible nozzle sizes: -025 or -03
- to 5. See Universal table
- to 6. Nozzle output: 1.35 l/min
Nozzles: Size 025 with 5.5 bar
Size 030 with 3.8 bar




Diagram (a) with example

| Application quantity l/ha | | | | | | | | | | Nozzle output l/min | Nozzle size | | | | | | | | | | | | | | | | | | | |
|--------------------------------------|-------------------|---------------------------------|---------------------------------|--------------------------------------|----------------------------------|---------------------------------|---------------------------------|---------------------------------|-----|--|--|--------------------------|-----|------|--------------|-----|-----|-----|-----|---------------------------------|--|--|--|--|--|--|--|--|--|--|
| 100 | 125 | 150 | 175 | 200 | 225 | 250 | 300 | 400 | 500 | | -01 | -015 | -02 | -025 | -03 | -04 | -05 | -06 | -08 | -10 | | | | | | | | | | |
| 4,8 5,4 6,0 | 4,8 | | | Travel speed km/h | | | | | | 0,25 0,30 0,35 0,40 0,45 0,50 | 1,2 1,7 2,3 3,0 3,8 4,7 | 1,0 1,3 1,7 2,1 | 1,2 | | Pressure bar | | | | | | | | | | | | | | | |
| | | | | 0,55 0,60 0,65 0,70 0,75 | 5,7 6,7 7,9 9,2 | 2,5 3,0 3,5 4,1 4,7 | 1,4 1,7 2,0 2,3 2,6 | 1,1 1,3 1,5 1,5 1,7 | | | | | | | | | | | | | | | | | | | | | | |
| | | | | 0,80 0,85 0,90 0,95 1,00 | 5,3 6,0 6,8 7,5 8,4 | 3,0 3,4 3,8 4,2 4,7 | 1,9 2,2 2,4 2,7 3,0 | 1,3 1,5 1,7 1,9 2,1 | | | | | | | | | | | | | | | | | | | | | | |
| | | | | 1,05 1,10 1,15 1,20 1,25 | 9,2 10,1 6,2 6,7 7,3 | 5,2 5,7 6,2 6,7 7,3 | 3,3 3,6 4,0 4,3 4,7 | 2,3 2,5 2,8 3,0 3,3 | | | | | | | | | | | | 1,3 1,4 1,5 1,7 1,8 | | | | | | | | | | |
| | | | | 1,30 1,35 1,40 1,45 1,50 | 7,9 8,5 9,2 | 5,1 5,5 5,9 6,3 6,8 | 3,5 3,8 4,1 4,4 4,7 | 2,0 2,1 2,3 2,5 2,6 | | | | | | | | | | | | 1,3 1,4 1,5 1,6 1,7 | | | | | | | | | | |
| 1,60 1,70 1,80 1,90 2,00 | 7,7 8,7 9,7 | 5,3 6,0 6,7 7,5 8,3 | 3,0 3,4 3,8 4,2 4,7 | 1,9 2,2 2,4 2,7 3,0 | 1,3 1,5 1,7 1,9 2,1 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2,10 2,20 2,30 2,40 2,50 | 9,2 10,1 | 5,2 5,7 6,2 6,7 7,3 | 3,3 3,6 4,0 4,3 4,7 | 2,3 2,5 2,8 3,0 3,3 | 1,3 1,4 1,5 1,7 1,8 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2,60 2,70 2,80 2,90 3,00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3,10 3,20 3,30 3,40 3,50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3,60 3,70 3,80 3,90 4,00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4,10 4,20 4,30 4,40 4,50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4,60 4,70 4,80 4,90 5,00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Travel speed km/h | | | | | | | | | | Pressure bar | | | | | | | | | | | | | | | | | | | | |

Universal table (b) with 50 cm nozzle spacing (with example)

The values apply for water of 20 °C, pressure measured directly at the nozzle.

Check the values with a measuring vessel before the start of application.

With placing quantity table

- 1 Determine placing quantity and travel speed.
- 2 In the placing quantity table look for the column with the required travel speed.
- 3 Look for the line(s) with the required placing quantity (use approximate values, if necessary).
- 4 Read nozzle size, pressure and nozzle output.

Example:

- 1 Placing quantity: 200 l/ha
Travel speed: 8 km/h
- 2 See placing quantity table
- 3 See placing quantity table
- 4 Nozzles: a) Size: 025
Pressure 5.0 bar
Nozzle output: 1.29 l/min

b) Size: 03
Pressure: 4.0 bar
Nozzle output: 1.39 l/min

| Type Colour | Pressure bar | l/min | Placing quantity in l/ha at km/h | | | | | | | |
|----------------|-----------------|-------|----------------------------------|-----|-----|-----|-----|-----|-----|-----|
| | | | 5 | 6 | 7 | 8 | 10 | 12 | 14 | 16 |
| -01 orange | 1,0 | 0,23 | 55 | 46 | 40 | 35 | 28 | 23 | 20 | 17 |
| | 1,5 | 0,28 | 68 | 57 | 49 | 42 | 34 | 28 | 24 | 21 |
| | 2,0 | 0,33 | 78 | 65 | 56 | 49 | 39 | 33 | 28 | 25 |
| | 2,5 | 0,37 | 88 | 73 | 63 | 55 | 44 | 37 | 31 | 27 |
| | 3,0 | 0,40 | 96 | 80 | 69 | 60 | 48 | 40 | 34 | 30 |
| | 4,0 | 0,46 | 111 | 92 | 79 | 69 | 55 | 46 | 40 | 35 |
| | 5,0 | 0,52 | 124 | 103 | 89 | 78 | 62 | 52 | 44 | 39 |
| | 6,0 | 0,57 | 136 | 113 | 97 | 85 | 68 | 57 | 49 | 42 |
| -015 green | 7,0 | 0,61 | 147 | 122 | 105 | 92 | 73 | 61 | 52 | 46 |
| | 8,0 | 0,65 | 157 | 131 | 112 | 98 | 78 | 65 | 56 | 49 |
| | 1,0 | 0,35 | 83 | 69 | 59 | 52 | 42 | 35 | 30 | 26 |
| | 1,5 | 0,42 | 102 | 85 | 73 | 64 | 51 | 42 | 36 | 32 |
| | 2,0 | 0,49 | 118 | 98 | 84 | 74 | 59 | 49 | 42 | 37 |
| | 2,5 | 0,55 | 132 | 110 | 94 | 82 | 66 | 55 | 47 | 41 |
| | 3,0 | 0,60 | 144 | 120 | 103 | 90 | 72 | 60 | 51 | 45 |
| | 4,0 | 0,69 | 166 | 139 | 119 | 104 | 83 | 69 | 59 | 52 |
| -02 yellow | 5,0 | 0,78 | 186 | 155 | 133 | 116 | 93 | 78 | 66 | 58 |
| | 6,0 | 0,85 | 204 | 170 | 146 | 127 | 102 | 85 | 73 | 64 |
| | 7,0 | 0,92 | 220 | 183 | 157 | 138 | 110 | 92 | 79 | 69 |
| | 8,0 | 0,98 | 235 | 196 | 168 | 147 | 118 | 98 | 84 | 74 |
| | 1,0 | 0,46 | 111 | 92 | 79 | 69 | 55 | 46 | 40 | 35 |
| | 1,5 | 0,57 | 136 | 113 | 97 | 85 | 68 | 57 | 49 | 42 |
| | 2,0 | 0,65 | 157 | 131 | 112 | 98 | 78 | 65 | 56 | 49 |
| | 2,5 | 0,73 | 175 | 146 | 125 | 110 | 88 | 73 | 63 | 55 |
| -025 lilac | 3,0 | 0,80 | 192 | 160 | 137 | 120 | 96 | 80 | 69 | 60 |
| | 4,0 | 0,92 | 222 | 185 | 158 | 139 | 111 | 92 | 79 | 69 |
| | 5,0 | 1,03 | 248 | 207 | 177 | 155 | 124 | 103 | 89 | 77 |
| | 6,0 | 1,13 | 271 | 226 | 194 | 170 | 136 | 113 | 97 | 85 |
| | 7,0 | 1,22 | 293 | 244 | 209 | 183 | 147 | 122 | 105 | 92 |
| | 8,0 | 1,31 | 313 | 261 | 224 | 196 | 157 | 131 | 112 | 98 |
| | 1,0 | 0,58 | 138 | 115 | 99 | 87 | 69 | 58 | 49 | 43 |
| | 1,5 | 0,71 | 170 | 141 | 121 | 106 | 85 | 71 | 61 | 53 |
| -03 blue | 2,0 | 0,82 | 196 | 163 | 140 | 122 | 98 | 82 | 70 | 61 |
| | 2,5 | 0,91 | 219 | 183 | 157 | 137 | 110 | 91 | 78 | 68 |
| | 3,0 | 1,00 | 240 | 200 | 171 | 150 | 120 | 100 | 86 | 75 |
| | 4,0 | 1,15 | 277 | 231 | 198 | 173 | 138 | 115 | 99 | 87 |
| | 5,0 | 1,29 | 310 | 258 | 221 | 194 | 155 | 129 | 111 | 97 |
| | 6,0 | 1,41 | 339 | 283 | 242 | 212 | 170 | 141 | 121 | 106 |
| | 7,0 | 1,53 | 367 | 306 | 262 | 229 | 183 | 153 | 131 | 115 |
| | 8,0 | 1,63 | 392 | 326 | 280 | 245 | 196 | 163 | 140 | 122 |
| -04 red | 1,0 | 0,69 | 166 | 139 | 119 | 104 | 83 | 69 | 59 | 52 |
| | 1,5 | 0,85 | 204 | 170 | 146 | 127 | 102 | 85 | 73 | 64 |
| | 2,0 | 0,98 | 235 | 196 | 168 | 147 | 118 | 98 | 84 | 74 |
| | 2,5 | 1,10 | 263 | 219 | 188 | 164 | 131 | 110 | 94 | 82 |
| | 3,0 | 1,20 | 288 | 240 | 206 | 180 | 144 | 120 | 103 | 90 |
| | 4,0 | 1,39 | 332 | 277 | 237 | 208 | 166 | 139 | 119 | 104 |
| | 5,0 | 1,55 | 372 | 310 | 266 | 232 | 186 | 155 | 133 | 116 |
| | 6,0 | 1,70 | 407 | 339 | 291 | 255 | 204 | 170 | 145 | 127 |
| -05 brown | 7,0 | 1,83 | 440 | 367 | 314 | 275 | 220 | 183 | 157 | 137 |
| | 8,0 | 1,96 | 470 | 392 | 336 | 294 | 235 | 196 | 168 | 147 |
| | 1,0 | 0,92 | 222 | 185 | 158 | 139 | 111 | 92 | 79 | 69 |
| | 1,5 | 1,13 | 271 | 226 | 194 | 170 | 136 | 113 | 97 | 85 |
| | 2,0 | 1,31 | 313 | 261 | 224 | 196 | 157 | 131 | 112 | 98 |
| | 2,5 | 1,46 | 351 | 292 | 250 | 219 | 175 | 146 | 125 | 110 |
| | 3,0 | 1,60 | 384 | 320 | 274 | 240 | 192 | 160 | 137 | 120 |
| | 4,0 | 1,85 | 444 | 370 | 317 | 277 | 222 | 185 | 158 | 139 |
| -06 grey | 5,0 | 2,07 | 496 | 413 | 354 | 310 | 248 | 207 | 177 | 155 |
| | 6,0 | 2,26 | 543 | 453 | 388 | 339 | 272 | 226 | 194 | 170 |
| | 7,0 | 2,44 | 587 | 489 | 419 | 367 | 293 | 244 | 209 | 183 |
| | 8,0 | 2,61 | 627 | 522 | 448 | 392 | 313 | 261 | 224 | 196 |
| | 1,0 | 0,92 | 222 | 185 | 158 | 139 | 111 | 92 | 79 | 69 |
| | 1,5 | 1,13 | 271 | 226 | 194 | 170 | 136 | 113 | 97 | 85 |
| | 2,0 | 1,31 | 313 | 261 | 224 | 196 | 157 | 131 | 112 | 98 |
| | 2,5 | 1,46 | 351 | 292 | 250 | 219 | 175 | 146 | 125 | 110 |

| Type Colour | Pressure bar | l/min | Placing quantity in l/ha at km/h | | | | | | | |
|--------------------|-----------------|-------|----------------------------------|------|------|------|------|-----|-----|-----|
| | | | 5 | 6 | 7 | 8 | 10 | 12 | 14 | 16 |
| -05 brown | 1,0 | 1,16 | 277 | 231 | 198 | 173 | 139 | 116 | 99 | 87 |
| | 1,5 | 1,41 | 339 | 283 | 242 | 212 | 170 | 141 | 121 | 106 |
| | 2,0 | 1,63 | 392 | 327 | 280 | 245 | 196 | 163 | 140 | 122 |
| | 2,5 | 1,83 | 438 | 365 | 313 | 274 | 219 | 183 | 157 | 137 |
| | 3,0 | 2,00 | 480 | 400 | 343 | 300 | 240 | 200 | 171 | 150 |
| | 4,0 | 2,31 | 554 | 462 | 396 | 346 | 277 | 231 | 198 | 173 |
| | 5,0 | 2,58 | 620 | 516 | 443 | 387 | 310 | 258 | 221 | 194 |
| | 6,0 | 2,83 | 679 | 566 | 485 | 424 | 339 | 283 | 242 | 212 |
| -06 grey | 7,0 | 3,06 | 733 | 611 | 524 | 458 | 367 | 306 | 262 | 229 |
| | 8,0 | 3,26 | 783 | 653 | 560 | 490 | 392 | 326 | 280 | 245 |
| | 1,0 | 1,39 | 333 | 277 | 238 | 208 | 166 | 139 | 119 | 104 |
| | 1,5 | 1,70 | 407 | 339 | 291 | 255 | 204 | 170 | 145 | 127 |
| | 2,0 | 1,96 | 470 | 392 | 336 | 294 | 235 | 196 | 168 | 147 |
| | 2,5 | 2,19 | 526 | 438 | 376 | 329 | 263 | 219 | 188 | 164 |
| | 3,0 | 2,40 | 576 | 480 | 411 | 360 | 288 | 240 | 206 | 180 |
| | 4,0 | 2,77 | 665 | 554 | 475 | 416 | 333 | 277 | 238 | 208 |
| -08 white | 5,0 | 3,10 | 744 | 620 | 531 | 465 | 372 | 310 | 266 | 232 |
| | 6,0 | 3,39 | 815 | 679 | 582 | 509 | 407 | 339 | 291 | 255 |
| | 7,0 | 3,67 | 880 | 733 | 628 | 550 | 440 | 367 | 314 | 275 |
| | 8,0 | 3,92 | 941 | 784 | 672 | 588 | 470 | 392 | 336 | 294 |
| | 1,0 | 1,85 | 444 | 370 | 317 | 277 | 222 | 185 | 158 | 139 |
| | 1,5 | 2,26 | 543 | 453 | 388 | 339 | 272 | 226 | 194 | 170 |
| | 2,0 | 2,61 | 627 | 523 | 448 | 392 | 314 | 261 | 224 | 196 |
| | 2,5 | 2,92 | 701 | 584 | 501 | 438 | 351 | 292 | 250 | 219 |
| -10 black | 3,0 | 3,20 | 768 | 640 | 549 | 480 | 384 | 320 | 274 | 240 |
| | 4,0 | 3,69 | 887 | 739 | 633 | 554 | 443 | 369 | 317 | 277 |
| | 5,0 | 4,13 | 992 | 826 | 708 | 620 | 496 | 413 | 354 | 310 |
| | 6,0 | 4,53 | 1086 | 905 | 776 | 679 | 543 | 453 | 388 | 339 |
| | 7,0 | 4,89 | 1173 | 978 | 838 | 733 | 587 | 489 | 419 | 367 |
| | 8,0 | 5,22 | 1254 | 1045 | 896 | 784 | 627 | 522 | 448 | 392 |
| | 1,0 | 2,31 | 554 | 462 | 396 | 346 | 277 | 231 | 198 | 173 |
| | 1,5 | 2,83 | 679 | 566 | 485 | 424 | 339 | 283 | 242 | 212 |
| -12 turquoise | 2,0 | 3,27 | 784 | 653 | 560 | 490 | 392 | 327 | 280 | 245 |
| | 2,5 | 3,65 | 876 | 730 | 626 | 548 | 438 | 365 | 313 | 274 |
| | 3,0 | 4,00 | 960 | 800 | 686 | 600 | 480 | 400 | 343 | 300 |
| | 4,0 | 4,62 | 1108 | 924 | 792 | 693 | 554 | 462 | 396 | 346 |
| | 5,0 | 5,16 | 1239 | 1033 | 885 | 775 | 620 | 516 | 443 | 387 |
| | 6,0 | 5,66 | 1357 | 1131 | 970 | 848 | 679 | 566 | 485 | 424 |
| | 7,0 | 6,11 | 1466 | 1222 | 1047 | 917 | 733 | 611 | 524 | 458 |
| | 8,0 | 6,53 | 1567 | 1306 | 1119 | 979 | 783 | 653 | 560 | 490 |
| -16 violet | 1,0 | 2,77 | 665 | 554 | 475 | 416 | 333 | 277 | 238 | 208 |
| | 1,5 | 3,39 | 814 | 679 | 582 | 509 | 407 | 339 | 291 | 255 |
| | 2,0 | 3,92 | 941 | 784 | 672 | 588 | 470 | 392 | 336 | 294 |
| | 2,5 | 4,38 | 1051 | 876 | 751 | 657 | 526 | 438 | 376 | 329 |
| | 3,0 | 4,80 | 1152 | 960 | 823 | 720 | 576 | 480 | 411 | 360 |
| | 4,0 | 5,54 | 1330 | 1109 | 950 | 831 | 665 | 554 | 475 | 416 |
| | 1,0 | 3,70 | 887 | 739 | 634 | 554 | 444 | 370 | 317 | 277 |
| | 1,5 | 4,52 | 1086 | 905 | 776 | 679 | 543 | 453 | 388 | 339 |
| -20 bright-blue | 2,0 | 5,23 | 1254 | 1045 | 896 | 784 | 627 | 523 | 448 | 392 |
| | 2,5 | 5,84 | 1402 | 1168 | 1001 | 876 | 701 | 584 | 501 | 438 |
| | 3,0 | 6,40 | 1536 | 1280 | 1097 | 960 | 768 | 640 | 549 | 480 |
| | 4,0 | 7,39 | 1774 | 1478 | 1267 | 1109 | 887 | 739 | 633 | 554 |
| | 1,0 | 4,62 | 1108 | 924 | 792 | 693 | 554 | 462 | 396 | 346 |
| | 1,5 | 5,66 | 1358 | 1131 | 970 | 849 | 679 | 566 | 485 | 424 |
| | 2,0 | 6,53 | 1568 | 1306 | 1120 | 980 | 784 | 653 | 560 | 490 |
| | 2,5 | 7,30 | 1753 | 1461 | 1252 | 1095 | 876 | 730 | 626 | 548 |
| | 3,0 | 8,00 | 1920 | 1600 | 1371 | 1200 | 960 | 800 | 686 | 600 |
| | 4,0 | 9,24 | 2217 | 1848 | 1584 | 1386 | 1109 | 924 | 792 | 693 |


Universal table with 50 cm nozzle spacing (with example)

The values apply for water of 20 °C, pressure measured directly at the nozzle.

Check the values with a measuring vessel before the start of application.

| Size ISO | Flow PSI | Capacity GPM | Gallons per acre based on 20" nozzle spacing | | | | | | | | | | | | Size ISO | Flow PSI | Capacity GPM | Gallons per acre based on 20" nozzle spacing | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|----------|--------------|--|-------|-------|-------|-------|--------|--------|--------|--------|--------|--------|-------|----------|----------|--------------|--|-------|-------|-------|--------|--------|--------|--------|--------|--------|----|-----|------|------|----|------|------|------|------|------|------|------|------|------|-----|
| | | | 4 MPH | 5 MPH | 6 MPH | 7 MPH | 8 MPH | 10 MPH | 12 MPH | 14 MPH | 16 MPH | 18 MPH | 20 MPH | 4 MPH | | | | 5 MPH | 6 MPH | 7 MPH | 8 MPH | 10 MPH | 12 MPH | 14 MPH | 16 MPH | 18 MPH | 20 MPH | | | | | | | | | | | | | | | |
| 015 | 20 | 0.11 | 7.9 | 6.3 | 5.2 | 4.5 | 3.9 | 3.1 | 2.6 | 2.2 | 2.0 | 1.7 | 1.6 | 04 | 20 | 0.28 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 8.4 | 7.0 | 6.0 | 5.3 | 4.7 | 4.2 | 05 | 20 | 0.35 | 26 | 21 | 17.5 | 15.0 | 13.1 | 10.5 | 8.8 | 7.5 | 6.6 | 5.8 | 5.3 | |
| | 30 | 0.13 | 9.6 | 7.7 | 6.4 | 5.5 | 4.8 | 3.9 | 3.2 | 2.8 | 2.4 | 2.1 | 1.9 | | 30 | 0.34 | 26 | 21 | 17.2 | 14.7 | 12.9 | 10.3 | 8.6 | 7.4 | 6.4 | 5.7 | 5.1 | | 30 | 0.43 | 32 | 26 | 21 | 18.4 | 16.1 | 12.9 | 10.7 | 9.2 | 8.0 | 7.1 | 6.4 | |
| | 40 | 0.15 | 11.1 | 8.9 | 7.4 | 6.4 | 5.6 | 4.5 | 3.7 | 3.2 | 2.8 | 2.5 | 2.2 | | 40 | 0.40 | 30 | 24 | 20 | 17.0 | 14.8 | 11.9 | 9.9 | 8.5 | 7.4 | 6.6 | 5.9 | | 40 | 0.50 | 37 | 30 | 25 | 21 | 18.6 | 14.9 | 12.4 | 10.6 | 9.3 | 8.3 | 7.4 | |
| | 50 | 0.17 | 12.4 | 10.0 | 8.3 | 7.1 | 6.2 | 5.0 | 4.1 | 3.6 | 3.1 | 2.8 | 2.5 | | 50 | 0.45 | 33 | 27 | 22 | 19.0 | 16.6 | 13.3 | 11.1 | 9.5 | 8.3 | 7.4 | 6.6 | | 5.9 | 50 | 0.56 | 42 | 33 | 28 | 24 | 21 | 16.6 | 13.8 | 11.9 | 10.4 | 9.2 | 8.3 |
| | 60 | 0.18 | 13.6 | 10.9 | 9.1 | 7.8 | 6.8 | 5.5 | 4.5 | 3.9 | 3.4 | 3.0 | 2.7 | | 60 | 0.49 | 36 | 29 | 24 | 21 | 19.2 | 14.5 | 12.1 | 10.4 | 9.1 | 8.1 | 7.3 | | 60 | 0.61 | 46 | 36 | 30 | 26 | 23 | 18.2 | 15.2 | 13.0 | 11.4 | 10.1 | 9.1 | |
| | 70 | 0.20 | 14.7 | 11.8 | 9.9 | 8.4 | 7.4 | 5.9 | 4.9 | 4.2 | 3.7 | 3.3 | 2.9 | | 70 | 0.53 | 39 | 31 | 26 | 23 | 19.6 | 15.7 | 13.1 | 11.2 | 9.8 | 8.7 | 7.9 | | 70 | 0.66 | 49 | 39 | 33 | 26 | 25 | 20 | 16.4 | 14.0 | 12.3 | 10.9 | 9.8 | |
| | 80 | 0.21 | 15.7 | 12.6 | 10.5 | 9.0 | 7.9 | 6.3 | 5.2 | 4.5 | 3.9 | 3.5 | 3.1 | | 80 | 0.57 | 42 | 34 | 28 | 24 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 9.3 | 8.4 | | 80 | 0.71 | 53 | 42 | 35 | 30 | 26 | 21 | 17.5 | 15.0 | 13.1 | 11.7 | 10.5 | |
| | 90 | 0.22 | 16.7 | 13.4 | 11.1 | 9.5 | 8.3 | 6.7 | 5.6 | 4.8 | 4.2 | 3.7 | 3.3 | | 90 | 0.60 | 45 | 36 | 30 | 26 | 22 | 17.8 | 14.8 | 12.7 | 11.1 | 9.9 | 8.9 | | 90 | 0.75 | 56 | 45 | 37 | 32 | 28 | 22 | 18.6 | 15.9 | 13.9 | 12.4 | 11.1 | |
| | 100 | 0.24 | 17.6 | 14.1 | 11.7 | 10.1 | 8.8 | 7.0 | 5.9 | 5.0 | 4.4 | 3.9 | 3.5 | | 100 | 0.63 | 47 | 38 | 31 | 27 | 24 | 18.8 | 15.6 | 13.4 | 11.7 | 10.4 | 9.4 | | 100 | 0.79 | 59 | 47 | 39 | 34 | 29 | 24 | 20 | 16.8 | 14.7 | 13.1 | 11.7 | |
| | 120 | 0.26 | 19.3 | 15.4 | 12.9 | 11.0 | 9.6 | 7.7 | 6.4 | 5.5 | 4.9 | 4.3 | 3.9 | | 120 | 0.69 | 51 | 41 | 34 | 29 | 26 | 21 | 17.1 | 14.7 | 12.9 | 11.4 | 10.3 | | 120 | 0.87 | 64 | 52 | 43 | 37 | 32 | 26 | 21 | 18.4 | 16.1 | 14.3 | 12.9 | |
| 02 | 20 | 0.14 | 10.5 | 8.4 | 7.0 | 6.0 | 5.2 | 4.2 | 3.5 | 3.0 | 2.6 | 2.3 | 2.1 | 06 | 20 | 0.42 | 32 | 25 | 21 | 18.0 | 15.8 | 12.6 | 10.5 | 9.0 | 7.9 | 7.0 | 6.3 | 08 | 20 | 0.57 | 42 | 34 | 28 | 24 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 9.3 | 8.4 | |
| | 30 | 0.17 | 12.9 | 10.3 | 8.6 | 7.3 | 6.4 | 5.1 | 4.3 | 3.7 | 3.2 | 2.9 | 2.6 | | 30 | 0.43 | 32 | 26 | 21 | 18.4 | 16.1 | 12.9 | 10.7 | 9.2 | 8.0 | 7.1 | 6.4 | | 30 | 0.69 | 51 | 41 | 34 | 29 | 26 | 21 | 17.1 | 14.7 | 12.9 | 11.4 | 10.3 | |
| | 40 | 0.20 | 14.8 | 11.9 | 9.9 | 8.5 | 7.4 | 5.9 | 4.9 | 4.2 | 3.7 | 3.3 | 3.0 | | 40 | 0.50 | 37 | 30 | 25 | 21 | 18.6 | 14.9 | 12.4 | 10.6 | 9.3 | 8.3 | 7.4 | | 40 | 0.80 | 59 | 47 | 39 | 34 | 30 | 24 | 20 | 16.9 | 14.8 | 13.1 | 11.8 | |
| | 50 | 0.22 | 16.6 | 13.3 | 11.1 | 9.5 | 8.3 | 6.6 | 5.5 | 4.7 | 4.1 | 3.7 | 3.3 | | 50 | 0.56 | 42 | 33 | 28 | 24 | 21 | 16.6 | 13.8 | 11.9 | 10.4 | 9.2 | 8.3 | | 50 | 0.89 | 66 | 53 | 44 | 38 | 33 | 27 | 22 | 18.9 | 16.5 | 14.7 | 13.2 | |
| | 60 | 0.24 | 18.2 | 14.5 | 12.1 | 10.4 | 9.1 | 7.3 | 6.1 | 5.2 | 4.5 | 4.0 | 3.6 | | 60 | 0.61 | 46 | 36 | 30 | 26 | 23 | 18.2 | 15.2 | 13.0 | 11.4 | 10.1 | 9.1 | | 60 | 0.98 | 73 | 58 | 48 | 42 | 36 | 29 | 24 | 21 | 18.1 | 16.1 | 14.5 | |
| | 70 | 0.26 | 20 | 15.7 | 13.1 | 11.2 | 9.8 | 7.9 | 6.5 | 5.6 | 4.9 | 4.4 | 3.9 | | 70 | 0.66 | 49 | 39 | 33 | 26 | 25 | 20 | 16.4 | 14.0 | 12.3 | 10.9 | 9.8 | | 70 | 1.05 | 78 | 63 | 52 | 45 | 39 | 31 | 26 | 22 | 20 | 17.4 | 15.7 | |
| | 80 | 0.28 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 8.4 | 7.0 | 6.0 | 5.2 | 4.7 | 4.2 | | 80 | 0.71 | 53 | 42 | 35 | 30 | 26 | 21 | 17.5 | 15.0 | 13.1 | 11.7 | 10.5 | | 80 | 1.13 | 84 | 67 | 56 | 48 | 42 | 34 | 28 | 24 | 21 | 18.6 | 16.7 | |
| | 90 | 0.30 | 22 | 17.8 | 14.8 | 12.7 | 11.1 | 8.9 | 7.4 | 6.4 | 5.6 | 4.9 | 4.5 | | 90 | 0.75 | 56 | 45 | 37 | 32 | 28 | 22 | 18.6 | 15.9 | 13.9 | 12.4 | 11.1 | | 90 | 1.20 | 89 | 71 | 59 | 51 | 44 | 36 | 30 | 25 | 22 | 20 | 17.8 | |
| | 100 | 0.32 | 24 | 18.8 | 15.6 | 13.4 | 11.7 | 9.4 | 7.8 | 6.7 | 5.9 | 5.2 | 4.7 | | 100 | 0.79 | 59 | 47 | 39 | 34 | 29 | 24 | 20 | 16.8 | 14.7 | 13.1 | 11.7 | | 100 | 1.26 | 94 | 75 | 62 | 54 | 47 | 37 | 31 | 27 | 23 | 21 | 18.7 | |
| | 120 | 0.35 | 24 | 21 | 17.1 | 14.7 | 12.9 | 10.3 | 8.6 | 7.3 | 6.4 | 5.7 | 5.1 | | 120 | 0.87 | 64 | 52 | 43 | 37 | 32 | 26 | 21 | 18.4 | 16.1 | 14.3 | 12.9 | | 120 | 1.38 | 103 | 82 | 68 | 59 | 51 | 41 | 34 | 29 | 26 | 23 | 21 | |
| 025 | 20 | 0.18 | 13.1 | 10.5 | 8.7 | 7.5 | 6.6 | 5.2 | 4.4 | 3.7 | 3.3 | 2.9 | 2.6 | 08 | 20 | 0.42 | 32 | 25 | 21 | 18.0 | 15.8 | 12.6 | 10.5 | 9.0 | 7.9 | 7.0 | 6.3 | 08 | 20 | 0.57 | 42 | 34 | 28 | 24 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 9.3 | 8.4 | |
| | 30 | 0.22 | 16.1 | 12.9 | 10.7 | 9.2 | 8.0 | 6.4 | 5.4 | 4.6 | 4.0 | 3.6 | 3.2 | | 30 | 0.52 | 39 | 31 | 26 | 22 | 19.3 | 15.4 | 12.9 | 11.0 | 9.6 | 8.6 | 7.7 | | 30 | 0.69 | 51 | 41 | 34 | 29 | 26 | 21 | 17.1 | 14.7 | 12.9 | 11.4 | 10.3 | |
| | 40 | 0.25 | 18.5 | 14.8 | 12.4 | 10.6 | 9.3 | 7.4 | 6.2 | 5.3 | 4.6 | 4.1 | 3.7 | | 40 | 0.60 | 45 | 36 | 30 | 26 | 22 | 17.8 | 14.9 | 12.7 | 11.1 | 9.9 | 8.9 | | 40 | 0.80 | 59 | 47 | 39 | 34 | 30 | 24 | 20 | 16.9 | 14.8 | 13.1 | 11.8 | |
| | 50 | 0.28 | 21 | 16.6 | 13.8 | 11.9 | 10.4 | 8.3 | 6.9 | 5.9 | 5.2 | 4.6 | 4.1 | | 50 | 0.67 | 50 | 40 | 33 | 29 | 25 | 20 | 16.6 | 14.2 | 12.5 | 11.1 | 10.0 | | 50 | 0.89 | 66 | 53 | 44 | 38 | 33 | 27 | 22 | 18.9 | 16.5 | 14.7 | 13.2 | |
| | 60 | 0.31 | 23 | 18.2 | 15.1 | 13.0 | 11.4 | 9.1 | 7.6 | 6.5 | 5.7 | 5.0 | 4.5 | | 60 | 0.74 | 55 | 44 | 36 | 31 | 27 | 22 | 19.2 | 15.6 | 13.6 | 12.1 | 10.9 | | 60 | 0.98 | 73 | 58 | 48 | 42 | 36 | 29 | 24 | 21 | 18.1 | 16.1 | 14.5 | |
| | 70 | 0.33 | 25 | 20 | 16.4 | 14.0 | 12.3 | 9.8 | 8.2 | 7.0 | 6.1 | 5.5 | 4.9 | | 70 | 0.79 | 59 | 47 | 39 | 34 | 30 | 24 | 20 | 16.8 | 14.7 | 13.1 | 11.8 | | 70 | 1.05 | 78 | 63 | 52 | 45 | 39 | 31 | 26 | 22 | 20 | 17.4 | 15.7 | |
| | 80 | 0.35 | 26 | 21 | 17.5 | 15.0 | 13.1 | 10.5 | 8.7 | 7.5 | 6.6 | 5.8 | 5.2 | | 80 | 0.85 | 63 | 50 | 42 | 36 | 32 | 25 | 21 | 18.0 | 15.9 | 14.0 | 12.6 | | 80 | 1.13 | 84 | 67 | 56 | 48 | 42 | 34 | 28 | 24 | 21 | 18.6 | 16.7 | |
| | 90 | 0.37 | 28 | 22 | 18.5 | 15.9 | 13.9 | 11.1 | 9.3 | 7.9 | 7.0 | 6.2 | 5.6 | | 90 | 0.90 | 67 | 54 | 45 | 38 | 33 | 27 | 22 | 19.1 | 16.7 | 14.9 | 13.4 | | 90 | 1.20 | 89 | 71 | 59 | 51 | 44 | 36 | 30 | 25 | 22 | 20 | 17.8 | |
| | 100 | 0.40 | 29 | 24 | 20 | 16.8 | 14.7 | 11.7 | 9.8 | 8.4 | 7.3 | 6.5 | 5.9 | | 100 | 0.95 | 71 | 56 | 47 | 40 | 35 | 28 | 24 | 20 | 17.6 | 15.7 | 14.1 | | 100 | 1.26 | 94 | 75 | 62 | 54 | 47 | 37 | 31 | 27 | 23 | 21 | 18.7 | |
| | 120 | 0.43 | 32 | 26 | 21 | 18.4 | 16.1 | 12.9 | 10.7 | 9.2 | 8.0 | 7.1 | 6.4 | | 120 | 1.04 | 77 | 62 | 52 | 44 | 39 | 31 | 26 | 22 | 19.3 | 17.2 | 15.4 | | 120 | 1.38 | 103 | 82 | 68 | 59 | 51 | 41 | 34 | 29 | 26 | 23 | 21 | |
| 03 | 20 | 0.21 | 15.7 | 12.6 | 10.5 | 9.0 | 7.9 | 6.3 | 5.2 | 4.5 | 3.9 | 3.5 | 3.1 | 08 | 20 | 0.57 | 42 | 34 | 28 | 24 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 9.3 | 8.4 | 08 | 20 | 0.57 | 42 | 34 | 28 | 24 | 21 | 16.8 | 14.0 | 12.0 | 10.5 | 9.3 | 8.4 | |
| | 30 | 0.26 | 19.3 | 15.4 | 12.9 | 11.0 | 9.6 | 7.7 | 6.4 | 5.5 | 4.8 | 4.3 | 3.9 | | 30 | 0.69 | 51 | 41 | 34 | 29 | 26 | 21 | 17.1 | 14.7 | 12.9 | 11.4 | 10.3 | | 30 | 0.69 | 51 | 41 | 34 | 29 | 26 | 21 | 17.1 | 14.7 | 12.9 | 11.4 | 10.3 | |
| | 40 | 0.30 | 22 | 17.8 | 14.8 | 12.7 | 11.1 | 8.9 | 7.4 | 6.4 | 5.6 | 4.9 | 4.5 | | 40 | 0.80 | 59 | 47 | 39 | 34 | 30 | 24 | 20 | 16.9 | 14.8 | 13.1 | 11.8 | | 40 | 0.80 | 59 | 47 | 39 | 34 | 30 | 24 | 20 | 16.9 | 14.8 | 13.1 | 11.8 | |
| | 50 | 0.34 | 25 | 20 | 16.6 | 14.2 | 12.4 | 10.0 | 8.3 | 7.1 | 6.2 | 5.5 | 5.0 | | 50 | 0.89 | 66 | 53 | 44 | 38 | 33 | 27 | 22 | 18.9 | 16.5 | 14.7 | 13.2 | | 50 | 0.89 | 66 | 53 | 44 | 38 | 33 | 27 | 22 | 18.9 | 16.5 | 14.7 | 13.2 | |
| | 60 | 0.37 | 27 | 22 | 18.2 | 15.6 | 13.6 | 10.9 | 9.1 | 7.8 | 6.8 | 6.1 | 5.5 | | 60 | 0.98 | 73 | 58 | 48 | 42 | 36 | 29 | 24 | 21 | 18.1 | 16.1 | 14.5 | | 60 | 0.98 | 73 | 58 | 48 | 42 | 36 | 29 | 24 | 21 | 18.1 | 16.1 | 14.5 | |
| | 70 | 0.40 | 29 | 24 | 20 | 16.8 | 14.7 | 11.9 | 9.8 | 8.4 | 7.4 | 6.5 | 5.9 | | 70 | 1.05 | 78 | 63 | 52 | 45 | 39 | 31 | 26 | 22 | 20 | 17.4 | 15.7 | | 70 | 1.05 | 78 | 63 | 52 | 45 | 39 | 31 | 26 | 22 | 20 | 17.4 | 15.7 | |
| | 80 | 0.42 | 32 | 25 | 21 | 18.0 | 15.7 | 12.6 | 10.5 | 9.0 | 7.9 | 7.0 | 6.3 | | 80 | 1.13 | 84 | 67 | 56 | 48 | 42 | 34 | 28 | 24 | 21 | 18.6 | 16.7 | | 80 | 1.13 | 84 | 67 | 56 | 48 | 42 | 34 | 28 | 24 | 21 | 18.6 | 16.7 | |
| | 90 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

For booms with 10 in. nozzle spacing:



Example 20 in. (output per nozzle)

$$20 \text{ gal lqd/ac} \times 20 \text{ in.} \times 5 \text{ mph}$$

$$6000$$

$$= 0,34 \text{ gal/min}$$

Example 10 in. (output per 2 nozzles)

$$2 \times 20 \text{ gal lqd/ac} \times 10 \text{ in.} \times 5 \text{ mph}$$

$$6000$$

$$= 0,34 \text{ gal/min}$$


Pressure ranges of different nozzles

| Nozzle type | Nozzle size | Permissible pressure range psi (bar) | |
|--------------------|-------------|--------------------------------------|---------------|
| | | min. pressure | max. pressure |
| LU / XRC - nozzles | 015 | 14 (1) | 22 (1.5) |
| LU / XRC - nozzles | 02 | 14 (1) | 36 (2.5) |
| LU / XRC - nozzles | 03 | 14 (1) | 44 (3.0) |
| LU / XRC - nozzles | 04 - 08 | 14 (1) | 73 (5.0) |
| AD / DG / TT | all sizes | 22 (1.5) | 87 (6) |
| AI | all sizes | 29 (2) | 116 (8) |
| ID | all sizes | 29 (2) | 116 (8) |
| Air-Mix nozzles | all sizes | 14 (1) | 87 (6) |
| IDK / IDKN | all sizes | 14 (1) | 87 (6) |
| TTI | all sizes | 14 (1) | 87 (6) |
| AVI | all sizes | 29 (2) | 116 (8) |


Permissible pressure ranges of different nozzle types and nozzle sizes

Fluid circuit

Design of water system Basic and water system CCS



- | | |
|---|---|
| 1 Injector | 21 PowerFill active filling pump (optional) |
| 2 Switch-over ball valve outside/internal cleaning (optional) | 22 Direct filling / residue drain |
| 3 Outside cleaning (optional) | 23 Fresh water filling |
| 4 Manual pressure filter flushing | 24 Filter NightLight cleaning (optional) |
| 5 Pressure filter drain | 25 High pressure cleaner (optional) |
| 6 3-way valve pressure filter | 26 Electrical pump NightLight cleaning (optional) |
| 7 Pressure filter drain | 27 NightLight with cleaning (optional) |
| 8 Pressure filter | 28 Cleaning centrifugal pump only with water system CCS |
| 9 Pressure filter | 29 Switch-over ball valve fresh water/solution suction |
| 10 Flow meter | 30 Suction filter with drain valve |
| 11 3-way valve circulation | 31 Centrifugal pump |
| 12 Pressure sensor | 32 Pressure sensor |
| 13 Folding boom | 33 Pressure output |
| 14 Internal cleaning | 34 Mechanical 6-way valve on pressure side |
| 15 Illuviation valve | 35 Air valve (optional) |
| 16 Spraying mixture container | 36 Agitator intensity |
| 17 Agitator | 37 Valve spraying mixture container drain |
| 18 Fresh water tank | 38 Pressure filter cleaning mechanically (intensity adjustable) or electrically |
| 19 Eco Fill | 39 Switch-over ball Illuviation valve / Fresh water tank filling |
| 20 External filling front right (optional) | |



Filling

Several filling variants are available.

Variant 1:

Standard port **(22)**, this connection can only be used for light suction, or the sucked in material must be at the same height as the spraying pump. (Water tower) This option allows fluid to be pumped directly into the spraying mixture container **(16)** or through any other pressure output into the spraying mixture container. Illuviation valve, circulation line/agitator, internal cleaning. Turn the pressure valve **(34)** to the desired position for this purpose.

Variant 2: Optionally via direct filling port **(20)**. The sucked in fluid can be transported directly into the spraying mixture container **(16)** via an external pump.

Variant 3:

The fluid can be sucked in and transported directly into the spraying mixture container via port **(20)** and the optionally installed pump **(21)**.

Filling the fresh water tank:

Variant 1:

fill with external pressure via port **(23)**.

Variant 2:

If the brewing tank is filled via port **(22)**, the pressure valve **(34)** can be set to Illuviation valve. At the same time, set the tap **(39)** to Fill fresh water.

CAUTION


In the suction line to the pump, in the pump itself or in the supply line to the Illuviation valve, there may still be spray agent or deposits. When changing the valve **(39)**, contaminated fresh water can be pumped into the fresh water tank!

- If necessary, flush the lines thoroughly before filling the fresh water tank!


Illuviation valve (15) pressure output:

This sucks in preparations from the illuviation valve into the spraying mixture container.

The fluid supplies the rinsing nozzles (40) and the shock nozzles (42) and canister flushing (41) of the illuviation valve.

**Spraying operation**

The spraying pump (31) sucks in fluid through the suction fitting (29) from the spraying mixture container (16) (spraying operation) or from the fresh water tank (18) (cleaning of the spraying system).




Spraying operation

Turn the pressure valve (34) to spraying operation.

In spraying operation the sucked in fluid is directed through the pressure filter (8, 9) and the flow meter (10) into the folding boom (13).

The circulation valve (11) is in position (a), so that pressure builds up in the spraying line and the wash is pressed to the nozzles from both sides.



Circulation

With the nozzles switched off, the circulation valve (11) is in position (b), so that the wash flows through the circulation system back into the spraying mixture container. This prevents the formation of deposits. Wash is immediately available at the nozzles when switching on.


Due to the permanent circulation of the biocatalytic solution through the complete spraying line, wash is constantly present at all nozzles while the nozzles are switched off.

Even when switching on individual sections or the entire spraying line for the first time, the biocatalytic solution is directly and well mixed available.


This circulation successfully prevents the formation of deposits and blockage.

Fluid circuit

Design of Water system Basic Pro and water system CCS Pro



- | | |
|--|---|
| 1 Injector | 22 PowerFill active filling pump (optional) |
| 2 Switch-over ball valve outside/internal cleaning (optional) | 23 Direct filling / residue drain |
| 3 Outside cleaning (optional) | 24 Fresh water filling |
| 4 Electrical pressure filter flushing | 25 Filter NightLight cleaning (optional) |
| 5 Pressure filter drain | 26 High pressure cleaner (optional) |
| 6 3-way valve pressure filter | 27 Electrical pump NightLight cleaning (optional) |
| 7 Pressure filter drain | 28 NightLight with cleaning (optional) |
| 8 Pressure filter | 29 Cleaning centrifugal pump only at CCS Pro |
| 9 Pressure filter | 30 Fresh water suction |
| 10 Flow meter | 31 Spraying mixture suction |
| 11 3-way valve circulation | 32 Suction filter with drain valve |
| 12 Pressure sensor | 33 Centrifugal pump |
| 13 Folding boom | 34 Pressure sensor |
| 14 Internal cleaning | 35 Pressure output |
| 15 Illuviation valve | 36 Internal cleaning pressure output |
| 16 Spraying mixture container | 37 Agitator pressure output |
| 17 Agitator | 38 Illuviation valve pressure output |
| 18 Fresh water tank | 39 Folding boom pressure output |
| 19 Eco Fill | 40 Filling pressure output |
| 20 External filling front right (optional) | 41 Air valve (optional) |
| 21 Switch-over ball valve illuviation valve/fresh water tank filling | 42 External suction |
| | 43 Pressure filter cleaning mechanically (intensity adjustable) or electrically |



Filling

Several filling variants are available.

Variant 1:

Standard port **(23)**, this connection can only be used for light suction, or the sucked in material must be at the same height as the spraying pump. (Water tower) This option allows fluid to be pumped directly into the spraying mixture container **(16)** or through any other pressure output into the spraying mixture container. Illuviation valve, circulation line/agitator, internal cleaning. For this purpose, select the different variants on the external operating terminal.

Variant 2: Optionally via direct filling port **(20)**. The sucked in fluid can be transported directly into the spraying mixture container **(16)** via an external pump.

Variant 3:

The fluid can be sucked in and transported directly into the spraying mixture container via port **(20)** and the optionally installed pump **(22)**.

Filling the fresh water tank:

Variant 1:

fill with external pressure via port **(23)**.

Variant 2:

Switch on suction externally at the external operating terminal. Switch on the illuviation valve when the remaining brew has been displaced by the lines into the brew tank. Switch valve **(21)** to fill with fresh water. Then fill the fresh water tank.

CAUTION


In the suction line to the pump, in the pump itself or in the supply line to the illuviation valve, there may still be spray agent or deposits. When changing the valve **(21)**, contaminated fresh water can be pumped into the fresh water tank!

➤ If necessary, flush the lines thoroughly before filling the fresh water tank!


Illuviation valve (15) pressure output:

This sucks in preparations from the illuviation valve into the spraying mixture container.

The fluid supplies the rinsing nozzles (44) and the shock nozzles (45) and canister flushing (46) of the illuviation valve.

**Spraying operation**

The spraying pump (33) sucks in fluid through the suction fitting (30 resp. 42) from the spraying mixture container (16) (spraying operation) or from the fresh water tank (18) (cleaning of the spraying system).




Spraying operation

Activate the circulation on the terminal for this purpose.

In spraying operation the sucked in fluid is directed through the pressure filter (8, 9) and the flow meter (10) into the folding boom (13).

The circulation valve (11) is in position (a), so that pressure builds up in the spraying line and the wash is pressed to the nozzles from both sides.



Circulation

With the nozzles switched off, the circulation valve (11) is in position (b), so that the wash flows through the circulation system back into the spraying mixture container. This prevents the formation of deposits. Wash is immediately available at the nozzles when switching on.

Due to the permanent circulation of the biocatalytic solution through the complete spraying line, wash is constantly present at all nozzles while the nozzles are switched off.

Even when switching on individual sections or the entire spraying line for the first time, the biocatalytic solution is directly and well mixed available.

This circulation successfully prevents the formation of deposits and blockage.

Filling with water

NOTE

When filling, pay attention to the permissible payload of your crop protection sprayer!

When filling the crop protection sprayer you must strictly pay attention to the different specific densities [lb/gal] ([kg/l]) of the individual fluids!

| Fluid | Density lb/gal [kg/l] |
|--|-----------------------|
| Water | 8.34 (1) |
| Carbonyl diamide | 9.3 (1.11) |
| Ammonium nitrate - carbonyl diamide solution | 10.65 (1.28) |
| NP-solution | 11.50 (1.38) |

Example: With 1055 gal. (4000 l) ammonium nitrate - carbonyl diamide solution the spraying mixture container is filled with a mass of $1057 \text{ gal} \times 10.65 \text{ lb/gal} = 11257 \text{ lb}$ ($4000 \text{ l} \times 1.28 \text{ kg/l} = 5120 \text{ kg}$)!

The crop protection sprayer can be filled via the filling ports or the dome.

WARNING

Danger to persons / animals due to accidental contact with spraying mixture when filling the spraying mixture container!

- The national and country-specific regulations for filling crop protection sprayers must be observed!
- Wear your personal protective outfit when processing crop protection agents or draining spraying mixture from the spraying mixture container.

The required personal protective outfit depends on the information of the manufacturer, the product information, the instructions for use, the safety data sheet or the operating instructions for the crop protection agent to be used.

- Before each filling check the crop protection sprayer for damage, e.g. leaking tanks and hoses as well as the correct positioning of all operating elements. Never leave the crop protection sprayer unattended during filling.
- Never exceed the rated volume when filling the spraying mixture container.
- Never exceed the permissible payload of the crop protection sprayer when filling the spraying mixture container.
- Pay attention to the specific weight of the fluid to be filled in.
- When filling constantly keep an eye on the level gauge to avoid overfilling of the spraying mixture container.
- When filling the spraying mixture container pay attention to sealed surfaces, so that no wash runs into the sewer system.
- No foam must escape from the spraying mixture container during filling.

A large cross-section funnel that reaches down to the bottom of the spraying mixture container most effectively prevents the formation of foam.

Adding an anti-foaming agent will also prevent overflowing of foam of the spraying mixture container.

Filling via the dome

- Fasten the end of the filling hose at least 3 in. (100 mm) above the dome of the spraying mixture container.
- The free outflow created this way offers the highest level of safety against the back flow of spraying mixture into the drinking water line. The dome screen must always be inserted in the spraying mixture container.

Filling the spraying mixture container through the filling port

Water systems Basic Pro and water system CCS Pro

The national laws and relevant regulations for filling the spraying mixture container via the suction hose from open water tapping points must be complied with.

- The sucked in preparation must be at the same level as the spraying pump and flow into the pump on its own.
- Always keep an eye on the level gauge while filling.
- Stop filling the spraying mixture container at the latest when the filling limit has been reached.



Filling port for spraying mixture container


1. Enter the desired container content in the terminal.
2. Connect the suction hose to the filling connection.
3. Open the filling valve.
4. Start the filling process via the external control terminal.
5. The suction fitting switches off automatically when the desired filling level is reached.
The filling process can be aborted at any time.
6. Using the *Pulling suction* function on the external control terminal, the supply line to the filling valve can be sucked empty.

7. Close the filling valve.
8. Uncouple the suction hose.
9. Close the connection with the cap.

Water systems Basic and water system CCS

The national laws and relevant regulations for filling the spraying mixture container via the suction hose from open water tapping points must be complied with.

- The sucked in preparation must be at the same level as the spraying pump and flow into the pump on its own
- Always keep an eye on the level gauge while filling.
- Stop filling the spraying mixture container at the latest when the filling limit has been reached.




Filling port for spraying mixture container and pressure side valve

1. Connect the suction hose to the filling connection.
2. Open the filling valve.
3. Move the valve to the desired position.
4. Start the filling process via the external control terminal.
5. The filling process can be aborted at any time.
6. Using the *Pulling suction* function on the external control terminal, the supply line to the filling valve can be sucked empty.
7. Close the filling valve.
8. Uncouple the suction hose.
9. Close the connection with the cap.

Direct filling / External filling (optionally without pump)

At the direct filling port fluid from an external tank can be pressed directly into the spraying mixture container.

- Always keep an eye on the level gauge while filling. No automatic shut-down when the spraying mixture container is full!
- Stop filling the spraying mixture container at the latest when the filling limit has been reached.
- Pay attention to the max. permissible flow rate. It must not exceed 264 gal lqd/min (1000 l/min).



Direct filling port (right side of machine), filter optional)

1. Connect the filling hose.
2. Open the filling valve.
3. Fill the spraying mixture container.
4. Close the filling valve.
5. Uncouple the hose.
6. Close the connection with the cap.

Direct filling / External filling (optionally with PowerFill pump)

At the direct filling port fluid from an external tank can be pressed directly into the spraying mixture container.

- Always keep an eye on the level gauge while filling. No automatic shut-down when the spraying mixture container is full!
- Stop filling the spraying mixture container at the latest when the filling limit has been reached.



Suction port (right side of machine)


1. Connect the filling hose.
2. Open the filling valve.
3. Start pump via the external control panel.
4. Stop pump at desired tank content via the external control panel.
5. Close the filling valve.
6. Uncouple the hose.
7. Close the connection with the cap.

Filling via the dome

- Always keep an eye on the level gauge while filling. No automatic shut-down when the spraying mixture container is full!
 - Stop filling the spraying mixture container at the latest when the filling limit has been reached.
1. Determine the exact filling quantity. Refer to the chapter *Calculating filling/refill quantities*.
 2. Open the lid of the dome from the platform.
 3. Fill the spraying mixture container through the filling opening using a water line with "free outflow".
 4. Stop filling the spraying mixture container as soon as the filling limit has been reached.
 5. Close the lid of the dome from the platform.



Dome (figure may vary according to the machine)



Dome screen and dome cleaning nozzle (figure may vary according to the machine)

NOTE

The dome screen must be checked daily and cleaned as necessary!

Filling the fresh water tank through the filling port


WARNING

Avoid impermissible contamination of the fresh water tank with crop protection agent or spraying mixture!

NOTE

Fill the fresh water tank only with clear water, never with crop protection agent or spraying mixture!

- Always keep an eye on the level gauge while filling. No automatic shut-down when the fresh water tank is full!
- Stop filling the fresh water tank at the latest when the filling limit has been reached.



Filling connection for fresh water tank

1. Connect the filling hose.
2. Open the filling valve.
3. Fill the fresh water tank.
4. Close the filling valve.
5. Uncouple the hose.
6. Close the connection with the cap.

Always have a sufficient amount of fresh water on board when using the crop protection sprayer. When filling the spraying mixture container check and refill also the fresh water tank.

Illuviation of preparations

Illuviation valve

DANGER

Wear appropriate protective outfit for the illuviation of the preparations.

Observe the regulations and notes as well as the safety data sheet of the crop protection agent manufacturer!

NOTE

Turn on the agitator for filling and the illuviation of preparations. To maintain a homogeneous mix, the agitator should remain activated until the spraying operation is finished. The intensity of the agitator can be set via the external control terminal.


Observe the regulations and notes of the crop protection agent manufacturer!

NOTE


Depending on the position of the ball valve of the suction side, water exits from the fresh water tank or spraying mixture from the spraying mixture container on the illuviation valve.

Crop protection agent and carbonyl diamide are poured into the illuviation valve, dissolved and drawn in.

Swing the illuviation valve down by pulling it by the handle.



Flush the respective preparation through the illuviation valve into the water of the spraying mixture container. A difference is in this case made between the illuviation of fluid and powdery preparations or carbonyl diamide.



- 1 Activate/deactivate the canister flushing
- 2 Activate/deactivate the washing gun
- 3 Activate/deactivate the shock nozzles
 - The shock nozzles support the illuviation of difficult to dissolve crop protection agents.
 - Two rinsing nozzles and the shock nozzles in the lower area of the Illuviation valve are activated.
- 4 Activate/deactivate the washing nozzles
- 5 Switch-over ball valve for sucking-off and external filling devices

NOTE

Care must be taken when cleaning the illuviation valve that no undesirable point-type entries of preparations are generated!

Flushing in liquid preparations during filling


Water systems Basic Pro and water system CCS Pro

1. Enter the desired container capacity in the terminal
2. Connect the suction hose to the filling connection and open the filling valve.



Filling port/filling valve

3. Start filling via terminal.
4. Switch on the illuviation valve on the terminal.
5. Open the lid on the illuviation valve.
6. Fill the preparation quantity calculated and measured for filling the tank into the illuviation valve.
7. Turn the switch-over ball valve (5) to the position for sucking-off. Have the content completely sucked off from the illuviation valve.
8. Close the switch-over ball valve (5) again. The process may need to be repeated if the required preparation could not be filled in during a single process.
9. Pre-clean the illuviation valve with the rinsing nozzles (4).
10. Open the switch-over ball valve (5) and have the contents sucked off.
11. Close the switch-over ball valve (5) again.
12. Switch off the illuviation valve on the terminal.
13. Top up the water shortfall.
14. Adjust the desired agitator power.



During the filling process the water sucked in through the suction hose is present at the illuviation valve.


Once the desired tank content is reached, the suction valve will automatically switch over to the spraying mixture container. Solution is then present at the illuviation valve.

Use the washing gun to remove any residues from the illuviation valve. Pull lever (2) and operate the gun.

Make sure that no undesired point-type entries of preparation are generated!

Water systems Basic and water system CCS


1. Enter the desired container capacity in the terminal.
2. Connect the suction hose to the filling connection and open the filling valve.



Filling connection

3. Turn the suction side valve to the desired tank.
4. Set the pressure side valve to illuviation valve.
5. Switch on the spraying pump on the terminal.
6. Open the lid on the illuviation valve.
7. Fill the preparation quantity calculated and measured for filling the tank into the illuviation valve.
8. Turn the switch-over ball valve (5) to the position for sucking-off. Have the content completely sucked off from the illuviation valve.
9. Close the switch-over ball valve (5) again. The process may need to be repeated if the required preparation could not be filled in during a single process.
10. Pre-clean the illuviation valve with the rinsing nozzles (4).
11. Open the switch-over ball valve (5) and have the contents sucked off.
12. Close the switch-over ball valve (5) again.
13. Set the pressure/suction side valves to the desired position.
14. Switch off the spraying pump on the terminal.
15. Top up the water shortfall.

16. Adjust the desired agitator power.




During the filling process the water sucked in through the suction hose is present at the illuviation valve.

Stop filling when the desired tank content has been reached.

Use the washing gun to remove any residues from the illuviation valve. Pull lever (2) and operate the gun.

Make sure that no undesired point-type entries of preparation are generated!

Flushing in liquid preparations with full or partly filled spraying mixture container



1. Open the lid on the illuviation valve.
2. Machines of the Basic Pro and CCS Pro variants: Switch on the illuviation valve on the terminal.

Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.
3. Fill the preparation quantity calculated and measured for filling the tank into the illuviation valve.
4. Turn the switch-over ball valve (5) to the position for sucking-off. Have the content completely sucked off from the illuviation valve.
5. Close the switch-over ball valve (5) again. The process may need to be repeated if the required preparation could not be filled in during a single process.
6. Pre-clean the illuviation valve with the rinsing nozzles (4).
7. Open the switch-over ball valve (5) and have the contents sucked off.
8. Clean the illuviation valve with the washing gun.
9. Close the switch-over ball valve (5) again.

10. Machines of the Basic Pro and CCS Pro variants: Switch off the illuviation valve on the terminal again.

Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.

11. Adjust the desired agitator power.

Illuviation of powdery preparations and carbonyl diamide



Exercise particular caution when handling powdery preparations or carbonyl diamide! Wear personal protective outfit! Observe the regulations and notes of the crop protection agent manufacturer!

Before spraying completely dissolve the carbonyl diamide by the activated agitator. Major temperature lowering of the spraying mixture occurs when dissolving larger quantities of carbonyl diamide. As a result, the carbonyl diamide dissolves only slowly. The warmer the water, the quick and better the dissolving of carbonyl diamide.


1. Fill the spraying mixture container with approx. 132 gal lqd (500 litres) of water.
2. Machines of the Basic Pro and CCS Pro variants: Switch on the illuviation valve on the terminal.

Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.
3. Open the lid on the illuviation valve.
4. Turn the switch-over ball valve (5) to the position for sucking-off.
5. Turn on the rinsing nozzles (4).
6. Turn on the shock nozzles (3).
7. Fill the preparation quantity calculated and measured for filling the tank slowly into the illuviation valve.
8. Clean the illuviation valve with the washing gun.

9. Close the switch-over ball valve (5) again.
10. Machines of the Basic Pro and CCS Pro variants: Switch off the illuviation valve on the terminal again.
Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.
11. Top up the water shortfall.
12. Adjust the desired agitator power.

Canister cleaning

Pre-cleaning the canister with spraying mixture



1. Open the lid on the illuviation valve.
2. Machines of the Basic Pro and CCS Pro variants: Switch on the illuviation valve on the terminal.
Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.
3. Set the switch-over ball valve (5) to sucking-off.
4. Switch on canister flushing (1).
5. Put the canister or any other container over the canister flushing facility and press it down for at least 30 seconds. Turn the containers during this process.
6. Turn off canister flushing (1) again.
7. Close the switch-over ball valve (5) again.

8. Machines of the Basic Pro and CCS Pro variants: Switch off the illuviation valve on the terminal again.

Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.

NOTE

Water or chemical emerges from the canister flushing nozzle, when the pressure plate is pressed down.

Canister cleaning with fresh water

NOTE

Cleaning the canisters with fresh water dilutes the spraying mixture concentration!

1. Open the lid on the illuviation valve.
2. Machines of the Basic Pro and CCS Pro variants: To be able to use clean water for illuviation, the *Recirculate fresh water* function on the terminal and the *Illuviation valve* must be activated.
Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.
➤ Switch on the illuviation valve on the terminal. The spraying pump starts automatically.
3. Set the switch-over ball valve (e) to sucking-off.
4. Switch on canister flushing (a).
5. Put the canister or any other container over the canister flushing facility and press it down for at least 30 seconds. Turn the containers during this process.
6. Turn off canister flushing (a) again.
7. Clean the illuviation valve with the washing gun.
8. Close the switch-over ball valve (e) again.

9. Machines of the Basic Pro and CCS Pro variants: Deactivate the *Recirculate fresh water* function and switch off the illuviation valve on the terminal.

Machines of the Basic and CCS variants: Adjusting the pressure/suction valves. Refer to the section *Liquid preparations during filling*.



NOTE

Water exits from the canister flushing, when the pressure plate is pressed down.

Empty preparation containers

- Thoroughly wash out empty preparation containers, make them unusable, collect them and dispose of according to regulations. Do not use for other purposes.
- If only spraying mixture is available for cleaning the preparation containers, you should just use this for preliminary cleaning.

Thoroughly clean if clear water is available, e.g. before preparing the next spraying mixture container filling or when diluting the residual quantity of the last spraying mixture container filling.

Close the lid of the illuviation valve again after all preparations have been flushed in and the illuviation valve and all containers have been cleaned. Swivel the illuviation valve again upward to the transport position with the handle.

Spraying operation

- Before starting the spraying operation exactly determine the necessary **application quantity** by using the instructions for use issued by the crop protection agent manufacturer.
- Enter the required application quantity (nominal quantity) into the **terminal** before starting the spraying operation.
- Strictly adhere to the required application quantity [gal lqd/ac]/[l/ha] during spraying operation,
 - to achieve an optimal treatment success with this crop protection measure.
 - to avoid unnecessary impact on the environment.
- Choose the required **nozzle type** from the spraying table before starting spraying – under due consideration of the
 - intended travel speed.
 - required application quantity.
 - required atomizing characteristic (fine, medium, or large drops) of the crop protection agent used for the crop protection measure to be carried out.
 - recommended distances.
 - See also chapter *Nozzle selection*.
- Choose the required **nozzle size** from the spraying table before starting spraying – under due consideration of the
 - intended travel speed.
 - required application quantity.
 - Planned spraying pressure.
 - See also chapter *Nozzle selection*.
- Choose a slow travel speed and a low spraying pressure to prevent losses by windward drifting!
 - See also chapter *Nozzle selection*.
- Apply additional measures for windward drift reduction at wind speeds of 9 ft/sec (3 m/s).
 - See chapter *Measures for windward drift reduction*.
- Do not apply at average wind speeds higher than 16 ft/sec (5 m/s).
- Switch the nozzles on and off only when driving to avoid overdosing.
- Avoid overdosing caused by overlapping
 - in case of inaccurate joining passes from one spraying track to the next and/or
 - when cornering at the headland with spraying boom switched on!
- Switch off the outer sections if the edge of the cultivation area runs at an angle to the cultivation area.
- During spraying operation keep an eye on the actual spraying mixture consumption in relation to the treated area. In case of discrepancies between the actual and the displayed placing quantity calibrate the flow meter.
 - Teach procedures must be carried out by HORSCH service staff.
- In case of deviations between the actual and the displayed distance calibrate the position sensor (pulses per 328 ft = 100 m). This activity should always be executed in the field.
 - Teach procedures must be carried out by HORSCH service staff.
- In case of weather related interruptions of spraying operation it is mandatory to clean filters, pump, fitting and spraying lines!

Folding boom control

WARNING

Danger of crushing and impact for persons staying in the danger zone when lifting or lowering for height adjustment of the spraying boom!

Instruct persons to leave the danger zone around the machine before lifting or lowering the spraying boom by means of the height adjustment.

NOTE

Adjust the spraying height (distance between nozzles and crop) as per currently applicable guidelines.

Always adjust the spraying boom parallel to the ground because the specified spraying height can only be achieved in this condition.

Control and regulation of spraying functions

Spraying pressure, nozzle size, placing quantity, travel speed, agitator

The spraying mixture container is empty when the spraying pressure suddenly drops significantly.

Should the spraying pressure drop under otherwise unchanged conditions, the suction or pressure filters are blocked.

Spraying pressure and nozzle size have an influence on the drop size and the sprayed-out fluid volume.

The higher the spraying pressure, the smaller the drop diameter of the sprayed spraying mixture. The smaller droplets are subject to higher, undesired windward drift!

- Increasing the spraying pressure also increases the placing quantity.
- Decreasing the spraying pressure also reduces the placing quantity.

Increasing the travel speed while leaving both nozzle size and spraying pressure unchanged, reduces the placing quantity.

Reducing the travel speed while leaving both nozzle size and spraying pressure unchanged, increases the placing quantity.

The travel speed is freely selectable, based on the automatic, area-related placing quantity control.

The agitator normally remains switched on from filling to the end of spraying. Observe the regulations and notes of the crop protection agent manufacturer.

Example:

Required application quantity: 21 gal lqd/ac
(200 l/ha)

Intended travel speed: approx. 5 mph
(8 km/h)

Nozzle type: AI / ID

Nozzle size: 03

Permissible pressure range for the installed spraying nozzles: min 44 psi
(3 bar)
max 116 psi
(8 bar)

Intended spraying pressure: 54 psi
(3.7 bar)

Permissible spraying pressures: 54 psi (3.7 bar)
±25%
40 psi (2.8 bar)
(min.) - 67 psi
(4.6 bar)
(max.)

Spraying

1. Switch on the terminal.
2. Adjust the agitator.
3. Prepare the spraying mixture as specified by the crop protection agent manufacturer and stir it up.
4. Unfold the spraying boom.
5. Set the working height of the spraying boom (distance between nozzles and plants) in dependence of the nozzles used according to the spraying table.
6. In the terminal check the value “min. pressure” and “max. pressure” for the permissible spraying pressure range (for the installed spraying nozzles).
7. Enter the value for “Nominal quantity” for the required application quantity into the terminal or check the stored value.
8. Switch on spraying via the terminal.



NOTE

Comply with the applicable country specific regulations! Comply with regulations concerning the distance to waters and adjacent areas!

Travelling to the field with the agitator switched on

- The intensity of the agitator can be adjusted via the terminal (depending on the variant).
- Switch on the agitator via the terminal (depending on the variant).

The required agitating power depends on the preparations used and must be checked by the user.

After filling the agitator may be set to maximum intensity to avoid separation during longer transport travels!

Before starting the spraying operation the stirring intensity set for travelling must be reset if it deviates from the stirring intensity required for spraying! Comply with the applicable country specific regulations!

Measures for windward drift reduction

- Schedule your work for early morning or evening (generally less wind).
- Reduce the spraying pressure.
- Choose bigger nozzles and higher water application quantities.
- Maintain the exact folding boom working height, because the risk of windward drift will increase considerably with increasing nozzle distance.
- Reduce the travel speed (to below 5 mph = 8 km/h).
- Use of so-called antidrift (AD) nozzles or injector (ID) nozzles (nozzles with a high proportion of coarse drops).
- Follow the distance instructions for the corresponding crop protection agent.

Spraying with 10 in. (25 cm) nozzle spacing and reduced target area distance

- The risk of windward drifting can be considerably reduced by reducing the target area distance to less than 20 in. (50 cm).
- This reduction of the target area distance is only possible with a continuous 10 in. (25 cm) nozzle pitch. Otherwise there is danger of strip formation caused by non-existing overlap of the spraying cones.
- A distance reduction is only possible if all nozzles used at a time are of the same type and the same size.
- The minimum target area distance corresponds to half the minimum target area distance for a corresponding 20 in. (50 cm) nozzle pitch.
- see nozzle manufacturer's data

Draining the spraying mixture container via the pressure output



Pressure output (figure varies depending on the machine type)

1. Couple a discharge hose with 2" Camlock coupling on the pressure output.
2. Open the ball valve.

NOTE

Drainage output can be controlled with the ball valve.

If the valve is fully open, the pump delivers with full output via the pressure output.

3. Switch on the circulation on the terminal.
4. Drain the spraying mixture container.
5. After drainage switch off the circulation to shut off the pump.
6. Close the ball valve and remove the discharge hose.
7. Close the pressure output with the cap.

Residual quantities

A differentiation is made between two types of residual quantities:

- **Excess residual quantity** after the end of spraying operation, e.g. resulting from errors in the calculation of the application quantity, in filling quantity or in spraying operation.
- **Technical residual quantities**, still remaining in the spraying mixture container, the suction fitting and the spraying line after a considerably drop in spraying pressure. The suction fitting consists of the assembly groups: switch-over ball valves, short lines and pump.

Technical residual quantities

Make sure that the residual quantity in the spraying line will be placed in the form of undiluted concentration. This is the case when switching to fresh water with the nozzles activated. Strictly spray this residual quantity from the spraying line on an untreated area. The residual quantity in the spraying line depends on the width of the boom.

Required travel distance in ft (m) to spray out the undiluted residual quantity in the spraying line for all working widths:

| gal lqd/ac (l/ha) | ft (m) |
|-------------------|----------|
| 11 (100) | 272 (83) |
| 16 (150) | 180 (55) |
| 21 (200) | 134 (41) |
| 27 (250) | 108 (33) |
| 32 (300) | 91 (28) |
| 43 (400) | 65 (20) |

Example:

With an application quantity of 21 gal lqd (200 l/ha) the travel distance to spray out the residual quantity is approx. 134 ft (41 m).

Draining technical residual quantities

NOTE

Make sure that the residual quantity in the spraying line will be sprayed out while the concentration is still undiluted.

- Spray this residual quantity from the spraying line on an untreated area.
- Refer to the chapter *Technical residual quantities* for the travel distance required to spray the residual quantity in the spraying line. The residual quantity in the spraying line depends on the working width of the folding boom.
- Once the residual quantity in the spraying mixture container has reached a level of only 26 gal lqd (100 litres) switch off the agitator to spray the spraying mixture container empty. With the agitator switched on the technical residual quantity increases in contrast to the specified values. With the water system Basic Pro and CCS Pro the agitator is automatically deactivated at a spraying mixture container content of less than 40 gal lqd (150 litres). With other water systems, the agitator must be switched off via the corresponding ball valves.
- Measures to protect the user must be applied when emptying residual quantities. Follow the instructions of the crop protection agent manufacturers and wear personal protective outfits.
- Dispose of the collected residual quantity of spraying mixture in accordance with the relevant statutory regulations.
- Collect the residual quantity of spraying mixture in suitable containers.
- Dispose of the residual quantity of spraying mixture with the stipulated waste disposal.

Draining technical residual quantities

Water systems Basic, CCS, Basic Pro and CCS Pro

The filling port is suitable for draining the technical residual quantities



Port with cap (figure varies according to the equipment)

1. Place a suitable collection vessel under the port for draining the residual quantity.
2. Take off the cap.
3. Open the valve.
4. Close the valve after draining is fully completed and close again with the cap.
5. Properly dispose of the collected residual quantity!

Diluted residual quantity

Perform the dilution and spraying out of residual quantity from the spraying mixture container after the end of spraying operation as follows:

Procedure

1. Spray the undiluted residual quantity from the spraying line on an untreated residual area.
2. Dilute the residual quantity in the spraying mixture container with 52 gal lqd (200 litres) of fresh water.
3. Spray the diluted residual quantity also on an untreated residual area.
4. Repeat steps 2 and 3 for a second (if necessary a third) time.

Diluting the residual quantity

Water systems Basic Pro and CCS Pro


1. Call up the *cleaning menu* on the main control terminal.
2. Select the submenu *Dilute spraying mixture* or *Recirculate fresh water in spraying mixture container*.
3. Select the ratio of fresh water to spraying mixture.
4. Start the process.

Water systems Basic and CCS

1. Turn the ball valve on the suction side to the fresh water position.
2. Turn the ball valve on the pressure side to the desired position.
3. Start the spraying pump on the terminal.
4. Stop the spraying pump when the desired spraying mixture tank content has been reached.
5. Turn the suction side valve to spraying mixture.

In case of multiple nozzle systems all existing nozzles must be opened for cleaning. There is danger of deposits if this instruction is not followed!

Draining the fresh water tank



Fresh water tank port (figure varies according to the equipment)

The port of the fresh water tank is located to the left of the irrigation valve. It serves to fill the fresh water tank and also to drain the fresh water. Remove the cap for drainage, open the ball valve and let the water drain out. Now shut the valve again and close the port with the cap.

WARNING

Danger of poisoning by contaminated water in the fresh water tank!

Do not use the water of the fresh water tank as drinking water!

Cleaning

WARNING

Danger of crushing, shearing, cutting, cutting off, being caught, winding up, being pulled in and impact caused by

- accidental lowering of lifted, unsecured machine parts.
- accidental starting and rolling of the machine.

Secure the machine against accidental starting and rolling before performing cleaning tasks on the machine.

Before starting cleaning work under the parallelogram of the folded folding boom, check the interlocking of the parallelogram.

WARNING

Danger of crushing, shearing, cutting, cutting off, being caught, winding up, being pulled in and impact caused by unprotected danger spots!

- Reattach protective features removed for cleaning the machine.
- Replace defective protective features with new ones. Use only HORSCH original parts.

CAUTION

Contamination with crop protection agents. Wear the personal protective outfit when cleaning the crop protection sprayer!

- Perform all maintenance work on the crop protection sprayer only after cleaning it.
- Pay particular attention to the brake, air and hydraulic lines.
- Never use gasoline, petroleum or mineral oils on brake, air and hydraulic oil lines.
- After cleaning, check all hydraulic lines for leaks and loose connections.
- Lubricate the crop protection sprayer after cleaning, especially after cleaning with a high pressure cleaner / steam jet or when using grease-dissolving cleaning agents.

- Pay attention to the statutory regulations concerning the handling and waste disposal of cleaning agents.
- Check for chafing and signs of damage. Remedy any faults immediately!
- Prior to working on the electrical system, disconnect it from the electric current supply.

Cleaning with high pressure cleaner / steam jet

NOTE

Do not clean **new machines** with a steam jet or high pressure cleaner.

The paint takes approx. 3 months to cure and could be damaged before this time.

Strictly observe the following points when cleaning with a high pressure cleaner/steam jet:

- Do not clean any electrical components.
- Do not clean any chrome-plated components.
- Before cleaning the machine cover all openings, which should stay clear of water, steam or cleaning agents for reasons of safety or functioning.
- Do not aim the water jet directly at electrical or electronic components and bearings. Keep the water jet at a distance of at least 60 in. (150 cm). Use only a flat jet.
- Do not direct the cleaning jet of the high pressure cleaner/steam jet directly on lubrication points and bearings, lines and stickers.
- Always keep a minimum distance of 12 in. (300 mm) between cleaning nozzle and machine.
- Avoid the use of dirt removing tools on the high pressure cleaner, if necessary, keep a greater distance.
- Pay attention to the safety regulations when using high pressure cleaners.

Cleaning the crop protection sprayer

NOTE

Regular cleaning of the crop protection sprayer is a prerequisite for proper maintenance and eases operation of the machine.

Service life and reliability of the crop protection sprayer essentially depend on the time the material of the crop protection sprayer is exposed to the crop protection agent.

- Keep the exposure time to the spraying mixture as short as possible, e.g. by daily cleaning after the end of spraying.
- Do not leave the spraying mixture for an unnecessary period of time in the spraying mixture container, e.g. not over night.
- Generally, clean the crop protection sprayer before placing a different crop protection agent.
- Dilute the residual quantity in the spraying mixture container and subsequently spray out the diluted residual quantity.
- Before the actual cleaning preliminarily cleaning of the crop protection sprayer should be done in the field.
- Dispose of any cleaning residues in an environmentally friendly manner each time after cleaning the crop protection sprayer.
- Disassemble the spraying nozzles at least once per season.
- Check the disassembled spraying nozzles for contamination, if necessary clean the nozzles with a soft brush.
- Flush the spraying lines without the spraying nozzles in place.

Cleaning the filters

A ring spanner for work on the pressure and suction filters is supplied with the machine. The ring spanner is located in the storage compartment at the left-hand side in the direction of travel.



Pressure filter

CAUTION

Spraying mixture running out! Wear personal protective outfit!

The pressure filter is located to the left of the illuviation valve.

The pressure value on the folding boom is shown on the terminal.

- Cleaning the filter daily.
- A warning appears on the terminal if the pressure differential is too high!
- Optionally, a second pressure filter may be installed in the middle section of the folding boom.



Pressure filter

1. Switch off the folding boom circulation.
2. Close the ball valve for folding boom supply.
3. For the water systems Basic Pro and CCS Pro operate the filter cleaning function on the external control panel.
4. For water systems Basic and CCS turn the pressure side valve to internal cleaning.
5. Drain the filter housing. Open the valve for this purpose. Collect used fluid and dispose of properly.
6. Unscrew the lid of the filter housing.
7. Remove the filter and clean/change it. Collect the deposits in a suitable tank and dispose of properly.
8. Insert the cleaned/new filter again and close the filter housing with the lid. Close the lock valve again.
9. For the water systems Basic Pro and CCS Pro deactivate the filter cleaning function on the external control panel again.

Suction filter

CAUTION

Spraying mixture running out! Wear personal protective outfit!

NOTE

- Clean the filter after suctioning contaminated water.
- The suction filter should be cleaned daily to prevent dirt deposits in it. In addition, the pressure output should be rinsed.

The suction filter is located to the left of the illuviation valve.




Centrifugal pump suction filter

1. For the water systems Basic Pro and CCS Pro operate the filter cleaning function on the external control panel. A note appears on the terminal that the filter can now be cleaned/replaced. Confirm the message with "ENTER".
2. For water systems Basic and CCS turn the suction side valve to the middle position/filter cleaning.
3. Drain the filter housing. Open the valve for this purpose. Collect used fluid and dispose of properly.
4. Unscrew the lid of the filter housing.
5. Remove the filter and clean/change it. Collect the deposits in a suitable tank and dispose of properly.
6. Insert the cleaned/new filter again and close the filter housing with the lid. Close the lock valve again.
7. For the water systems Basic Pro and CCS Pro deactivate the filter cleaning function on the external control panel again.

NOTE

Clean the thread of the filter housing if soiled.

The suction filter of the cleaning pump is located at the left behind the filling port.



Cleaning pump suction filter

1. Drain the fresh water tank.
2. Unscrew the lid of the filter housing.
3. Remove the filter and clean/change it. Collect the deposits in a suitable tank and dispose of properly.
4. Insert the cleaned/new filter again and close the filter housing with the lid.

CCS - Continuous inside cleaning (Continuous Cleaning System)

Continuous inside cleaning is a quick cleaning process of the crop protection sprayer without leaving the cabin.

Continuous inside cleaning is controlled from the driver's cabin.

Mode of operation: Principle of positive displacement instead of principle of dilution.

The additional centrifugal pump feeds clear water through the internal cleaning nozzles into the spraying mixture container. The spraying pump sucks in this water and uses it to force the chemical residue through the nozzles out of the pipeline system.

This means quick, thorough cleaning with optimised water consumption.



The initially placed residual quantity is undiluted (up to 10 gal lqd = 40 l). Place the residual quantity on an untreated surface!

- CCS cleaning is automatically included in the cleaning program.
- CCS Pro: CCS cleaning can only be carried out by starting the main cleaning program.
- CCS cleaning can be closed manually after thorough cleaning or it ends automatically when the fresh water tank contains no more water.

Start of CCS cleaning, see chapter *Cleaning the sprayer with drained tank*.



- The duration of the *Continuous Inside Cleaning* process depends on how heavily the crop protection sprayer is soiled with the crop protection agents used.
- Operate the CCS-function until only fresh water runs out of the nozzles.
- Follow the manufacturer instructions of the crop protection agents.

Cleaning with drained spraying mixture container



The initially placed residual quantity is undiluted. Therefore, place the residual quantity on an untreated surface!

Clean the spraying mixture container after use!

Main cleaning on machines of the CCS Pro variant:

1. Empty the spraying mixture container completely.
2. The fresh water tank must be filled with at least 80 gal lqd (300 litres) of water.
3. Call up the cleaning menu on the terminal.
4. Select the *Main cleaning* function in the sub-menu.
5. The border and edge nozzles can be cleaned as well, if necessary.
6. Start the program.

- When the program is running, the folding boom, quick filling valve, injector line, pressure filter, agitator and inside of the spraying mixture container are cleaned automatically.
 - The message appears on the terminal prompting to spray the residual quantity on an untreated residual area.
 - CCS cleaning starts.
7. CCS cleaning can be closed manually after thorough cleaning or it ends automatically when the fresh water tank and spraying mixture container contain no more water and the folding boom pressure is 0 psi (bar).

Main cleaning on machines of the CCS variant:

1. Empty the spraying mixture container completely.
2. The fresh water tank must be filled with at least 300 litres of water.
3. Set the ball valve on the suction side to spraying mixture container.
4. Set the ball valve on the pressure side to circulation/spraying.
5. Call up the cleaning menu on the terminal.
6. Select the Continuous Inside Cleaning function in the submenu.
7. The border and edge nozzles can be cleaned as well, if necessary.
8. Start the program.
- Approx. 6 gal lqd (25 litres) of fresh water is pumped into the spraying mixture container via internal cleaning.
- The message appears on the terminal prompting to spray the residual quantity on an untreated residual area.
- CCS cleaning starts.
9. CCS cleaning can be closed manually after thorough cleaning or it ends automatically when the fresh water tank and spraying mixture container contain no more water and the folding boom pressure is 0 psi (bar).

NOTE

In case of multiple nozzle bodies all existing nozzles must be cleaned. There is danger of deposits if this instruction is not followed!

Washing program for machines of the Basic Pro and CCS Pro variants:

1. Fill the spraying mixture container with approx. 26 gal lqd (100 l) of water.
2. Call up the cleaning menu on the terminal.
3. Select the *Washing program* function in the submenu.
4. Start the program.
5. Activate cleaning of the illuviation valve.
6. Set the switch-over ball valve on the illuviation valve to sucking-off.
7. Switch on the canister flushing nozzle and operate the canister flusher, using a suitable container, until only clear water runs out.
8. Switch on the rinsing nozzles until only clear water runs out.
9. Switch on the shock nozzle for approx. 10 sec.
10. Switch on the spray gun and spray into the tank until only clear water runs out.
11. Switch off the illuviation valve.
12. Stop cleaning after the desired time.
13. Switch on circulation.
14. Spray the diluted residual quantity on an untreated residual area.
15. Activate the *Air Valve* function, in order to clean the folding boom with air (optional).
16. Repeat steps 1-15 for a second time (if necessary, a third time) (dilution principle).
17. Cleaning suction and pressure filters.

Washing program for machines of the Basic and CCS variants:

1. Fill the fresh water tank with approx. 26 gal lqd (100 l) of water.
2. Set the ball valve on the suction side to fresh water tank.
3. Activate the pump.
4. Using the ball valve of the pressure side, direct filling, agitator, inside/outside cleaning, illuviation valve and folding boom can each be cleaned with fresh water.
5. When cleaning the illuviation valve, turn the switch-over ball valve to sucking-off.
6. Switch on the canister flushing nozzle and operate the canister flusher, using a suitable container, until only clear water runs out.
7. Switch on the closed circuit flushing until only clear water runs out.
8. Switch on the shock nozzle for approx. 10 sec. (only for illuviation valve from stainless steel).
9. Switch on the washing gun and spray into the tank until clear water runs out.
10. Switch off the pump after cleaning.
11. Set the ball valve on the pressure side to circulation/spraying.
12. Set the ball valve on the suction side to spraying mixture container.
13. Spray the diluted residual quantity on an untreated residual area.
14. Activate the "Air Valve" function, in order to clean the folding boom with air (optional).
15. Repeat steps 1-14 for a second time (if necessary, a third time) (dilution principle).
16. Cleaning suction and pressure filters.



NOTE

In case of multiple nozzle bodies all existing nozzles must be cleaned. There is danger of deposits if this instruction is not followed!

Cleaning with filled spraying mixture container



NOTE

The initially placed residual quantity is undiluted. Therefore, place the residual quantity on an untreated surface!

Clean the suction fittings and spraying line in case of weather-dependent interruptions of the spraying operation!

- Perform cleaning in the field by using water from the fresh water tank.
- Refer to the chapter *Technical residual quantities* for the travel distance required to spray this undiluted residual quantity.

Procedure for machines of the CCS Pro and Basic Pro variant:

1. Switch off the nozzles.
2. Call up the cleaning menu on the terminal.
3. Select the *Folding boom cleaning* function in the submenu.
4. Start the program.
5. A message on the terminal indicates that the required travel distance can be travelled with the nozzles activated (on untreated residual area).
6. The cleaning process ends automatically.
7. Activate the *Air Valve* function, in order to clean the folding boom with air (optional).

Procedure for machines of the CCS and Basic variant

1. Switch off the nozzles.
2. Set the ball valve on the suction side to fresh water tank.
3. Set the ball valve on the pressure side to folding boom.
4. Switch on the circulation on the terminal.
5. Drive the required travel distance with the nozzles switched on (on an untreated residual area).
6. Activate the "Air Valve" function, in order to clean the folding boom with air (optional).
7. Set the ball valve on the suction side to spraying mixture container.

NOTE

In case of multiple nozzle bodies all existing nozzles must be cleaned. There is danger of deposits if this instruction is not followed!

Folding boom cleaning with Air Valve (optional)

This function blows out the technical residual quantities left in the folding boom lines after the cleaning process.

This reduces deposits in nozzles and folding boom lines.

Blow-out process

1. Air reservoir of the machine must be filled.
2. Switch off all spraying functions. Switch off pressure agitator, internal cleaning, injector and spraying pump as well.
3. For machine of the CCS and Basic variant set the pressure side valve to folding boom.
4. Call up the cleaning menu on the terminal.
5. Select the *Air Valve* function in the submenu.
6. Start the program.
7. The blow-out process ends automatically.

8. Repeat the function if necessary, until no more fluid escapes from the nozzles.

NOTE

Depending on the spraying agent, the diaphragms may get stuck together. We therefore recommend performing *Folding boom cleaning* first. Refer to the section *Cleaning with filled spraying mixture container*.

Cleaning the spraying mixture container only for machines of the CCS and CCS Pro variant

The function pumps fresh water into the spraying mixture container for internal cleaning to prevent drying of the spraying mixture.

The function is enabled from a travel speed of 1.9 mph (3 km/h) and runs in the background of the entire machine functions.

In addition, the filling level of the spraying mixture container must lie below the internal cleaning nozzles and the inside wings must be unfolded.

1. Call up the cleaning menu on the terminal.
2. Select the *Clean spraying mixture container* function in the submenu.
3. Set the time of the interval.
4. Set the time per cleaning process.
5. Start cleaning.
6. On CCS machines, this cleaning is to be started only manually without time interval.

Outside cleaning (optional)

With outside cleaning, undesired contamination is removed and the unintentional dripping / draining of adhering crop protection agents is prevented.

⚠ NOTE

- Wear personal protective outfit during outside cleaning. Observe the regulations and notes of the crop protection agent manufacturers!
- Cleaning water must not enter surface water or the sewage system.
- Perform cleaning therefore on an unpaved and green area.


⚠ NOTE

Observe the position of the suction valve for CCS machines! Wash may possibly be sprayed if it is set to spraying mixture container. Likewise, the lines may still contain residual spraying mixture after switching the suction side to fresh water tank.

Outside cleaning is required:

- if the crop protection sprayer is soiled with spraying mixture.
- when changing the crop protection agent.
- before winter storage.
- before care / maintenance of the machine.

1. Switch off all spraying functions.
2. Turn the switch-over ball valve to outside cleaning.
3. Activate outside cleaning on page 3 on the external control terminal. or activate the pump for ABT mini
4. Pull the pressure hose off the reel and clean the machine with the washing gun.
5. Relieve the residual pressure after finishing cleaning. Wind up the pressure hose again on the reel and place the washing gun on the bracket.
6. Deactivate outside cleaning again on the external control terminal.
7. Turn the switch-over ball valve behind the illuviation valve again to internal cleaning.



Switch-over ball valve between internal and outside cleaning

Care and maintenance

WARNING

Danger of crushing, shearing, cutting, cutting off, being caught, winding up, being pulled in and impact caused by

- **accidental lowering of lifted, unsecured machine parts.**
- **accidental starting and rolling of the machine.**

Secure both tractor and crop protection sprayer against accidental starting and unintended rolling before you start care, service or maintenance work on the machine.

Before starting work under the parallelogram of the folded folding boom, check the interlocking of the parallelogram.

WARNING

Danger of crushing, shearing, cutting, cutting off, being caught, winding up, being pulled in and impact caused by unprotected danger spots!

- Reattach all protective features that were removed for the purpose of care, service and maintenance work on the machine.
- Replace defective protective features with new ones. Use only HORSCH original parts.

DANGER

- Observe all safety notes when carrying out care, service and maintenance work!
- Maintenance and/or repair work under raised, moveable machine parts must only be carried out, after these parts have been positively secured against accidental lowering with appropriate means.

CAUTION

Contamination with crop protection agents.

- Perform all maintenance work on the crop protection sprayer only after cleaning it.

NOTE

- Regular and proper maintenance will keep the crop protection sprayer for a long time in an operable state and prevents premature wear.

Your machine has been designed and built to offer maximum performance, economy and operator friendliness under a vast variety of operating conditions.

Before delivery the machine was inspected at the factory and by your dealer to make sure that it is in optimal condition. For trouble-free operation it is very important to carry out the necessary work for care and maintenance at the recommended intervals.

- Ensure that regular tests and inspections are always carried out to schedule as specified in the operating instructions.
- For service and maintenance work park the machine on level and solid ground, secure it against rolling away.
- Use only spare parts approved by HORSCH.
- Use only spare hoses approved by HORSCH and always use hose clamps made of V2A for assembly.
- When performing care and maintenance work pay attention to environmental protection measures.
- Strictly comply with the statutory regulations for the disposal of operating materials, such as oils and greases. These statutory regulations also apply to parts coming into contact with such operating materials.
- Initiate protective measures (e.g. cover or even disassemble lines at particularly critical points)
 - when welding, drilling or grinding
 - when working with abrasive cutting wheels in the vicinity of plastic hoses and electric lines.

- Thoroughly clean the crop protection sprayer before each repair or maintenance, especially the parts contaminated by the spraying mixture.
- Carry out repairs only on machines shut down and secured against restarting.
- Switch off the main battery switch with all care and maintenance work.
This applies in particular to welding work on the machine. The ground connection must be as close as possible to the welding point.
- Retighten screw connections loosened for care and maintenance work.

Appropriate expert knowledge is the prerequisite for the performance of tests and maintenance work. This expert knowledge cannot be obtained from these operating instructions!

The following is generally prohibited:

- drilling on the undercarriage
- enlarging existing boreholes on the vehicle frame
- welding on load-bearing parts

Conversions affect specifications in the operating instructions.



NOTE

Before each commissioning

- Check hoses, pipes and connecting pieces for apparent faults or leaking connections.
- Remedy chafed sections on hoses and pipes.
- Immediately replace worn or damaged hoses and pipes.
- Seal leaking connections immediately.

Maintenance intervals

The maintenance intervals are determined by many different factors.

For example, the different operating conditions, weather impact, travel and working speeds, dust accumulation and type of soil, crop protection agents and carbonyl diamide agents used, etc. affect the maintenance intervals. The quality of the lubricants and cleaning agents also affects the time to the next care activities.

The specified maintenance intervals therefore only serve as a reference.

In case of deviations from normal operating conditions the intervals must be adapted accordingly.

Regular maintenance is the basis for a fully operable machine. Properly serviced machines reduce the risk of failing and ensure economical use and operation of the machines.

Lubricating the machine

The machine should be lubricated at regular intervals and after each cleaning action. This ensures operability and reduces repair costs and downtimes.



Hygiene

Lubricants and mineral oil products are not harmful to health as long as they are used as instructed.

Prolonged skin contact or the inhalation of vapours should, however, be avoided.

Handling lubricants

Wear gloves or use protective creams to protect against direct contact with oils.

Thoroughly clean any oil off your skin by washing with warm water and soap.

Lubricate / grease the machine at the indicated intervals. Carefully clean lubrication points and grease gun before lubricating, so that no dirt is pressed into the bearings. Press the used up grease completely out of the bearings and replace it with fresh grease!

Lubricants



- A lithium-saponified multi-purpose grease with EP additives must be used for lubrication tasks.
- Use only cleaned hydraulic oil that complies with the demanded cleanliness class:
 - Cleanliness class 9 as per NAS 1638
 - Cleanliness class 18/16/13 as per ISO 4406

| Brand | Lubricant designation normal working conditions |
|-------|---|
| ARAL | Aralub HL 2 |
| FINA | FINA Marson L2 |
| ESSO | ESSO Beacon 2 |
| SHELL | SHELL Ratinax A |

| Brand | Lubricant designation extreme working conditions |
|-------|--|
| ARAL | Aralub HLP 2 |
| FINA | FINA Marson EPL-2 |
| ESSO | ESSO Beacon EP 2 |
| SHELL | Tetinax AM |

Brake shaft bearings, outer and inner



No grease or oil must enter into the brake. Use only lithium-saponified grease with a dropping point higher than 374 °F (190 °C).

Faults

WARNING




Danger of crushing, shearing, cutting, cutting off, being caught, winding up, being pulled in and impact caused by

- accidental lowering of lifted, unsecured machine parts.
- accidental starting and rolling of the machine.

Secure the machine against unintended starting and accidental rolling away, before faults on the machine are rectified. Wait until the machine has come to a halt before entering the danger zone.

| Fault | Cause | Remedy |
|--|--|---|
| The pump does not prime. | Blockage in the suction side (suction hose) / fitting | Remove the blockage. |
| | Pump draws in air. | <ul style="list-style-type: none"> • Check the hose connection on the suction hose for leakage. • Drain valve on suction filter open. • Suction filter housing leaking. |
| Pump does not generate any power. | Jammed or damaged ball valves. | Replace the ball valves. |
| | Pump draws in air, noticeable air bubbles in the spraying mixture container. | Check the hose connections on the suction hose for leak tightness. |
| Wobbling of the spraying cone | Irregular fluid flow from the pump. | Check valves on suction and pressure side, replace if necessary. |
| The required and entered application quantity is not reached. | High travel speed; low pump drive speed | Reduce the travel speed and increase the pump drive speed until both the error message and the audible warning disappear. |
| | Clogged nozzles / nozzle filter or suction filter / pressure filter | Clean nozzles / nozzle filters with compressed air. For this purpose unscrew the nozzles and blow them out with a compressed air gun (on the folding boom middle section). In case of frequent appearance check the suction filter / pressure filter. |
| The permitted spraying pressure range of the installed spraying nozzles is left. | Changed specified travel speed which affects the spraying pressure. | Change the travel speed to reach the travel speed range again that has been determined for spraying operation. |
| The spraying pressure does not maintain the nominal value. | Spraying pressure too low | <ul style="list-style-type: none"> • Clean the filter. • Increase the engine speed. |
| Main cleaning process stops at internal cleaning. | Manual switch-over ball valve internal/outside cleaning set to outside cleaning. | Switch over valve to internal cleaning. |


Superstructure maintenance overview

| Maintenance location | Work instructions | Interval |
|--|--|----------|
| After 10 operating hours | | |
| Retighten all screw and plug-in connections as well as the hydraulic connections. | Even firmly tightened screw connections can come loose (e.g. because of material settlement or paint residues between the screw elements). This can lead to loose screw connections and leaking hydraulic connections. | Once |
| Before the season | | |
| Complete machine | Read the operating instructions carefully as a refresher. | |
| | Check all screw connections for firm seating and retighten as necessary | |
| | Check condition and function of all protective features and replace, if necessary | |
| | Check electrical lines for damage and replace, if necessary. | |
| | Check the function and leak tightness of the hydraulic system and water system. | |
| In use | | |
| Hydraulics | | |
|  WARNING | Lock all hydraulically operated parts before any work on the hydraulic system. Depressurise the hydraulics! Empty the pressure accumulators. | |
| | Allow hydraulic oil and hydraulic components heated during operation to cool down before any work on the hydraulic system. | |
| | Observe the notes on hydraulics in the chapter <i>Safety and responsibility</i> . | |
| Hydraulic system and components | Check all hydraulic components and hoses for function, leak tightness, fastening and chafing | 50 h |
| Hydraulic hoses | Check the hydraulic hoses regularly for damage (cracks, chafing, etc.). | |
| | Replace damaged and faulty hoses immediately. | |
| | Hydraulic hoses must be replaced after 6 years. For this purpose, pay attention to the manufacturing date on the crimp sleeve (year/month) and the hose (quarter/year): | |
| |   | |
| | Crimp sleeve Hose | |
| | Depending on the conditions of use (e.g. weather influences) or in case of higher strains on the machine the hoses may need to be replaced earlier. | |
| | Have the hydraulic system checked by an expert at least once every year. | |
| | In addition, follow the country specific regulations and directives. | |
| Electrics | | |
| Electrical lines | Check for damage | 50 h |
| Lighting | Check function | daily |


| Maintenance location | Work instructions | Interval |
|---|---|----------|
| Water system | | |
| Cleaning centrifugal pump | Cleaning, flushing | daily |
| Spraying mixture container | | |
| Pressure filter | | |
| Suction filter | | |
| Dome screen | | |
| Spraying nozzles | | |
| Spraying centrifugal pump | | |
| Cleaning centrifugal pump | check for leaks | 50 h |
| Spraying centrifugal pump | check for leaks | daily |
| Hose assembly | check for leaks | 50 h |
| Spraying nozzles | Replace worn nozzles | yearly |
| Flow meter | Calibrating the flow meter | yearly |
| High pressure cleaner (optional) | Oil change | yearly |
| Folding boom | | |
| Complete machine | Check for apparent faults | daily |
| Folding boom / parallelogram | Visual inspection of folding joints for zero clearance, apparent faults and wear. In case of play or loose components, have faults corrected by HORSCH Service staff. | 50 h |
| Folding boom | Check setting | yearly |
| Safety installations | | |
| Lighting and warning boards | Check condition and function | daily |
| Warning and safety stickers | Check that they are in place and legible | 50 h |
| At the end of the season | | |
| Complete machine | Perform care and cleaning work; do not spray plastic parts with oil or similar | |
| | Spray the piston rods of the hydraulic cylinder with a suitable corrosion protection agent | |
| | Check all screw and plug-and-socket-connections for firm seating (see torque table) | |
| | Check frame and connecting parts for condition and firm seating | |
| | Check electrical lines for damage and replace, if necessary. | |
| | | |
| NOTES: <ul style="list-style-type: none"> The <i>daily</i> maintenance interval designates maintenance on each working day before working with the machine Follow additional maintenance notes in the respective chapters. | | |

| Lubrication points (lubricating grease: DIN 51825 KP/2K-40) - Lubricate the following, number of lubrication points in brackets | | |
|---|--|---------------|
| Height adjustment | mechanical: lubricate (2 per suspension) | when adjusted |
| | hydraulic: lubricate (2 per suspension) | 10 h or daily |
| Suspension | lubricate (2 per suspension) | 10 h or daily |
| Steering | lubricate (1 per suspension) | 10 h or daily |
| | | |
| Pendulum frame / central frame connection | lubricate (5) | 50 h |
| Central frame | lubricate (2) | 50 h |
| Inside wing / middle frame connection | lubricate (2) | 50 h |
| Parallelogram | lubricate (6 each on both sides) | 50 h |
| Central frame / middle frame tractor link arm | lubricate (2) | 50 h |
| Parallelogram interlock cylinder | lubricate (2) | 50 h |
| | | |
| Outside wing / collision protection | lubricate (2 each on both sides) | 50 h |
| Inside wing / outside wing | lubricate (2 each on both sides) | 50 h |
| Middle section / inside wing | lubricate (4 each on both sides) | 50 h |


Overview of basic vehicle lubrication points



Height adjustment




Suspension



Steering


Folding boom 5-piece double folding




Overview of lubrication points middle section

NOTE


Certain lubrication points can only be reached when the folding boom is unfolded or the parallelogram is raised or lowered.




Pendulum frame / central frame connection




Central frame




Inside wing / middle frame connection




Parallelogram to machine connection



Parallelogram to central frame connection



Central frame / middle frame tractor link arm



Parallelogram lock

Calibrating the flow meter

The flow meter is calibrated by using the tank method. A major amount of water is thereby discharged from the spraying mixture container over a certain period of time.

With the help of simulated travel speed and the spraying duration the distance the machine will travel can be calculated.

Distance = travel speed x spraying duration

Multiplied with the working width gives you the area that would be processed when working with the simulated travel speed and spraying time.

Processed area = distance x working width

You can then calculate the required amount of spraying mixture and compare it with the amount actually used.

Required placing quantity =
processed area x placing quantity

The correction factor for the set pulses/100 l is thereby determined. This is the required quantity, divided by the quantity actually placed.

Correction factor = $\frac{\text{required quantity}}{\text{placed quantity}}$

➤ The value is finally corrected under parameter *Main flow pulses*, and a new calibration is made by using the new values.

For the crop protection sprayer the standard value is 2,100 pulses/100 l.

Example:

The numerical values in the example were randomly chosen and may differ from practice.

- Machine with 36 m working width.
- Setting on terminal: 2,100 pulses / 100 l
- Set 200 l / ha as placing quantity.
- Set 10 km/h as simulated travel speed.
- Note the filling level spraying mixture container.
- Read the value under parameter *Main flow pulses* (pulses/100 l) on the terminal and write it down.
- Switch on the crop protection sprayer and run it for 15 minutes.

The distance thereby is:

10 km/h x 0.25 h = 2,500 m

Multiplying this with the working width gives you a processed area of:

2,500 m x 36 m = 90,000 m² = 9 ha

The product of this area and the set placing quantity results in the required amount of spraying mixture:

9 ha x 200 l/ha = 1,800 l

This value is now set into relation to the quantity actually placed. The actually placed quantity is the difference in filling level spraying mixture container before and after calibration.

Here the quantity actually placed is: 490 lqd gal (1.850 l)

The correction factor in this case is:

Correction factor = $\frac{490 \text{ lqd gal (1.800 l)}}{490 \text{ lqd gal (1.850 l)}} = 0.973$

The placed quantity is too high, the value under parameter 457 therefore needs to be corrected.

New value (pulses/100 l):

2,100 x 0.973 = 2,043

Calibrating the flow meter

The flow meter is calibrated by using the tank method. A major amount of water is thereby discharged from the spraying mixture container over a certain period of time.

With the help of simulated travel speed and the spraying duration the distance the machine will travel can be calculated.

Distance = travel speed x spraying duration

Multiplied with the working width gives you the area that would be processed when working with the simulated travel speed and spraying time.

Processed area = distance x working width

You can then calculate the required amount of spraying mixture and compare it with the amount actually used.

Required placing quantity =
processed area x placing quantity

The correction factor for the set pulses/26 gal lqd is thereby determined. This is the required quantity, divided by the quantity actually placed.

Correction factor = $\frac{\text{required quantity}}{\text{placed quantity}}$

➤ The value is finally corrected under parameter *Main flow pulses*, and a new calibration is made by using the new values.

For the crop protection sprayer the standard value is 2,100 pulses/26 gal lqd.

Example:

The numerical values in the example were randomly chosen and may differ from practice.

- Machine with 120 ft working width.
- Setting on terminal: 2,100 pulses / 26 gal lqd
- Set 21 gal lqd/ac as placing quantity.
- Set 6.2 mph as simulated travel speed.
- Note the filling level spraying mixture container.
- Read the value under parameter *Main flow pulses* (pulses/26 gal lqd) on the terminal and write it down.
- Switch on the crop protection sprayer and run it for 15 minutes.

The distance thereby is:

6.2 mph x 0,25 h = 1.55 mi = ca. 8200 ft

Multiplying this with the working width gives you a processed area of:

8200 ft x 120 ft = 984,000 ft² = 22.5 ac

The product of this area and the set placing quantity results in the required amount of spraying mixture:

22.5 ac x 21 gal lqd/ac = 473 gal lqd

This value is now set into relation to the quantity actually placed. The actually placed quantity is the difference in filling level spraying mixture container before and after calibration.

Here the quantity actually placed is: 488 gal lqd

The correction factor in this case is:

Correction factor = $\frac{473 \text{ gal lqd}}{488 \text{ gal lqd}} = 0.97$

The placed quantity is too high, the value under parameter 457 therefore needs to be corrected.

New value (pulses/26 gal lqd):

2,100 x 0.97 = 2,037

Inspection of the crop protection sprayer

Inspection of the crop protection sprayer must only be carried out by authorized agencies. The national legal inspection intervals must be complied with!

Checking the pump capacity

1. Connect the test hose on the pressure output (2" Camloc coupling required).




Pressure output (figure varies depending on machine type)

2. Open the valve.
3. Adjust the pressure control to 116 psi (8 bar).
4. Switch on the circulation on the terminal. The pump shall run at full capacity at this.
5. Deactivate circulation on the terminal again after the test has been completed.
6. Close the valve.
7. Uncouple the test hose on the pressure output.
8. Close the pressure output with the cap.


Flow meter test

➤ To test the flow meter, the test adapter set (order number 36960072) can be ordered from HORSCH.


1. Disconnect the hose union to the flow meter on the middle section.




2. Connect the first hose of the test adapter set to the flow meter. Connect the second hose of the test adapter set to the dismantled hose on the flow meter.



3. Connect the two other ends of the hoses of the test adapter set to the test device.
4. To perform the test, circulation must be activated on the terminal.
5. Deactivate circulation on the terminal again after the test has been completed.
6. Uncouple both hoses of the test adapter set on the test device and on the sprayer.
7. Reconnect the hose of the flow meter on the middle section of the machine. Ensure a correct and watertight connection!




Maintenance overview chassis

| Maintenance location | Work instructions | Interval |
|---|---|--------------------|
| After 10 operating hours | | |
| Retighten all screw and plug-in connections as well as the hydraulic connections. | Even firmly tightened screw connections can come loose (e.g. because of material settlement or paint residues between the screw elements). This can lead to loose screw connections and leaking hydraulic connections. | Once |
| Retighten allwheel nuts M22 x 1.5 - 375 ft lb (510 Nm) | <ul style="list-style-type: none"> ➤ initially after 10 hours or 31 mi (50 km) ➤ again after 10 hours or 31 mi (50 km) ➤ then retighten daily until the screws have settled and further tightening is no longer possible. ➤ then always before the start of the season and every 50 operating hours during use. | |
| Cabin filter system | | |
| Before the season | | |
| Complete machine | Read the operating instructions carefully as a refresher. | |
| | Check all screw connections for firm seating and retighten as necessary | |
| | Check condition and function of all protective features and replace, if necessary | |
| | Check electrical lines for damage and replace, if necessary. | |
| | Check the function and leak tightness of the hydraulic system and water system. | |
| In use | | |
| Hydraulics | | |
| <div>⚠ WARNING</div> | Lock all hydraulically operated parts before any work on the hydraulic system. Depressurise the hydraulics! Empty the pressure accumulators. | |
| | Allow hydraulic oil and hydraulic components heated during operation to cool down before any work on the hydraulic system. | |
| | Observe the notes on hydraulics in the chapter <i>Safety and responsibility</i> . | |
| Hydraulic system and components | Check all hydraulic components and hoses for function, leak tightness, fastening and chafing | 50 h |
| Hydraulic hoses | Check the hydraulic hoses regularly for damage (cracks, chafing, etc.). | |
| | Replace damaged and faulty hoses immediately. | |
| | Hydraulic hoses must be replaced after 6 years. For this purpose, pay attention to the manufacturing date on the crimp sleeve (year/month) and the hose (quarter/year): | |
| |  | |
| | Crimp sleeve Hose | |
| | Depending on the conditions of use (e.g. weather influences) or in case of higher strains on the machine the hoses may need to be replaced earlier. | |
| Hydraulics pressure filter | Have the hydraulic system checked by an expert at least once every year. | |
| | In addition, follow the country specific regulations and directives. | |
| Hydraulics pressure filter | Replace element | 1200 h or annually |

| Maintenance location | Work instructions | Interval |
|---|---|--------------------|
| Hydraulics suction filter | Replace element | 1200 h or annually |
| Hydraulics spillage oil suction filter | Replace element | 1200 h or annually |
| Hydraulics return suction filter | Replace element | 1200 h or annually |
| Hydraulic oil tank | Oil change | 1200 h or annually |
| Hydraulics priming pump suction filter | Replace element | 1200 h or annually |
| Hydraulics working pump pressure filter | Replace element | 1200 h or annually |
| Electrics | | |
| Electrical lines | Check for damage | 50 h |
| Lighting | Check function | daily |
| Chassis | | |
| Compressed air | Replace dryer cartridge | 2400 or 2 years |
| | Drain air reservoir | daily |
| | Check the filter-regulator combination | daily |
| Engine | Check the oil level | daily |
| | Check oil filter | 100 h |
| | Replace fuel prefilter inspection glass | 600 h or annually |
| | Replace fuel prefilter | 600 h or annually |
| | Replace fuel main prefilter | 600 h or annually |
| | Replace oil filter | 600 h or annually |
| | Change engine oil | 600 h or annually |
| | Check V-ribbed belt | 600 h or annually |
| | Replace the crankcase breather filter | 1200 h or annually |
| | Check AdBlue vent filter and replace as needed (optional) | 1200 h or annually |
| | Clean battery | 1200 h or annually |
| | Check valve cover seal and adjust inlet /outlet valves | 2400 or 2 years |
| | Replace AdBlue filter (optional) | 2400 or 2 years |
| | Replace V-ribbed belt | 3600 or 3 years |
| | Change coolant | 3600 or 3 years |

| Maintenance location | Work instructions | Interval |
|---|---|--|
| Air filter | Check / clean preliminary filter system | 600 h |
| | Replace element | 1200 h or annually |
| | Replace safety element | 2400 or 2 years |
| Cooling system, turbocharger | Check / inspect antifreeze mixture | 100 h |
| | Check hose connections and ports for firm seating | 600 h |
| Air conditioning system | Check air conditioning | as required |
| | Replace air conditioning system drier cartridge | as required |
| | Changing oil of air-conditioning compressor | as required |
| | Change refrigerant | as required |
| Sliding axle | Visual inspection for damages | daily |
| | Retighten grub screws and locking nuts after adjustment | after the first 100 h, then every 1200 h |
| Mechanical height adjustment (optional) | Visual inspection for damages | daily |
| | Retighten all locking nuts after an adjustment. | after the first 100 h, then every 1200 h |
| Wheel drive | Change wheel hub oil | after the first 100 h, then every 600 h |
| | Check rubber gaskets and suspension pins | 600 h |
| Service brake | Check function | 600 h |
| Cabin | Clean / replace pocket filter | every 6 months |
| | Activated-carbon filter category 2 | every 3 months |
| Category 4 filtering (optional) | Activated-carbon filter | every 3 months |
| | Dust filter | every 6 months |
| | Aerosol filters | every 6 months |
| Windscreen washing system tank | Fill windscreen washer tank | as required |

| Maintenance location | Work instructions | Interval |
|---|--|-----------|
| Wheels / brakes | | |
| Undercarriage / wheels | Check for damage (cracks, etc.) | daily |
| | Check fastening / retighten wheel nuts - see above | see above |
| | Check air pressure | daily |
| Brake system | Check function | daily |
| | Check brake lines and hoses for damages, crushing points and kinks | daily |
| | check for leaks | 200 h |
| | Inspection of brake lining | 200 h |
| | Check brake settings | yearly |
| | Bleed brake system | yearly |
| Safety installations | | |
| Lighting and warning boards | Check condition and function | daily |
| Warning and safety stickers | Check that they are in place and legible | 50 h |
| At the end of the season | | |
| Complete machine | Perform care and cleaning work; do not spray plastic parts with oil or similar | |
| | Spray the piston rods of the hydraulic cylinder with a suitable corrosion protection agent | |
| | Check all screw and plug-and-socket-connections for firm seating (see torque table) | |
| | Check frame and connecting parts for condition and firm seating | |
| | Check electrical lines for damage and replace, if necessary. | |
| | | |
| Brake system | Check brake lines, check adjustment | |
| NOTES: <ul style="list-style-type: none"> The <i>daily</i> maintenance interval designates maintenance on each working day before working with the machine Follow additional maintenance notes in the respective chapters. | | |



Check rubber gaskets and steering cylinder cotter pins
(Figure varies depending on the machine design)

Fuels and lubricants

| Filling points | Filling quantity * | Type *** | Change interval ** |
|--|--|---|---|
| Engine (with filter) | approx. 4 gal lqd (15.2 l) | <ul style="list-style-type: none"> • 5W-30 ACEA E6 • 10W-40 ACEA E9 / • API CJ-4 Low SAPs | every 600 operating hours (min. 1x per year) |
| Wheel drive <ul style="list-style-type: none"> • PowerGear (GFT 8130) • HighPowerGear (GFT 8144) | approx. 4 x 64 fl oz (1.9 l) approx. 4 x 88 fl oz (2.6 l) | <ul style="list-style-type: none"> • Min. requirements acc. to CAT TO-4 SAE 50 • Approved oils <ul style="list-style-type: none"> - Mobil Trans HD 50 - Mobilgear SHC XMP 220 - Spirax S4 CX 50 - FUCHS TITAN UTTO TO-4 SAE 50 | after the first 100 and then every 600 operating hours (at least 1x per year) |
| Windscreen washing system | approx. 1 gal lqd (4 l) | | fill up to max. level. |
| Hydraulic system oil change quantity with max. filling | approx. 26 gal lqd (100 l) | Hydraulic oil HVLP-D46 Cleanliness class ISO 4406 18/16/13 | every 1200 operating hours (min. 1x per year) |
| Fuel tank | approx. 118 gal lqd (450 l) | Diesel fuel **** DIN EN 590 | after work and fill up as required |
| AdBlue tank | approx. 12 gal lqd (48 l) | Urea solution AdBlue ISO 22241 | after work and fill up as required |
| Cooling system | approx. 9 gal lqd (35 l) | Mixture of clear, soft water and coolant (red colour) | replace engine coolant after 3 years |
| Air conditioning system | 2 lbs (1.250 kg) | R 134a | as required |
| High pressure cleaner | approx. 14 fl oz (0.4 l) | AGIP GAMMA 30 | yearly |
| Lubrication points, see lubrication chart | up to max. | Lithium saponified grease, NLGI class2 (worked penetration number 265-295) | See lubrication chart; lubricate all other bearings and joints regularly with oil |

* The inspection by means of dipstick or other fluid measuring facilities is decisive for the amount to be filled in

** Time limited by the value reached first

*** Approved brand designations, as far as determined. See current list of fuels and lubricants, which is available in authorized workshops in form of service information.

**** In case of a sulphur content higher than 1% in the diesel fuel, the oil change intervals must be halved. A sulphur content of 0.05% is recommended, but sufficient lubrication abilities (e.g. by additives) must be confirmed by the fuel supplier. Alternative fuels, e.g. RME, only after consultation with authorized workshops.

Maintenance of the hydraulic system

WARNING

Danger of infection caused by high pressure hydraulic oil from the hydraulic system penetrating into the body!
Danger of severe injuries!

If injured by hydraulic oil, consult a doctor immediately!

- Work on the hydraulic system must only be performed by specialist workshops!
- Always depressurize the hydraulic system before starting work in the hydraulic system!
- Use appropriate aids when checking for leaks!
- Never try to seal off leaking hydraulic hoses with your hands or fingers!
- Ensure correct connection of the hydraulic hoses.
- Check all hydraulic hoses and couplings regularly for damage and contamination.
- Have the hydraulic hoses inspected by an expert under safety related aspects at least once every year!
- Replace hydraulic hoses if damaged or excessively aged! Use only original hydraulic hoses from HORSCH!

NOTE

Make sure the hydraulics are depressurised when connecting the hose lines!

NOTE

The hydraulic cylinders must be filled again with hydraulic oil after carrying out installation work on the hydraulic system. The complete hydraulic system must subsequently be bled. This is done by selecting all hydraulic functions several times. Hydraulic cylinders must extend and retract without jerking.

- Danger zones must be blocked off during commissioning.
- When performing installation work, raised machine parts must be lowered completely, moved to a safe position or secured at the particular height by suitable means.

Even if properly stored and under permissible stress, hoses and hose connections are subject to natural ageing. This limits their shelf life and their utilization period.

Deviating from this, the utilization period can also be determined on the basis of empirical values, particularly under due consideration of the endangering potential. For hoses and hose lines made of thermoplastics other guide values may be decisive.

The utilization period of hydraulic hoses should not exceed six years, including a possible storage time of maximum two years.

Depending on the conditions of use (e.g. weather influences) or in case of higher strains on the machine the hoses may need to be replaced earlier.

- Dispose of old oil environmentally. Strictly adhere to the corresponding country-specific regulations.
- Keep hydraulic oil out of the reach of children!
- Make sure that no hydraulic oil enters into the ground or into water!
- In addition, follow the country specific regulations and directives.

NOTE

Additional specifications of the hydraulic system (circuit diagrams, etc.) can be obtained from the HORSCH service department.

Inspection criteria for hydraulic hoses

NOTE

The following inspection criteria must be observed in the interest of your own safety and to reduce environmental damages!

Replace hoses, if these fulfil at least one criterion from the following list:

- Damage to the outer layer to the ply (e.g. chafing, cuts, cracks).
- Embrittlement of the outer layer (formation of cracks in the hose material).
- Deformations, which do not correspond with the natural shape of the hose. Both in pressureless and pressurized condition or in case of bending (e.g. layer separation, formation of blisters, squeezing, buckling).
- Leakages.
- Failure to comply with installation requirements.
- The max. utilization period of 6 years has expired.

The date of manufacture on the hydraulic hose fitting plus 6 years is decisive. If the fitting is marked with the manufacturing date "2014", the utilization period ends in January 2020.

NOTE

Leaking hoses / pipes and connecting pieces are frequently the result of:

- missing O-rings or seals
- damaged or poorly fitted O-rings
- brittle or deformed O-rings or seals
- foreign objects
- loose hose clamps

Assembly and disassembly of hydraulic hoses

NOTE

Use only original spare hoses from HORSCH. These spare hoses withstand the chemical, mechanical and thermal loads.

- Generally use hose clamps made of stainless steel when installing hoses.

When installing and disassembling hydraulic hoses comply with the following notes.

Ensure cleanliness!

Hydraulic hoses must be installed so that the following is ensured under any operating condition:

- no tensile loads, except by own dead weight.
 - no buckling stress in case of short lengths.
 - no falling below the permissible bending radii.
 - avoiding external mechanical stresses on the hydraulic hoses.
 - no rubbing of hoses on components or against each other through appropriate arrangement and fastening.
 - if necessary, protection through protective sheathing.
 - covering sharp-edged components.
- Fasten hydraulic hoses at the intended fastening points.
 - Hose clamps are to be avoided at locations where natural movements and changes of the hose length may be interfered with.
 - It is not permitted to cover hydraulic hoses with paint!

Storage

- Clean the machine thoroughly. Chaff and dirt will attract moisture, which causes corrosion.
- Park the machine indoors and secure it with wheel chocks against rolling away.
- Unplug the terminal and store it in a dry place.
- Protect the machine against corrosion. Use only biodegradable oils for anti-rust spraying.
- Protect the hydraulic cylinder piston rods against corrosion.



NOTE

- Do not spray the plastic and rubber parts with oil or corrosion protection agent. These parts could become brittle and break.

At the end of the season



NOTE

If a high pressure cleaner is used for cleaning, do not direct the water jet to bearings, electrics/electronic components and sensitive cover panels.

- Clean the filter elements of suction and pressure side.
- Lubricate the machine according to the lubrication plan.
- Grease the visible threads of setscrews and similar.
- Wet all lever joints and bearing points, which are not subjected to lubrication, slightly with oil.
- Drain air reservoir.
- Lower the height adjustment (optional).



NOTE

Make a note of all service and maintenance work that has to be done before the start of the next season and place a corresponding order with your HORSCH sales partner in due time. Your HORSCH sales partner will be in a much better position to execute the maintenance service and possibly necessary repairs outside the season.

Drain

Drainage spraying mixture container

1. Switch off all functions.
2. Open the suction filter.
3. Remove the cap on the residue drain.
4. Put a suitable collecting vessel under the drain.
5. Water systems Basic Pro and CCS Pro: Activate the *residue drain* function on page 3 of the external control terminal to completely drain the spraying mixture container.
6. Water systems Basic and CCS: Set the suction and pressure valve for draining the spraying mixture container without residue
7. Empty the pressure filter via the valve.
8. Deactivate the function again on the water systems Basic Pro and CCS Pro after drainage is completed.
9. Close the port again with the cap!
10. Properly dispose of the collected residual spraying mixture!

Drainage fresh water tank

1. Remove the cap on the connection for fresh water filling and open the ball valve.
2. Allow the fresh water to drain.
3. Close the ball valve again at the end and closed the connection with the cap.

Putting the sprayer system into winter storage

Clean machine with fresh water

- See chapter *Cleaning*.


Empty the machine completely

- Drain and clean suction filter.
- Drain and clean pressure filter.
- Activate the air function (optional).
- Operate the high pressure cleaner until no more water runs out (optional).
- Operate the NightLight until no more water runs out (optional).
- Empty the hand washing tank. Open the drain plug on the bottom of the tank for this purpose and then close it again.



Hand washing tank (figure varies depending on the vehicle version)

- Open the cap and filling valve of the fresh water tank to drain it completely.
Open the cap and filling valve of the suction connection to fill the spraying mixture container.
- Open the cap and filling valve of the pressure output to drain the connection.
- Open the cap and filling valve of direct filling to drain it completely (optional).



Filling connections



Direct filling port at the right of the cabin (optional) (figure varies depending on the vehicle version)

Machines with filling pump optional

- Drain the pump

Residue drain

Water systems Basic Pro and CCS Pro:

- Activate the *Pulling suction* function on the external control terminal for approx. 10 sec. to drain the suction connection for filling the wash tank.
- Activate the *residue drain* function on page 3 on the external control terminal to completely drain the spraying mixture container. In addition, all valves will be drained.

- Deactivate the *residue drain* function again on the external control terminal after the spraying mixture container and lines have been completely drained. Close the ball valve for direct filling, filling the fresh water tank, suction connection for filling the spraying mixture container, residue drain and pressure output again. Put on the cap again for pressure output, direct filling, filling the fresh water tank, suction connection for filling the spraying mixture container and residue drain.

➤

Water systems Basic and CCS:

- Set the ball valve on the suction side to spraying mixture container.
- Activate the spraying pump on the external control terminal Mini for approx. 10 sec. to drain the suction port for filling the spraying mixture container.
- Set the ball valve on the suction side to residue drain.
- Set the ball valve on the pressure side to circulation spraying.
- Set the ball valve of the suction side to spraying mixture container after tank and lines are completely drained. Close the ball valve for direct filling, filling the fresh water tank, suction connection for filling the spraying mixture container, residue drain and pressure output again. Replace the cap for pressure output, direct filling, filling of fresh water tank, suction port for filling the spraying mixture container and the residue drain



NOTE

Refer to the supplied HORSCH terminal operating instructions (Chapter Winter storage of spraying system) for further information on putting the spraying system in winter storage.

Winter storage

1. Depending on the desired frost protection, fill the appropriate amount of gallons (litres) of antifreeze and clear water into the fresh water tank. At least 15 gal lqd (60 litres) of the ready mix are required.



NOTE

After draining the machine (without air function) approx. 5-10 gal lqd (20-40 litres) of water still remains in the lines! This residual quantity mixes with the antifreeze mix during the winter storage process and thereby lowers the antifreeze temperature even further!

| Frost-proof to | Antifreeze agent | Clear water |
|----------------------|---------------------|-------------------|
| -4 °F (-20 °C) | 7 gal lqd (30 L) | 5 gal lqd 20 L |
| -16.6 °F (-27 °C) | 9 gal lqd (35 L) | 3 gal lqd 15 L |
| -40 °F -40 °C | 11 gal lqd 45 L | 2 gal lqd 10 L |

This table only serves as a note!



NOTE

Follow the specifications of the antifreeze agent used to mix the desired concentration!
Use only approved anti-freeze agents!

2. Activate outside cleaning on the external control terminal (optional equipment). Apply pressure to the spray gun until antifreeze mix escapes. Now deactivate outside cleaning again.
3. Activate the high pressure cleaner on the external control terminal (optional equipment). Apply pressure to the washing gun until antifreeze mix escapes. Now deactivate the high pressure cleaner again.
4. Activate NightLight cleaning (optional equipment) on the external control terminal until an antifreeze mix escapes at the cleaning nozzles. The function can only be activated for 4 seconds at a time. The function can only be activated again following a pause of 3 seconds.
5. Start the Winter Storage function on the external control terminal. The message *HP Cleaner and NightLight Cleaning actuated?* is displayed. Confirm the message with "ENTER".

NOTE


Refer to the supplied HORSCH terminal operating instructions (Chapter Winter storage of spraying system) for further information on putting the spraying system in winter storage.

Before the new season

Before the start of the new season the machine should be thoroughly examined. A machine in technically mint condition rules out costly malfunctions during the season.


Clean the machine thoroughly from inside and outside.

- Drain the antifreeze agent into a suitable collection vessel via the residue drain.



Residue drain

- Store or dispose of anti-freeze as specified by the manufacturer.
- Drain the fluid in the pressure fitting via the pressure output also into a suitable collection vessel.



Pressure output

- Clean the spraying system thoroughly with fresh water. This is the only way of ensuring that no more antifreeze mix is present in the crop protection sprayer.
Let the existing cleaning programs run several times with fresh water.
- Completely lubricate the machine as per lubrication chart.
- Check whether all bolts have been tightened and that all cotter pins are in place.
- Check the tire pressure!
- Position possibly removed belts and V-belts again and check the belt tension.
- Remove the covers from the engine openings.
- Check all seals and the filling capacity of the engine coolant.
- Check battery. Check the battery charge condition or voltage (recharge the battery, if necessary).

Waste disposal



NOTE

Clean the entire crop protection sprayer thoroughly from inside and outside, before disposing of it!

Oils, greases and waste contaminated with these substances represent a great danger for the environment and must be disposed of environmentally friendly and in compliance with the corresponding legal regulations.

If necessary contact your local authorities to obtain all relevant information.

Various substances will accumulate during use and maintenance, which must be disposed of appropriately.

For the waste disposal of auxiliary and operating media as well as other chemicals you must strictly comply with the specifications in the respective safety data sheets.

Decommissioning

If the machine is no longer suitable for use and needs to be disposed of, it must be decommissioned. All machine parts must be separated by material and passed on to environmentally friendly waste disposal or recycling. Attention must be paid to all valid regulations.

Decommissioning and waste disposal must only be carried out by operators who have been trained by HORSCH.

Contact a waste disposal company, if this should be necessary.

Appendix

Anzugsdrehmoment



HINWEIS

- The tightening torques only serve as guidelines and are generally valid. Actual data given at the corresponding points in the operating instructions have priority.
- Screws and nuts must not be treated with lubricants, since this would change the friction value.

Metric screws

| Tightening torques - metric screws in ft lb (Nm) | | | | | | | |
|--|-------------|---------------------------------|-------------|--------------|--------------|---------------|------------|
| Size ø mm | Pitch mm | Screw design - property classes | | | | | Wheel nuts |
| | | 4.8 | 5.8 | 8.8 | 10.9 | 12.9 | |
| 3 | 0.50 | 0.7 (0.9) | 0.8 (1.1) | 1.3 (1.8) | 1.9 (2.6) | 2.2 (3.0) | |
| 4 | 0.70 | 1.2 (1.6) | 1.5 (2.0) | 2.3 (3.1) | 3.3 (4.5) | 3.9 (5.3) | |
| 5 | 0.80 | 2.4 (3.2) | 3.0 (4.0) | 4.5 (6.1) | 6.6 (8.9) | 7.7 (10.4) | |
| 6 | 1.00 | 4.1 (5.5) | 5.0 (6.8) | 7.7 (10.4) | 11.3 (15.3) | 13.2 (17.9) | |
| 7 | 1.00 | 6.9 (9.3) | 8.5 (11.5) | 12.7 (17.2) | 18 (25) | 22 (30) | |
| 8 | 1.25 | 10.0 (13.6) | 12.4 (16.8) | 18 (25) | 27 (37) | 33 (44) | |
| 8 | 1.00 | 10.7 (14.5) | 13 (18) | 20 (27) | 30 (40) | 35 (47) | |
| 10 | 1.50 | 19.6 (26.6) | 24 (33) | 37 (50) | 54 (73) | 63 (86) | |
| 10 | 1.25 | 21 (28) | 26 (35) | 39 (53) | 58 (78) | 67 (91) | |
| 12 | 1.75 | 34 (46) | 41 (56) | 64 (86) | 94 (127) | 110 (148) | |
| 12 | 1.25 | 37 (50) | 46 (62) | 70 (95) | 103 (139) | 120 (163) | |
| 14 | 2.00 | 54 (73) | 66 (90) | 101 (137) | 148 (201) | 173 (235) | |
| 14 | 1.50 | 58 (79) | 71 (96) | 111 (150) | 162 (220) | 190 (257) | |
| 16 | 2.00 | 83 (113) | 104 (141) | 158 (214) | 232 (314) | 272 (369) | |
| 16 | 1.50 | 89 (121) | 111 (150) | 169 (229) | 248 (336) | 290 (393) | |
| 18 | 2.50 | 116 (157) | 143 (194) | 226 (306) | 321 (435) | 375 (509) | |
| 18 | 1.50 | 131 (178) | 162 (220) | 254 (345) | 362 (615) | 424 (575) | 221 (300) |
| 20 | 2.50 | 164 (222) | 203 (275) | 319 (432) | 454 (615) | 530 (719) | |
| 20 | 1.50 | 183 (248) | 226 (307) | 356 (482) | 507 (687) | 593 (804) | |
| 22 | 2.50 | 225 (305) | 277 (376) | 370 (502) | 622 (843) | 728 (987) | |
| 22 | 1.50 | 249 (337) | 307 (416) | 482 (654) | 688 (932) | 804 (1,090) | 376 (510) |
| 24 | 3.00 | 282 (383) | 350 (519) | 549 (744) | 800 (1080) | 915 (1,240) | |
| 24 | 2.00 | 310 (420) | 383 (519) | 600 (814) | 860 (1160) | 1,000 (1,360) | |
| 27 | 3.00 | 419 (568) | 519 (703) | 740 (1000) | 1,160 (1570) | 1,360 (1,840) | |
| 27 | 2.00 | 454 (615) | 560 (760) | 885 (1200) | 1,300 (1700) | 1,470 (1,990) | |
| 30 | 3.50 | 569 (772) | 730 (995) | 1,100 (1500) | 1,570 (2130) | 1,840 (2,500) | |
| 30 | 2.00 | 630 (850) | 780 (1060) | 1,230 (1670) | 1,750 (2370) | 1,760 (2,380) | |

Inch screws

| Tightening torques - inch screws in ft lb (Nm) | | | | | | | |
|--|------|------------------|---------------|-----------------|---------------|-----------------|---------------|
| Screw diameter | | Strength 2 | | Strength 5 | | Strength 8 | |
| | | No marks on head | | 3 marks on head | | 6 marks on head | |
| Inch | mm | Coarse thread | Fine thread | Coarse thread | Fine thread | Coarse thread | Fine thread |
| 1/4 | 6.4 | 4.1 (5.6) | 4.7 (6.3) | 6.4 (8.6) | 7.2 (9.8) | 9.0 (12.2) | 10.0 (13.5) |
| 5/16 | 7.9 | 8.0 (10.8) | 9.0 (12.2) | 13.0 (17.6) | 14.0 (19.0) | 18.0 (24.4) | 20.0 (27.1) |
| 3/8 | 9.5 | 15.0 (20.3) | 17.0 (23.0) | 23.0 (31.2) | 26.0 (35.2) | 33.0 (44.7) | 37.0 (50.2) |
| 7/16 | 11.1 | 25.0 (33.9) | 27.0 (36.6) | 37.0 (50.2) | 41.0 (55.6) | 52.0 (70.5) | 58.0 (78.6) |
| 1/2 | 12.7 | 35.0 (47.5) | 40.0 (54.2) | 57.0 (77.3) | 64.0 (86.8) | 80.0 (108.5) | 90.0 (122.0) |
| 9/16 | 14.3 | 50.0 (67.8) | 60.0 (81.3) | 80.0 (108.5) | 90.0 (122.0) | 115.0 (156.0) | 130.0 (176.3) |
| 5/8 | 15.9 | 70.1 (95.0) | 80.0 (108.5) | 110.0 (149.1) | 125.0 (169.5) | 159.0 (216.0) | 180.0 (244.0) |
| 3/4 | 19.1 | 125.0 (169.5) | 140.0 (189.8) | 200.0 (271.1) | 220.0 (298.3) | 280.0 (380.0) | 315.0 (427.0) |
| 7/8 | 22.2 | 130.0 (176.3) | 145.0 (196.6) | 320.0 (433.9) | 350.0 (474.5) | 450.0 (610.0) | 500.0 (678.0) |
| 1 | 25.4 | 190.0 (257.6) | 205.0 (278.0) | 480.0 (650.8) | 530.0 (718.6) | 675.0 (915.2) | 750.0 (1,017) |
| 1 1/8 | 28.6 | 265.0 (359.3) | 300.0 (406.8) | 600.0 (813.5) | 670.0 (908.4) | 960.0 (1,302) | 1,075 (1,458) |
| 1 1/4 | 31.8 | 375.1 (508.5) | 415.0 (562.7) | 840.0 (1,139) | 929 (1,261) | 1,360 (1,844) | 1,500 (2,034) |
| 1 3/8 | 34.9 | 490.0 (664.4) | 560.0 (759.3) | 1,100 (1,491) | 1,250 (1,695) | 1,780 (2,414) | 2,030 (2,753) |
| 1 1/2 | 38.1 | 650.0 (881.3) | 730.0 (989.8) | 1,450 (1,966) | 1,650 (2,237) | 2,307 (3,128) | 2,670 (3,620) |

Stainless steel screws


| Tightening torques - stainless steel screws in ft lb (Nm) | | | | |
|---|-------------|-------------------|-------------------|-------------------|
| Size ø mm | Pitch mm | Screw design | | |
| | | Property class 50 | Property class 70 | Property class 80 |
| 5 | 0.80 | 1.3 (1.7) | 2.6 (3.5) | 3.5 (4.7) |
| 6 | 1.00 | 2.2 (3.0) | 4.4 (6.0) | 5.9 (8.0) |
| 8 | 1.25 | 5.2 (7.1) | 12 (16) | 16 (22) |
| 10 | 1.50 | 10 (14) | 24 (32) | 32 (43) |
| 12 | 1.75 | 18 (24) | 41 (56) | 55 (75) |
| 16 | 2.00 | 44 (59) | 100 (135) | 133 (180) |
| 20 | 2.50 | 84 (114) | 207 (280) | 273 (370) |
| 24 | 3.00 | 146 (198) | 336 (455) | 446 (605) |
| 30 | 3.50 | 290 (393) | 774 (1,050) | 1,000 (1,400) |

HORSCH Leeb metering cup

The Horsch Leeb metering cup is used to adjust and check agricultural spraying implements. Before starting the measurement, the field sprayer to be calibrated must be filled with clean water. Now open the nozzles with the desired settings for placing the crop protection agents. All nozzles should always be opened during setting or checking.

Determining the placing quantity in l/ha

To determine the placing quantity, the HORSCH Leeb metering cup is held under a spraying nozzle of the field sprayer for 30 seconds at 20 in. (50 cm) nozzle spacing and for 60 seconds at 10 in. (25 cm) nozzle spacing. The pump must be switched on for the entire period and the placing quantity set on the terminal must not be changed. Now place the metering cup on a level surface. The fluid level indicates the measured placing quantity at different travel speeds.




The example shows: 16 gal lqd/ac (150 l/ha) at 7.5 mph (12 km/h) or 21 gal lqd/ac (200 l/ha) at 5.6 mph (9 km/h) etc.

- Placing quantity too high, lower spraying pressure.
- Placing quantity too low, increase spraying pressure.

Nozzle selection and control

The fluid level, which indicates the placing quantity in l/ha on one side of the HORSCH Leeb metering cup, shows at the same time on the other side of the measuring cup with which nozzle size and at which spraying pressure this placing quantity is reached.

- At a nozzle spacing of 20 in. (50 cm) the respective nozzle sizes can be read off directly.
- At a nozzle spacing of 10 in. (25 cm) the respective nozzle sizes must be halved.



Example: The previous fluid level indicates that at 20 in. (50 cm) nozzle spacing the desired placing quantity of 16 gal lqd/ac (150 l/ha) is achieved at approx. 7 mph (12 km/h) with nozzle size 04 (red) at approx. 40 psi (2.7 bar) or with nozzle size 03 (blue) at approx. 70 psi (4.8 bar) etc. Accordingly, with a nozzle spacing of 10 in. (25 cm), the placing quantity of 16 gal lqd/ac (150 l/ha) at 7 mph (12 km/h) is achieved with nozzle size 02 (yellow) at approx. 40 psi (2.7 bar) or with nozzle size 015 (green) at approx. 70 psi (4.8 bar).

All values apply to water with a temperature of 59°F° (15 °C) and the pressure measured at the nozzle. As a rule, the spraying pressure displayed at the terminal is slightly higher, as pressure losses occur between the fittings and nozzles.

Liquid fertiliser operation

At present there are mainly two different types of liquid fertiliser available:

- Ammonium nitrate - carbonyl diamide solution (AHL) with 61 lbs (28 kg) N per 220 lbs (100 kg) AHL.
- An NP-solution 10-34-0 with 22 lbs (10 kg) N and 74 lbs (34 kg) P₂O₅ per 220 lbs (100 kg) NP-solution.

When using flat jet nozzles the corresponding values for the application quantity gal lqd/ac (l/ha) from the spraying table must be multiplied with 0.88 for ammonium nitrate - carbonyl diamide solution and 0.85 for NP-solution. The listed application quantities (l/ha) apply only for water.

The following is generally valid:

Place liquid fertiliser in the form of coarse drops to prevent burning of plants. Excessively large drops will roll off the leaf and small drops enhance the magnifying glass effect.

Due to the salt concentration in the fertiliser, excessive application of fertiliser can cause burning on the leaves.

3-jet nozzles (optional)

The use of 3-jet nozzles for the application of liquid fertiliser is beneficial if the liquid fertiliser is to enter into the plant through the roots rather than through the leaf.

The nozzle orifice integrated in the nozzle with its opening ensures an almost pressureless, coarse drop distribution of the liquid fertiliser. This prevents the generation of undesired spray mist and the formation of small droplets. The coarse drops created by the 3-jet nozzle hit the plants with low energy and roll off their surface.

Even though damage caused by burning is almost completely prevented, one should not use 3-jet spray nozzles for late top dressing, but use trailed hoses instead.

Only use the black bayonet nuts for all the following 3-jet nozzles.

| Various 3-jet nozzles and their fields of application at approx. 5 mp/h (8 km/h) | |
|--|---|
| 3 - jet - yellow | 5.3 - 8.5 gal lqd/ac (50 - 80 l/ha) (AHL) |
| 3 - jet - red | 8.5 - 13.5 gal lqd/ac (80 - 126 l/ha) (AHL) |
| 3 - jet - blue | 12 - 19 gal lqd/ac (115 - 180 l/ha) (AHL) |
| 3 - jet - white | 17 - 28.5 gal lqd/ac (155 - 267 l/ha) (AHL) |



NOTE

The pump must be flushed with fresh water after each liquid fertiliser operation. If not flushed with fresh water, the pump seals may become damaged!

Conversion table for spraying liquid fertiliser AHL

(Ammonium nitrate - carbonyl diamide solution)

NOTE

When filling pay attention to the different densities [lb/gal] ([kg/l]) of the individual fluids and the permissible payload of the crop protection sprayer!

| N lbs (kg) | Sol. N gal (litre) | Sol. N lbs (kg) | N lbs (kg) | Sol. N gal (litre) | Sol. N lbs (kg) | N lbs (kg) | Sol. N gal (litre) | Sol. N lbs (kg) |
|------------------|--------------------------|-----------------------|------------------|--------------------------|-----------------------|------------------|--------------------------|-----------------------|
| 22 (10) | 7 (27.8) | 78 (35.8) | 171 (78) | 57 (216.5) | 613 (278.3) | 304 (138) | 101 (384.0) | 1.086 (493.0) |
| 26 (12) | 8 (33.3) | 94 (42.9) | 176 (80) | 58 (222.1) | 360 (285.8) | 308 (140) | 102 (389.0) | 1.002 (500.0) |
| 30 (14) | 10 (38.9) | 110 (50.0) | 180 (82) | 60 (227.9) | 645 (292.8) | 313 (142) | 104 (394.0) | 1.117 (507.0) |
| 35 (16) | 11 (44.5) | 125 (57.1) | 185 (84) | 61 (233.3) | 661 (300.0) | 317 (144) | 105 (400.0) | 1.135 (515.0) |
| 39 (18) | 13 (50.0) | 141 (64.3) | 189 (86) | 61 (233.3) | 677 (307.5) | 321 (146) | 107 (406.0) | 1.148 (521.0) |
| 44 (20) | 14 (55.5) | 157 (71.5) | 194 (88) | 63 (242.2) | 692 (314.1) | 326 (148) | 108 (411.0) | 1.166 (529.0) |
| 48 (22) | 16 (61.6) | 173 (78.5) | 198 (90) | 66 (250.0) | 709 (321.7) | 330 (150) | 110 (417.0) | 1.179 (535.0) |
| 52 (24) | 17 (66.7) | 188 (85.6) | 202 (92) | 67 (255.7) | 723 (328.3) | 341 (155) | 113 (431.0) | 1.221 (554.0) |
| 57 (26) | 19 (75.0) | 204 (92.9) | 207 (94) | 69 (261.2) | 740 (335.8) | 352 (160) | 117 (445.0) | 1.261 (572.0) |
| 61 (28) | 20 (77.8) | 220 (100) | 211 (96) | 70 (266.7) | 755 (342.7) | 363 (165) | 120 (458.0) | 1.298 (589.0) |
| 66 (30) | 22 (83.4) | 236 (107.1) | 216 (98) | 71 (272.0) | 771 (350.0) | 374 (170) | 124 (472.0) | 1.338 607.0 |
| 70 (32) | 23 (89.0) | 251 (114.2) | 220 (100) | 73 (278.0) | 787 (357.4) | 385 (175) | 128 (486.0) | 1.377 625.0 |
| 74 (34) | 24 (94.5) | 267 (121.4) | 224 (102) | 74 (283.7) | 802 (364.2) | 396 (180) | 132 (500.0) | 1.417 (643.0) |
| 79 (36) | 26 (100.0) | 283 (128.7) | 229 (104) | 75 (285.5) | 819 (371.8) | 407 (185) | 135 (514.0) | 1.455 (660.0) |
| 83 (38) | 27 (105.6) | 299 (135.9) | 233 (106) | 77 (294.2) | 834 (378.3) | 418 (190) | 139 (527.0) | 1.496 (679.0) |
| 88 (40) | 29 (111.0) | 315 (143.0) | 238 (108) | 79 (300.0) | 850 (386.0) | 429 (195) | 142 (541.0) | 1.534 (696.0) |
| 92 (42) | 30 (116.8) | 330 (150.0) | 242 (110) | 80 (305.6) | 866 (393.0) | 440 (200) | 146 (556.0) | 1.574 714.0 |
| 97 (44) | 32 (122.2) | 346 (157.1) | 246 (112) | 82 (311.1) | 881 (400.0) | | | |
| 101 (46) | 33 (127.9) | 362 (164.3) | 251 (114) | 83 (316.5) | 889 (407.5) | | | |
| 105 (48) | 35 (133.3) | 378 (171.5) | 255 (116) | 85 (322.1) | 913 (414.3) | | | |
| 110 (50) | 36 (139.0) | 393 (178.6) | 260 (118) | 86 (328.0) | 928 (421.0) | | | |
| 114 (52) | 38 (144.6) | 410 (186.0) | 264 (120) | 87 (333.0) | 943 (428.0) | | | |
| 119 (54) | 39 (150.0) | 425 (193.0) | 268 (122) | 89 (339.0) | 961 (436.0) | | | |
| 123 (56) | 41 (155.7) | 440 (200.0) | 273 (124) | 90 (344.0) | 967 (443.0) | | | |
| 127 (58) | 42 (161.1) | 457 (207.3) | 277 (126) | 92 (350.0) | 992 (450.0) | | | |
| 132 (60) | 44 (166.7) | 472 (214.2) | 282 (128) | 94 (356.0) | 1.107 (457.0) | | | |
| 135 (62) | 45 (172.3) | 488 (221.7) | | | | | | |
| 141 (64) | 46 (177.9) | 503 (228.3) | 286 (130) | 95 (361.0) | 1.025 (465.0) | | | |
| 145 (66) | 48 (183.4) | 520 (235.9) | | | | | | |
| 149 (68) | 49 (188.9) | 535 (243.0) | 291 (132) | 96 (367.0) | 1.038 (471.0) | | | |
| 154 (70) | 51 (194.5) | 551 (250.0) | | | | | | |
| 158 (72) | 52 (200.0) | 567 (257.2) | 295 (134) | 98 (372.0) | 1.053 (478.0) | | | |
| 163 (74) | 54 (204.9) | 582 (264.2) | | | | | | |
| 167 (76) | 55 (211.6) | 599 (271.8) | 299 (136) | 99 (378.0) | 1.069 485.0 | | | |

Density: 10.65 lb/gal (1.28 kg/l), i.e. approx. 61 lbs (28 kg) N to 220 lbs (100 kg) liquid fertiliser or 79 lbs (36 kg) N to 26 gal lqd (100 litre) liquid fertiliser at 41 - 50 °F (5 - 10 °C)

Index

Symbole

12 Volt vehicle network 70,133

A

Acceleration characteristics 128
Access ladder 73,90
Accessories 9
Access steps 138
Activated-carbon filter 116
AdBlue 237
AdBlue filter change 50
Aerosol filters 116
Agitator 137,144,198,205,206
Air conditioning control unit 66
Air conditioning system 66,76,92,95,98,235,237
Air filter 64,66,115,235
Air flow 94
Air pressure of tyres 58
Air reservoir 68,234
Air valve 217
Ammonium nitrate - carbonyl diamide solution 178,193,248,249
Anzugsdrehmoment 245
Appendix 245
Application quantity 177,178,204
Application quantity, fault 222
Arm rest 82,89
Arm rest inclination 82
Assist starting 133
Audio track 120
Axle load 36
Axles 55

B

Backrest adjustment 82
Battery 14,70,71,234
Battery capacity 71
Battery main switch 71,123
Bayonet cap 157,158
Bayonet connection 157,158
Bayonet nut 159
Blow-out process 217
Bluetooth 122
BoomControl 152,172
BoomControl modes 152

Brake 170
Brakes 128
Brake system 14,54,171,236

C

Cabin 73,235
Cabin air filtering category 4 115
Cabin door 74
Cabin light 77,101
Cabin sockets 107
Cabin temperature 93
Cabin windows 94
Camera system 103
Canister 202
Canister flushing 142,202
Carbonyl diamide 201
Care 17
CCS - Continuous inside cleaning 214
Central electrics 75,77,108,110
Centrifugal pump 141
Chargers 133
Cigarette lighter 107
Circulating air filter 77,78,113
Circulation 188,192
Circulation system 156
Cleaning 211,212,214,216
Cleaning nozzles 159
Climatronic 92,93
Closed circuit flushing 142
Collision protection 150,155
Commissioning 26,170
Components chassis 45
Compressed air 234
Compressed air connection 47,157,158
Compressed air system 68
Compressor 66
Condenser 66,67
Contamination 212
Control unit 146
Control valve 157
Conversion table 249
Cooler package 64
Cooling box 102
Cooling system 14,235,237
Cover 46

Crankcase 46
Crop protection agent 176,178,196,204,206,208
Cruise control 131,172

D

Damage 7
Danger zone 19,205
Decommissioning 244
Delivery 26
Density 193
Design 40,137,138
Diaphragm 159
Diaphragm valve 159
Diesel filter change 51
Diluted residual quantity 209
Dimensions 36
Direct filling 147,148,166,185,189,195
Direction of travel 128
Disposal 219
Distance reduction 207
Dome 137,139,196
Dome screen 139,146,185,189,224
Door 100
Drain 240
Drift 204,206
Drilling 220
Drinking water 210
Drive lever 90,91,126,127,128,131
Driver's seat 75,79
Drive slippage control 129
Driving information 88
Driving lights 76
Dryer cartridge 66,67,234

E

ECON mode 92,94
ECON operation 94
Edge and border nozzles 164
Electrical vehicle socket outlets 107
Electric power supply 123
Electrics 13
Electric system 211
Emergency exit 100
Emptying of machine 241
Empty preparation containers 203
Engine 45,123,124,234,237
Engine coolant 46
Engine oil 45
Engine operation 123

Engine start 123
Environment 244
Error code table 97
Evaporator 66
Exhaust gas system 49
Expansion valve 66
External control terminal 137,147,148
External filling 195

F

Fan nozzle 78
Fan setting 93
Fan speed 92,93
Fault 95
Faults 222
Field mode 130,136
Field travel 77
Filling 186,190,193,199,201,202,203
Filling connection 140,147,148,194,199,200
Filling connections 137
Filling level gauge 143
Filling quantity 177
Filter 144,149
Filter-regulator combination 68
Fire extinguisher 169
Fittings 147
Flange 37
Flashing beacon 76
Flow meter 204,230,231,232
Fluid 186,190
Fluid level 71
Foam 193
Folding 174
Folding boom 137,150,174
Folding boom cleaning 217
Folding boom control 205
Folding boom lock 150,153
Folding boom rest 150,154
Folding in 175
Folding variants 151
Foot brake pedal 100
Foot pedal 100
Foreword 7
Forward driving 125
Fresh air filter category 2 113
Fresh water 241
Fresh water tank 137,140,147,148,196,210,240
Fuel filter 49,234
Fuel prefilter 234

Fuel pump 48
Fuels and lubricants 237
Fuel tank 48,237
Fuses 108,110

G

Generator 71
GPS receiver 162,163

H

Hand pump 55
Hand washing tank 137,140,241
Hazard light system 77
Headland 204
Headlight flasher 87
Heating 76,92
Height adjustment 80,89
High beam 87
HighPowerGear 56
High pressure cleaner 167,211,237,241
Hillside locations 20
Hinged clamp 158
Hinged lid 142
Horizontal suspension 80
Horn 86
Hose clamps 219
Hose reel 167
Hydraulic oil cooler 53
Hydraulic oil filter 53
Hydraulic oil tank 52,234
Hydraulics 13,41,223,233,234,239
Hydraulics, cleaning 211
Hydraulic system 171,238

I

Ignition 99,123
Ignition key 124
Ignition lock 75,99,123
Illuviation 198,201
Illuviation valve 137,142,198,199,200,201,202
Inch screws 246
Inspection glass 52
Installation 26
Instructor's seat 75,84
Internal cabin pressure 77
Internal cleaning 214
ISOBUS 99

J

Joint mechanism 155
Jump lead 133

L

Lateral horizontal suspension 83
Length 31
Liability 7
Lighting 42
Light system 171
Liquid fertiliser operation 248
Liquid preparations 201
Load bearing capacity 36,37
Longitudinal adjustment 81,89
Lubrication points 225
Lumbar support 82

M

Machine terminal 75,99,129,130,135
Maintenance 17,54,223,233
Maintenance access 62,137,139
Mechanical release device folding boom parallelogram 60
Mechanical release device spraying pump and fan 60,62
Media files 120,121
Meshes 145
Mesh size 146
Metering cup 143
Metrische Schrauben 245
Middle section 150
Minimum distance 211
Mirror heating 106
Monitor 75
Multi-function control panel 75,89,172
Multi-function switch 86
Multi-mode buttons 120
Multiple nozzle body manual quadruple 158
Multiple nozzle body manual triple 157
Multiple nozzle body pneumatic 158

N

NightLight 165,241
Nozzle 158
Nozzle assembly 159
Nozzle body 157
Nozzle camera 105
Nozzle control 156
Nozzle opening 145
Nozzle replacement 159
Nozzles 145,178,204,248
Nozzle selection 178
NP-solution 178,193,248
N-Sensor bracket 168

O

Oil change 52
Oil dipstick 45
Oil filter 234
Oil pressure 45
On/off 120
Operating terminal 75,99
Operation 135,170
Operator functions 90,172
Optional equipment 162
Outside cleaning 137,166,217
Outside rear view mirror 76,106
Outside temperature 94

P

Parallelogram 150,224
Parallelogram lock 150,154
Parking 170
Parking brake 125,127,128,170,171
Payload 193,249
Pedal 75,100,125,126,127,129
Personal protective outfit 193
Phone calls 120
Pipes 156
Piston diaphragm pump 185,189
Placing quantity 205
Placing quantity table 181
Pneumatic control valve 158
Ports 147,148
Position sensor 204
PowerGear 56
Preparations 201
Pressure 33,176,204,206
Pressure accumulator 13
Pressure filter 145,149,205,212,224,233,241
Pressure filter elements 145
Pressure hose 167
Pressure monitoring 118
Pressure output 147,148,185,189,207
Pressure plate 143,202,203
Pressure switch 66,67
Protective outfit 167,176
Pump 222
Pump capacity 232

R

Radio 76,120
Radio frequency range 103,120
Radio loudspeakers 78
Radio operation 120
Radio station 120,121
Reading lamp 77,101

Rear axle steering 90,130
Rear view camera 75,105
Recycling 244
Refill quantity 177
Refrigerant 66
Refrigerant R134a 66
REHEAT mode 92,94
Release button 126,127,128
Remedy 95
Residual quantities 208
Residual quantity 34,208,209
Residue drain 147,148,241
Retaining clip 143
Return suction filter 234
Reverse driving 127
Reversing fitting 142
Ribbed V-belt 47,234
Rinsing nozzles 143
Road / field travel 132
Road mode 130,135
Road transportation 12
Road travel 77
Roof console 76,77,78
Rubber seal 157,158

S

Safety 9
Safety and protective features 219
Safety container 72
Safety element 66
Safety package 168
Safety stickers 21
Screw connections 18,220
Seal, nozzle 159
Seat belt 83
Seat depth adjustment 81
Seat heating 83
Seat inclination adjustment 81
Seat occupation detection 79
SectionBox 173
Sections 33,172
Sensor 204
Service 8
Service brake 129
Service brake system 14,30
Service mode 91
Service position 90,91
Shock nozzle 142,143,198,201
Single nozzle body 157
Sliding axle 235
Slope compensation 150,155,172
Slope mode 90,131

Sockets 107
Software menu 103,120,121
Spare parts 9,219
Speed 33,178,181,204
Spraying 206,207
Spraying boom 205,206
Spraying cone, fault 222
Spraying function 90
Spraying height 205
Spraying line 156
Spraying mixture 167,176,177,193,220
Spraying mixture container 137,138,144,194,224,240
Spraying nozzles 172,224
Spraying operation 99,176,187,188,191,192,204
Spraying pressure 176,204,206
Spraying pressure, fault 222
Spraying pump 137,141,185,189
Spraying table 206
Spring accumulator 91
Stability 20
Stainless steel screws 246
Starter 71
Station scan 120
Steam jet 211
Steering 54
Steering column 75,85
Steering column adjustment 85
Stickers 21,44
Stirring intensity 144
Storage 240
Storage compartment 75,77,102,137
Stowage bag 83
Suction filter 146,149,205,213,224,234,241
Suction opening 143
Suction port 147,148
Sun visor 76,101
Suspension 59,90
Switch-over ball valve 142,199,200,201,202

T

Table 178,180,182,183
Target area distance 207
Technical data 31
Technical residual quantities 208
Temperature unit 94
Terminal 130,132,175,176,199,200,204,206
Test braking 30
Tight fit of wheel nuts 58
Tool bracket 72
Tool storage 72
Top speed 12

Total length 31
Towing 133
Traffic 11
Transport 26
Transport height 31
Transport lock 153
Transport mode 91
Transport position 171
Transport width 11
Travel direction indicator 87
Travel direction switch 91,125
Travel distance 208
Travel modes 130
Travel operation 125
Travel speed 178,181,204
Turbocharger 235
Type approval 12
Type plate 35
Tyre load bearing capacity 36
Tyres 36,37,57,58

U

Ultrasonic sensor 152
Unfolding 175
USB ports 107
Use in the field 15

V

Valve 157,158
Ventilation 140
Volume 33
Volume knob 120

W

Warning 193
Warning messages 136
Warranty 7
Washing facility 165
Washing gun 142,143,167,199,200
Washing program 215
Waste disposal 244
Water separator 68
Water system 224
Weight 36
Weight adjustment 80
Welding 220
Wheel camera 105
Wheel drive 56,235,237
Wheel nuts 233
Wheels 30
Wheels / brakes 236
Wind meter 166

Windscreen washing system 68,86
Windscreen wipers 86
Wind speed 204
Winter storage 241,242
Working height 206
Working lights 76
Working pressure 33

All details on technical specifications and pictograms are approximate and for information only. Subject to technical product revisions.

**HORSCH LEEB Application
Systems GmbH**
Kleegartenstraße 54
94405 Landau a. d. Isar

Tel.: +49 9951 6041-0
Fax: +49 9951 6041-3092
E-Mail: info.leebe@horsch.com

HORSCH
Farming with passion

www.horsch.com