

Clearing NVRAM on an AGI3

- 1) With the unit powered on as shown below, you should see lights on the AGI3. The Power light should be solid green. The Stat light should be blinking green and amber.



- 2) Second you will need to disconnect the main cable from the back of the AGI3 as seen below.



- 3) Last you will need to hold down the white function button and restore the main cable back to the AGI3. Note, you cannot let up on the white Function button until you see the LED's blink through the series of blink explained below.

The Stat, RX TX, and System fix light will blink amber in color slowly at first and then start to blink faster. Finally the lights will go red and then sequence will repeat. Continue to hold the button down until you see the sequence repeat itself four times. Once you have seen the sequence repeat its self four times you can let go of the function button.

